



# CM, CME

Service instructions



# CM, CME

---

English (GB)	
Service instructions .....	3

Original service instructions.

## CONTENTS

	Page
<b>1. Symbols used in this document</b>	<b>3</b>
<b>2. Type identification</b>	<b>4</b>
2.1 Nameplate	4
2.2 Type key	5
<b>3. Tightening torques and lubricants</b>	<b>6</b>
<b>4. Service tools</b>	<b>7</b>
4.1 Standard tools	7
4.2 Torque tools	7
<b>5. Dismantling and assembly</b>	<b>8</b>
5.1 General information	8
5.2 CM 1, 3, 5, cast iron	8
5.3 CM 1, 3, 5, stainless steel	9
5.4 CM 10, 15, 25, cast iron	11
5.5 CM 10, 15, 25, stainless steel	12
5.6 MG 71 and MG 80 motors	14
5.7 MG 90, MG 100, MG 112 and MG 132 motors	14
5.8 Checking and replacing impellers and chambers	15
<b>6. Fault finding</b>	<b>16</b>
<b>7. Drawings</b>	<b>17</b>
7.1 CM 1, 3, 5	17
7.2 CM 10, 15, 25	19
<b>8. Order of assembly for chambers and impellers</b>	<b>21</b>
8.1 Key for CM 1, 3, 5	21
8.2 CM 1, 3, 5, cast iron	21
8.3 CM 1, 3, 5, stainless steel	21
8.4 Key for CM 10, 15, 25	22
8.5 CM 10, 15, 25, cast iron	22
8.6 CM 10, 15, 25, stainless steel	23

## 1. Symbols used in this document



Warning

If these safety instructions are not observed, it may result in personal injury.



If these safety instructions are not observed, it may result in malfunction or damage to the equipment.



Notes or instructions that make the job easier and ensure safe operation.

## 2. Type identification

This section shows the nameplate, the type key and the codes that can appear in the variant code.

**Note** As codes can be combined, a code position may contain more than one code (letter).

### 2.1 Nameplate

<b>Type</b> [ 1 ]		<b>P<sub>max</sub></b> [ 6 ] bar [ 6 ] <b>PSI</b> [ 6 ] <b>MPa</b>	
<b>Model</b> [ 2 ]		<b>T<sub>liq,max</sub></b> [ 7 ] °C [ 7 ] °F	
<b>Env</b> [ 3 ]	<b>IP</b> [ 4 ]	<b>T<sub>Amb</sub></b> [ 5 ] °C [ 5 ] °F	<b>Insulation class</b> [ 8 ] [ 9 ]
<b>50 Hz</b>	<b>Q<sub>nom</sub></b> [ 10 ] <b>m<sup>3</sup>/h</b> [ 10 ] <b>GPM</b>	<b>50 Hz</b>	<b>Q<sub>nom</sub></b> [ 10 ] <b>m<sup>3</sup>/h</b> [ 10 ] <b>GPM</b>
	<b>H<sub>nom</sub></b> [ 11 ] <b>m</b> [ 11 ] <b>PSI</b>		<b>H<sub>nom</sub></b> [ 11 ] <b>m</b> [ 11 ] <b>PSI</b>
	<b>H<sub>max</sub></b> [ 12 ] <b>m</b> [ 12 ] <b>PSI</b>		<b>H<sub>max</sub></b> [ 12 ] <b>m</b> [ 12 ] <b>PSI</b>

Fig. 1 Pump nameplate



<b>50 Hz</b> [ 1 ] ~ [ 2 ] / [ 2 ] <b>V</b>		<b>60 Hz</b> [ 1 ] ~ [ 2 ] / [ 2 ] <b>V</b>	
<b>I<sub>max</sub></b> [ 3 ] / [ 3 ] <b>A</b>		<b>I<sub>max</sub></b> [ 3 ] / [ 3 ] <b>A</b>	
<b>I<sub>1/1</sub></b> [ 4 ] / [ 4 ] <b>A</b>		<b>I<sub>1/1</sub></b> [ 4 ] / [ 4 ] <b>A</b>	
<b>P<sub>2</sub></b> [ 5 ] <b>kW</b> [ 5 ] <b>HP</b>		<b>P<sub>2</sub></b> [ 5 ] <b>kW</b> [ 5 ] <b>HP</b>	
<b>Capacitor</b> [ 6 ] <b>uF / V</b>		<b>Capacitor</b> [ 6 ] <b>uF / V</b>	
 			

Fig. 2 Motor nameplate

The pump and motor nameplates are positioned on the motor fan cover or terminal box. The data and information on the pump nameplate are described in the table below.

Pos.	Description
1	Pump type
2	Pump model
3	Environmental rating for enclosures based on NEMA type designations
4	Enclosure class
5	Maximum ambient temperature [°C] / [°F]
6	Maximum system pressure [bar] / [psi] / [MPa]
7	Maximum liquid temperature [°C] / [°F]
8	Insulation class
9	Motor protection
10	Rated flow [m <sup>3</sup> /h] / [GPM]
11	Head at rated flow [m] / [psi]
12	Maximum head [m] / [psi]

The data and information on the motor nameplate are described in the table below.

Pos.	Description
1	Number of phases
2	Voltage [V]
3	Maximum current [A]
4	Rated current [A]
5	Power output [kW] / [hp]
6	<b>Single-phase pumps only:</b> Capacitor size [µF] and voltage [V]

## 2.2 Type key

### CM, CME

#### Example

CME 10 -8 A -R -A -E -A V B E X -X -X -X

#### Type range

CM: Centrifugal Modular

CME: CM with integrated frequency converter

#### Rated flow rate

Rated flow rate at 50 Hz [m<sup>3</sup>/h]

Number of impellers

#### Pump version

- A: Basic version
- B: Oversize motor (one flange size larger)
- E: Pumps with certificates and other approvals
- HS: High-pressure pump with high-speed MGE motor
- I: Altered pressure class
- J: Pump with a different maximum speed
- M: Magnet-driven pump
- N: CME pump with sensor (see code for "Sensor")
- P: Undersize motor (one flange size smaller)
- T: Oversize motor (two flange sizes larger)
- V: CME pump for Multi-E
- X: Special pump

#### Pipe connection

- C: Tri-Clamp®
- F: DIN flange
- G: ANSI flange
- J: JIS flange
- P: PJE coupling
- R: Whitworth thread Rp (ISO 7/1)
- S: Internal NPT thread

#### Materials in contact with pumped liquid

	Inlet and discharge parts	EN-GJL-200
A:	Pump shaft	EN 1.4057/AISI 431
	Impellers/chambers	EN 1.4301/AISI 304
	Sleeve	EN 1.4401/AISI 316
G:	Pump shaft	EN 1.4401/AISI 316
	Impellers/chambers	EN 1.4401/AISI 316
	Sleeve	EN 1.4301/AISI 304
I:	Pump shaft	EN 1.4301/AISI 304
	Impellers/chambers	EN 1.4301/AISI 304
X:	Special version	

#### Rubber parts in pump (excl. neck ring and shaft seal)

- E: EPDM (ethylene propylene)
- K: FFKM (perfluor)
- V: FKM (fluor)

**Note:** Gaskets between chambers of cast-iron versions are made of Tesnit BA-U.

#### Sensor

Sensor designation

#### Mains plug

- A: Cable glands
- B: Harting plug
- C: With cable

#### Motor information

- A: Standard motor (IP55)
- B: Phase-insulated motor for use with frequency converter
- C: IP54
- D: Pt100 in stator
- E: Angular contact bearing
- F: Motor heater
- G: Three-phase motor with overload protection
- H: Single-phase motor with no overload protection

#### Supply voltage

- A: 1 x 220 V, 60 Hz
- B: 1 x 115/230 V, 60 Hz
- C: 1 x 220-240 V, 50 Hz
- D: 1 x 127 V, 60 Hz
- E: 3 x 208-230/440-480 V, 60 Hz
- F: 3 x 220-240/380-415 V, 50 Hz
- G: 3 x 200/346 V, 50 Hz; 200-220/346-380 V, 60 Hz
- H: 3 x 575 V, 60 Hz
- I: 3 x 400 V, 50/60 Hz
- J: 3 x 380-415 V, 50 Hz; 440-480 V, 60 Hz
- K: 1 x 220-240 V, MGE motor
- L: 3 x 380-480 V, MGE motor
- M: 1 x 208-230 V, MLE motor
- N: 3 x 460-480 V, MLE motor
- O: 3 x 220-240/380-415 V, 50 Hz  
3 x 220-255/380-440 V, 60 Hz

#### Material of secondary seal

- E: EPDM (ethylene propylene)
- K: FFKM (perfluor)
- V: FKM (fluor)

#### Material of stationary shaft seal part

- B: Carbon, synthetic resin-impregnated
- Q: Silicon carbide (SIC)

#### Material of rotating seal face

- Q: Silicon carbide (SIC)
- V: Aluminium oxide (Al<sub>2</sub>O<sub>3</sub>)

#### Shaft seal type designation

- A: O-ring seal with fixed driver

#### Note

The type key cannot be used for ordering, as not all combinations are possible.

### 3. Tightening torques and lubricants

Pos.	Designation	Quantity	Dimensions	Torque [Nm]	Lubricant
2b	Screw, CM 1, 3, 5	2	M8 x 40	16-18	THREAD-EZE
	Hexagon socket head cap screw CM 10, 15, 25	2	M8 x 80	16-18	THREAD-EZE
11	O-ring	2	Ø18.5 x 2.0	-	-
25	Plug	2	-	10-12	-
26	Staybolt, CM 1, 3, 5, cast iron	4	M6	12-14	-
	Staybolt, CM 1, 3, 5, stainless steel	4	M8	12-14	-
	Staybolt, CM 10, 15, 25, cast iron	4	M8	25-27	THREAD-EZE
	Staybolt, CM 10, 15, 25, stainless steel	4	M8	20-22	-
28g	Screw	4	M6 x 14	8-10	THREAD-EZE
31	O-ring, CM 1, 3, 5	1	Ø114.0 x 3.90	-	Rocol 22
	O-ring, CM 10, 15, 25	1	Ø153.2 x 4.70	-	Rocol 22
67	Lock nut	1	M8	21-23	-
102	O-ring	1	Ø17.86 x 2.62	-	V7140084
103	Seal faces	1	-	-	Silicone oil, 350 cSt, food grade
107	O-ring	1	Ø11.5 x 3.18	-	Rocol 22
152	Screw	2	M4 x 8	2.7 - 3.3	-
		4	M5 x 12	3.5 - 4	-
155	Bearing cover plate	1	-	-	Rocol 22
157a	Gasket, MG 71, MG 80	1	Ø114.8 / 121.2 x 0.25	-	-
	Gasket, MG 90	2	Ø141.2 / 145.5	-	-
	Gasket, MG 100	-	-	-	-
158a	O-ring	1	Ø35.4 x 1.97	-	Rocol 22
159	O-ring, MG 71, MG 80	1	Ø32 x 2	-	-
	O-ring, MG 90, MG 100	1	Ø52 x 3.0	-	Rocol 22
	O-ring, MG 112, 132	1	Ø62 x 3.0	-	-
159a	Seal ring	1	-	-	Castrol LMX grease
181	Screw, MG 71, MG 80	4	M6 x 16	5-8	-
	Staybolt, MG 90	4	M5 x 220	-	-
	Staybolt, MG 90L	4	M5 x 260	-	-
	Staybolt, MG 100	4	M5 x 270	4.5 - 6	THREAD-EZE
	Staybolt, MG 112	4	M6 x 288	-	-


THREAD-EZE, product number 00SV9997 (0.5 l).

Rocol 22, product number 00RM2924 (1 kg).

Castrol LMX grease, product number 00RM4311.

Silicone oil, 350 cSt, food grade 00SV0862 (1 l).

## 4. Service tools



### 4.1 Standard tools

Pos.	Designation	For pos.	Further information	Product number
A	Screwdriver	103, 156	-	SV0803
B	Cross-head screwdriver	181	Ph2 x 100	SV0279
C	Torx screwdriver	J	TX30 x 115 mm	SV0335
D	Ring/open-end spanner	64c	15 mm	-
		67	13 mm	SV0055
E	Hexagon key	26	5 mm	-
			6 mm	SV0196
F	Puller for bearing	153, 154	-	-
G	Plastic hammer	156	-	SV0349
H	Ratchet handle	156	-	96777072
I	Hexagon head driver	26	M6 - 5 mm	SV0296
			M8 - 6 mm	SV0297
			M5 - 4 mm	-
J	Bits kit	28g, 152, 181	-	SV2010

### 4.2 Torque tools

Pos.	Designation	For pos.	Further information	Product number
K	Torque screwdriver	J	1-6 Nm	SV0438
L	Ring insert tool	N	13 mm - 9 x 12 mm	SV0294
M	Ratchet insert tool	I	9 x 12 mm - 1/2"	SV0295
N	Torque wrench	L, M	9 x 12 mm - 4-20 Nm	SV2092
			9 x 12 mm - 20-100 Nm	SV0269

## 5. Dismantling and assembly

### 5.1 General information

If it is necessary to dismantle the pump, either because it is choked or damaged, please follow the instructions in the following sections.

Position numbers of parts (digits) refer to section 7. *Drawings*; position numbers of tools (letters) refer to section 4. *Service tools*.

#### Before dismantling the pump

- Disconnect the electricity supply to the motor.
- Close the isolating valves, if fitted, to avoid draining the system.
- Remove the electric cable in accordance with local regulations.

#### Before assembly

- Clean and check all parts.
- Replace defective parts by new parts.
- Order the necessary service kits.
- Gaskets and O-rings should always be replaced when the pump is overhauled.

#### During assembly

- Lubricate and tighten screws and nuts to correct torque. See section 3. *Tightening torques and lubricants*.

### 5.2 CM 1, 3, 5, cast iron

#### 5.2.1 Dismantling


1. Remove staybolts (pos. 26).
2. Remove inlet part (pos. 6).
3. Remove gasket (pos. 139b) and chamber (pos. 4e).
4. Hold clamp (pos. 64c), and remove nut (pos. 67).
5. Remove lock washers (pos. 66) and clamp (pos. 64c).
6. Remove impeller (pos. 49).
7. Remove bearing ring (pos. 47a) and short spacing pipe (pos. 64a).

**Note** Step 7 applies only to pumps with eight stages.

8. Remove chamber for bearing (pos. 4a), gasket (pos. 139b), impeller (pos. 49) and spacing pipe (pos. 64).

**Note** Step 8 applies only to pumps with eight stages.

9. Continue the dismantling until shaft seal (pos. 105).
10. Remove shaft seal (pos. 105). See fig. 3.



**Fig. 3** Exploded view of shaft seal

Dismantling of MG 71 and MG 80, see section 5.6.1 *Dismantling*.

**Note** Dismantling of MG 90 and MG 100, see section 5.7.1 *Dismantling*.


**Note** It is advisable always to replace wear rings (pos. 45) and wear ring retainers (pos. 65). See section 5.8 *Checking and replacing impellers and chambers*.

### 5.2.2 Assembly

Assembly of MG 71 and MG 80, see section 5.6.2 *Assembly*.

**Note** Assembly of MG 90 and MG 100, see section 5.7.2 *Assembly*.

1. Fit O-ring (pos. 102) on the stationary shaft seal part. See fig. 4. For correct lubricant, see section 3. *Tightening torques and lubricants*.




**Fig. 4** Fitting the O-ring on the stationary shaft seal part

2. Press the stationary shaft seal part home. See fig. 5.



**Warning**  
Do not touch the seal face.




**Fig. 5** Fitting the stationary shaft seal part (only SiC/SiC)

3. Fit the rotating shaft seal part (pos. 104) so that the seal face touches the stationary part.



**Warning**  
Do not touch the seal face.

4. Fit O-ring (pos. 107) into the rotating shaft seal part (pos. 104). For correct lubricant, see section 3. *Tightening torques and lubricants*.
5. Fit retainer (pos. 111) and stop ring (pos. 111a). See fig. 6.



**Fig. 6** Fitting the stop ring

TM04 4322 1209


TM04 4436 1209

TM04 4327 1209

TM04 4325 1209



6. Fit spring (pos. 108) and driver (pos. 112). See fig. 7.



**Fig. 7** Fitting the spring and driver


7. Fit impeller (pos. 49), spacing pipe (pos. 64), gasket (pos. 139b) and chamber plate (pos. 4f).  
8. Continue the assembly until chamber for bearing (pos. 4a).

**Note** Step 8 applies only to pumps with eight stages.

9. Fit chamber for bearing (pos. 4a), short spacing pipe (pos. 64a), gasket (pos. 139b) and bearing ring (pos. 47a).  
See section 8. *Order of assembly for chambers and impellers.*

**Note** Step 9 applies only to pumps with eight stages.

10. Fit impeller (pos. 49), clamp (pos. 64c), washers (pos. 66) and nut (pos. 67). See fig. 8.



**Fig. 8** Correct fitting of washers

11. Hold clamp (pos. 64c), and tighten nut (pos. 67). See section 3. *Tightening torques and lubricants.*  
12. Fit chamber (pos. 4e) and gasket (pos. 139b).  
13. Fit inlet part (pos. 6).  
14. Fit and cross-tighten staybolts (pos. 26). See section 3. *Tightening torques and lubricants.*

## 5.3 CM 1, 3, 5, stainless steel

### 5.3.1 Dismantling


1. Remove staybolts (pos. 26).
2. Remove clamping flange (pos. 6a) and sleeve (pos. 16).
3. Remove chamber (pos. 4e).
4. Hold clamp (pos. 64c), and remove nut (pos. 67).
5. Remove lock washers (pos. 66) and clamp (pos. 64c).
6. Remove impeller (pos. 49).
7. Remove bearing ring (pos. 47a) and short spacing pipe (pos. 64a).

**Note** Step 7 applies only to pumps with eight or more stages.

8. Remove chamber for bearing (pos. 4a), impeller (pos. 49) and spacing pipe (pos. 64).

**Note** Step 8 applies only to pumps with eight or more stages.

9. Continue the dismantling until shaft seal (pos. 105).
10. Remove shaft seal (pos. 105). See fig. 9.



**Fig. 9** Exploded view of shaft seal

11. Remove O-ring (pos. 31) and cover plate (pos. 32).

Dismantling of MG 71 and MG 80, see section 5.6.1 *Dismantling.*

**Note** Dismantling of MG 90 and MG 100, see section 5.7.1 *Dismantling.*

It is advisable always to replace wear rings (pos. 45) and wear ring retainers (pos. 65). See section 5.8 *Checking and replacing impellers and chambers.*

**Note**

TM04 4326 1209


TM02 1057 0501

TM04 4327 1909

### 5.3.2 Assembly

**Note** Assembly of MG 71 and MG 80, see section 5.6.2 *Assembly*. Assembly of MG 90 and MG 100, see section 5.7.2 *Assembly*.

1. Fit cover plate (pos. 32) and O-ring (pos. 31). Lubricate the O-ring. See section 3. *Tightening torques and lubricants*.
2. Fit O-ring (pos. 102) on the stationary shaft seal part. See fig. 10. See section 3. *Tightening torques and lubricants*.




**Fig. 10** Fitting the O-ring on the stationary shaft seal part

3. Press the stationary shaft seal part home. See fig. 11.



**Warning**  
Do not touch the seal face.




**Fig. 11** Fitting the stationary shaft seal part (only SiC/SiC)

4. Fit the rotating shaft seal part (pos. 104) so that the seal face touches the stationary part.




**Warning**  
Do not touch the seal face.

5. Fit O-ring (pos. 107) into the rotating shaft seal part (pos. 104). See section 3. *Tightening torques and lubricants*.
6. Fit retainer (pos. 111) and stop ring (pos. 111a). See fig. 12.



**Fig. 12** Fitting the stop ring

7. Fit spring (pos. 108) and driver (pos. 112). See fig. 13.




**Fig. 13** Fitting the spring and driver

8. Fit impeller (pos. 49), chamber with holes (pos. 4d) and spacing pipe (pos. 64).
9. Fit impeller (pos. 49), chamber (pos. 4) and spacing pipe (pos. 64).
10. Fit impeller (pos. 49), chamber (pos. 4a), short spacing pipe (pos. 64a) and bearing ring (pos. 47a). See section 8. *Order of assembly for chambers and impellers*.

**Note** Step 10 applies only to pumps with eight or more stages.

11. Fit impeller (pos. 49), clamp (pos. 64c), washers (pos. 66) and nut (pos. 67). See fig. 14.




**Fig. 14** Correct fitting of washers

12. Hold clamp (pos. 64c), and tighten nut (pos. 67). See section 3. *Tightening torques and lubricants*.
13. Fit chamber (pos. 4e), sleeve (pos. 16) and clamping flange (pos. 6a).

**Caution** Do not forget to fit the last chamber (pos. 4e), as it is possible to assemble the pump without the last chamber.

14. Make sure the holes on the chamber with holes (pos. 4d) are facing the same direction as the outlet port of the sleeve (pos. 16) and the outlet port is positioned in the middle between the holes. In the case of 3 and 9 o'clock variants, this rule must be followed as well.



**Fig. 15** Correct positioning of the chamber with holes (pos. 4d) and the outlet port of the sleeve (pos. 16)

15. Fit and cross-tighten staybolts (pos. 26). See section 3. *Tightening torques and lubricants*.

TM04 4322 1909

TM04 4435 1909

TM04 4325 1909

TM04 4326 1909


TM02 1057 0501

TM07 5504 4919

## 5.4 CM 10, 15, 25, cast iron

### 5.4.1 Dismantling

1. Remove staybolts (pos. 26).
2. Remove inlet part (pos. 6) and gasket (pos. 139b).
3. Hold clamp (pos. 64c), and remove nut (pos. 67).
4. Remove lock washers (pos. 66) and clamp (pos. 64c).
5. Remove impeller (pos. 49) and spacing pipe (pos. 64).
6. Remove chamber (pos. 4).
7. Continue the dismantling until shaft seal (pos. 105).
8. Remove shaft seal (pos. 105). See fig. 16.



TM04 4327 1209

**Fig. 16** Exploded view of shaft seal

9. Loosen and remove screws (pos. 2b) and discharge part (pos. 2).

Dismantling of MG 71 and MG 80, see section 5.6.1 *Dismantling*.

**Note**

Dismantling of MG 90, MG 100, MG 112 and MG 132, see section 5.7.1 *Dismantling*.

It is advisable always to replace wear rings (pos. 45) and wear ring retainers (pos. 65).

**Note**

See section 5.8 *Checking and replacing impellers and chambers*.


### 5.4.2 Assembly

Assembly of MG 71 and MG 80, see section 5.6.2 *Assembly*.

**Note**

Assembly of MG 90, MG 100, MG 112 and MG 132, see section 5.7.2 *Assembly*.

1. Fit discharge part (pos. 2).
2. Fit and tighten screws (pos. 2b). See section 3. *Tightening torques and lubricants*
3. Fit O-ring (pos. 102) on the stationary shaft seal part. See fig. 17. See section 3. *Tightening torques and lubricants*.




**Fig. 17** Fitting the O-ring on the stationary shaft seal part

4. Press the stationary shaft seal part home. See fig. 18.



**Warning**

Do not touch the seal face.



**Fig. 18** Fitting the stationary shaft seal part (only SiC/SiC)

TM04 4322 1209


TM04 5051 2509

- Fit the rotating shaft seal part (pos. 104) so that the seal face touches the stationary part.




**Warning**  
Do not touch the seal face.

- Fit O-ring (pos. 107) into the rotating shaft seal part (pos. 104). See section 3. *Tightening torques and lubricants*
- Fit retainer (pos. 111) and stop ring (pos. 111a). See fig. 19.




**Fig. 19** Fitting the stop ring

- Fit spring (pos. 108) and driver (pos. 112). See fig. 20.



**Fig. 20** Fitting the spring and driver

- Fit short spacing pipe (pos. 64a), impeller (pos. 49), gasket (pos. 139c) and chamber (pos. 4g).
- Fit gasket (pos. 139b), spacing pipe (pos. 64), impeller (pos. 49) and chamber (pos. 4).
- Continue the assembly until clamp (pos. 64c). For correct fitting of chambers and impellers, see section 8. *Order of assembly for chambers and impellers*.
- Fit impeller (pos. 49), clamp (pos. 64c), washers (pos. 66) and nut (pos. 67). See fig. 21.



**Fig. 21** Correct fitting of washers

- Hold clamp (pos. 64c), and tighten nut (pos. 67). See section 3. *Tightening torques and lubricants*.
- Fit gasket (pos. 139b).
- Fit inlet part (pos. 6).
- Fit and cross-tighten staybolts (pos. 26). See section 3. *Tightening torques and lubricants*.


## 5.5 CM 10, 15, 25, stainless steel

### 5.5.1 Dismantling

- Remove staybolts (pos. 26).
- Remove clamping flange (pos. 6a) and sleeve (pos. 16).
- Remove the chamber plate (pos. 4f).
- Hold clamp (pos. 64c), and remove nut (pos. 67).
- Remove lock washers (pos. 66) and clamp (pos. 64c).
- Remove impeller (pos. 49).
- Remove spacing pipe (pos. 64e), bearing ring (pos. 47a) and chamber for bearing (pos. 4a).

**Note** Step 7 applies only to pumps with six or more stages.

- Continue the dismantling until shaft seal (pos. 105).
- Remove shaft seal (pos. 105). See fig. 22.



**Fig. 22** Exploded view of shaft seal

- Remove O-ring (pos. 31) and cover plate (pos. 32).

Dismantling of MG 71 and MG 80, see section 5.6.1 *Dismantling*.

**Note** Dismantling of MG 90, MG 100, MG 112 and MG 132, see section 5.7.1 *Dismantling*.

It is advisable always to replace wear rings (pos. 45) and wear ring retainers (pos. 65). See section 5.8 *Checking and replacing impellers and chambers*.

**Note**

5.5.2 Assembly

Assembly of MG 71 and MG 80, see section 5.6.2 Assembly.

**Note**

Assembly of MG 90, MG 100, MG 112 and MG 132, see section 5.7.2 Assembly.

1. Fit cover plate (pos. 32) and O-ring (pos. 31). Lubricate the O-ring. See section 3. *Tightening torques and lubricants*.
2. Fit O-ring (pos. 102) on the stationary shaft seal part. See fig. 23. For correct lubricant, see section 3. *Tightening torques and lubricants*




Fig. 23 Fitting the O-ring on the stationary shaft seal part

3. Press the stationary shaft seal part home. See fig. 24.



Warning  
Do not touch the seal face.




Fig. 24 Fitting the stationary shaft seal part (only SiC/SiC)

4. Fit the rotating shaft seal part (pos. 104) so that the seal face touches the stationary part.



Warning  
Do not touch the seal face.

5. Fit O-ring (pos. 107) into the rotating shaft seal part (pos. 104). For correct lubricant, see section 3. *Tightening torques and lubricants*
6. Fit retainer (pos. 111) and stop ring (pos. 111a). See fig. 25.




Fig. 25 Fitting the stop ring

7. Fit spring (pos. 108) and driver (pos. 112). See fig. 26.




Fig. 26 Fitting the spring and driver

8. Fit short spacing pipe (pos. 64a), chamber with holes (pos. 4d) and impeller (pos. 49).
9. Continue the assembly until clamp (pos. 64c). For correct fitting of chambers and impellers, see section 8. *Order of assembly for chambers and impellers*.
10. Fit clamp (pos. 64c), washers (pos. 66) and nut (pos. 67). See fig. 27.




Fig. 27 Correct fitting of washers

11. Hold clamp (pos. 64c), and tighten nut (pos. 67). See section 3. *Tightening torques and lubricants*.
12. Fit the chamber plate (pos. 4f).

**Caution** Do not forget to fit the chamber plate (pos. 4f), as it is possible to assemble the pump without the last chamber.

13. Fit sleeve (pos. 16) and clamping flange (pos. 6a).
14. Make sure the holes on the chamber with holes (pos. 4d) are facing the same direction as the outlet port of the sleeve (pos. 16) and the outlet port is positioned in the middle between the holes. In the case of 3 and 9 o'clock variants, this rule must be followed as well.




Fig. 28 Correct positioning of the chamber with holes (pos. 4d) and the outlet port of the sleeve (pos. 16)

15. Fit and cross-tighten staybolts (pos. 26). See section 3. *Tightening torques and lubricants*.

TM04 4326 1909

TM04 4322 1909

TM02 1057 0501

TM04 4435 1909

TM07 5503 4919

TM04 4325 1909

## 5.6 MG 71 and MG 80 motors

### 5.6.1 Dismantling

1. Remove screws (pos. 152).
2. Remove fan cover (pos. 151).
3. Remove fan (pos. 156) and seal ring (pos. 159a).
4. Remove screws (pos. 181).
5. Remove motor flange (pos. 156b) and gasket (pos. 157a).
6. Remove diverting disc (pos. 79), O-ring (pos. 158a) and bearing cover plate (pos. 155).
7. Pull shaft (pos. 51) out of stator housing (pos. 150).
8. Pull bearing (pos. 153) off shaft (pos. 51).
9. Remove O-ring (pos. 159) and spring (pos. 158).
10. Pull bearing (pos. 154) off shaft (pos. 51).

### 5.6.2 Assembly

1. Push bearing (pos. 154) onto shaft (pos. 51).
2. Fit spring (pos. 158) and O-ring (pos. 159). See fig. 29.




Fig. 29 Correct fitting of spring and O-ring

3. Push bearing (pos. 153) onto shaft (pos. 51).
4. Fit shaft (pos. 51) into stator housing (pos. 150).
5. Fit bearing cover plate (pos. 155), O-ring (pos. 158a) and diverting disc (pos. 79). Lubricate the surface of the cover plate (pos. 155) turning against the bearing. Lubricate the O-ring (pos. 158a).  
For correct lubricant, see section 3. *Tightening torques and lubricants*.
6. Fit gasket (pos. 157a) and motor flange (pos. 156b).
7. Fit and cross-tighten screws (pos. 181). See section 3. *Tightening torques and lubricants*.
8. Fit and lubricate the seal ring (pos. 159a).  
For correct lubricant, see section 3. *Tightening torques and lubricants*.
9. Fit the fan (pos. 156).
10. Fit fan cover (pos. 151).
11. Fit and tighten screws (pos. 152). See section 3. *Tightening torques and lubricants*.

TM04 4441 1209

## 5.7 MG 90, MG 100, MG 112 and MG 132 motors

### 5.7.1 Dismantling

1. Only cast iron pumps: Remove screws (pos. 2b).
2. Only cast iron pumps: Remove discharge part (pos. 2).
3. Remove screws (pos. 152).
4. Remove fan cover (pos. 151).
5. Remove fan (pos. 156) and seal ring (pos. 159a).
6. Remove staybolts (pos. 181).
7. Remove motor flange (pos. 156b), gasket (pos. 157a) and bearing cover (pos. 156a).
8. Remove diverting disc (pos. 79), O-ring (pos. 158a) and bearing cover plate (pos. 155).
9. Pull shaft (pos. 51) out of stator housing (pos. 150).
10. Pull bearing (pos. 153) off shaft (pos. 51).
11. Remove O-ring (pos. 159) and spring (pos. 158).
12. Pull bearing (pos. 154) off shaft (pos. 51).

### 5.7.2 Assembly

1. Push bearing (pos. 154) onto shaft (pos. 51).
2. Fit spring (pos. 158) and O-ring (pos. 159). See fig. 30.





Fig. 30 Correct fitting of spring and O-ring

3. Push bearing (pos. 153) onto shaft (pos. 51).
4. Fit shaft (pos. 51) into stator housing (pos. 150).
5. Fit bearing cover plate (pos. 155), O-ring (pos. 158a) and diverting disc (pos. 79). Lubricate the surface of the cover plate (pos. 155) turning against the bearing. Lubricate the O-ring (pos. 158a).  
For correct lubricant, see section 3. *Tightening torques and lubricants*.
6. Fit bearing cover (pos. 156a), gasket (pos. 157a) and motor flange (pos. 156b).
7. Fit and cross-tighten staybolts (pos. 181). See section 3. *Tightening torques and lubricants*.
8. Fit and lubricate the seal ring (pos. 159a). For correct lubricant, see section 3. *Tightening torques and lubricants*.
9. Fit the fan (pos. 156).
10. Fit fan cover (pos. 151).
11. Fit and tighten screws (pos. 152). See section 3. *Tightening torques and lubricants*.
12. Only cast iron pumps: Fit discharge part (pos. 2).
13. Only cast iron pumps: Fit and tighten screws (pos. 2b).  
See section 3. *Tightening torques and lubricants*.

TM04 4441 1209

## 5.8 Checking and replacing impellers and chambers

Check	Replace
<p style="text-align: center;"><b>Impeller</b></p> <ul style="list-style-type: none"> <li>Check whether it is necessary to replace the impeller due to friction between wear ring and impeller skirt. If wear has caused a noticeable (use a finger nail) groove in the impeller skirt, the impeller should be replaced. It is advisable always to replace wear rings (pos. 45) and wear ring retainers (pos. 65) when the chamber stack is dismantled.</li> </ul>	<p style="text-align: center;"><b>Wear ring/wear ring retainer</b></p> <ol style="list-style-type: none"> <li>Prise the wear ring retainer (pos. 65) up and free of the chamber using a screwdriver.</li> <li>Remove wear ring (pos. 45).</li> <li>Fit a new wear ring in the chamber. See fig. 31.</li> <li>Press a new wear ring retainer on the wear ring and into the chamber.</li> </ol> <p><i>It must be possible to move the wear ring freely (sideways) between the retainer and the chamber.</i></p>
<b>Bearing ring</b>	
<ul style="list-style-type: none"> <li>Check whether there is a visible and noticeable (use a finger nail) edge on the rotating bearing ring.</li> </ul>	<ul style="list-style-type: none"> <li>Replace both bearing rings (pos. 47a) and chamber for bearing (pos. 4a).</li> </ul>



**Fig. 31** Correct fitting of wear ring

TM02 1182 0601

## 6. Fault finding



### Warning

Before removing the terminal box cover, make sure that the electricity supply has been switched off.

The pumped liquid may be scalding hot and under high pressure. Before any removal or dismantling of the pump, the system must therefore be drained, or the isolating valves on either side of the pump must be closed.

Fault	Cause	Remedy
1. The pump does not run.	a) Supply failure.	Switch on the switch. Check cables and cable connections for defects and loose connections.
	b) Fuses are blown.	Check cables and cable connections for defects, and replace the fuses.
	c) Motor protection tripped.	See 2. a), b), c), d), e), f).
	d) Control-current circuit defective.	Repair or replace the control-current circuit.
2. Motor-protective circuit breaker has tripped (trips out immediately when supply is switched on).	a) Fuses are blown.	See 1. b).
	b) Contacts of the motor-protective circuit breaker or magnet coil defective.	Replace the contacts of the motor-protective circuit breaker, the magnet coil or the entire motor-protective circuit breaker.
	c) Cable connection is loose or faulty.	Check cables and cable connections for defects, and replace the fuses.
	d) Motor winding is defective.	Repair or replace the motor.
	e) The pump is mechanically blocked.	Switch off the electricity supply, and clean or repair the pump.
	f) The setting of the motor-protective circuit breaker is too low.	Set the motor-protective circuit breaker according to the rated current of the motor ( $I_{1/1}$ ). See nameplate.
3. The motor-protective circuit breaker trips out occasionally.	a) The setting of the motor-protective circuit breaker is too low.	See 2. f).
	b) Periodic supply failure.	See 2. c).
	c) Periodically low voltage.	Check cables and cable connections for defects and loose connections. Check that the supply cable of the pump is correctly sized.
4. The motor-protective circuit breaker has not tripped out, but the pump is inadvertently out of operation.	a) See 1. a), b), d) and 2. e).	
5. The pump performance is unstable.	a) Pump inlet pressure too low.	Check the inlet conditions of the pump.
	b) Inlet pipe is partly blocked by impurities.	Remove and clean the inlet pipe.
	c) Leakage in inlet pipe.	Remove and repair the inlet pipe.
	d) Air in inlet pipe or pump.	Vent the inlet pipe/pump. Check the inlet conditions of the pump.
6. The pump runs, but gives no water.	a) Pump inlet pressure too low.	See 5. a).
	b) Inlet pipe partly blocked by impurities.	See 5. b).
	c) The foot or non-return valve is stuck in its closed position.	Remove and clean, repair or replace the valve.
	d) Leakage in inlet pipe.	See 5. c).
	e) Air in inlet pipe or pump.	See 5. d).
7. The pump runs backwards when switched off.	a) Leakage in inlet pipe.	See 5. c).
	b) Foot or non-return valve defective.	See 6. c).
	c) The foot valve is stuck in completely or partly open position.	See 6. c).
8. The pump runs with reduced performance.	a) Wrong direction of rotation.	<b>Three-phase pumps only:</b> Switch off the electricity supply with the external circuit breaker and interchange two phases in the pump terminal box. It is possible to check the direction of rotation by means of the installation indicator. Black: The direction of rotation is correct. White: The direction of rotation is incorrect.
	b) See 5. a), b), c), d).	









MG(E)71/80

MG(E) 90/100/112/132




Fig. 35 CM 10, 15, 25, cast iron

## 8. Order of assembly for chambers and impellers

### 8.1 Key for CM 1, 3, 5

Bearings	
Chamber cpl.	A
Chamber with bearing cpl.	B
Chamber with holes	C
Chamber plate	D
Chamber without guide vanes	E
Impeller	F

### 8.2 CM 1, 3, 5, cast iron

CM 1, 3, 5, cast iron														
Pos.	2		3		4		5		6		7		8	
	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller
1*	D	F	D	F	D	F	D	F	D	F	D	F	D	F
2	E	F	A	F	A	F	A	F	A	F	A	F	A	F
3			E	F	A	F	A	F	A	F	A	F	A	F
4					E	F	A	F	A	F	A	F	A	F
5							E	F	A	F	A	F	A	F
6									E	F	A	F	A	F
7											E	F	B	F
8													E	F

\* Pos. 1 is next to the motor.

### 8.3 CM 1, 3, 5, stainless steel

CM 1, 3, 5, stainless steel														
Pos.	2		3		4		5		6		7		8	
	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller
1*	C	F	C	F	C	F	C	F	C	F	C	F	C	F
2	E	F	A	F	A	F	A	F	A	F	A	F	A	F
3	E		E	F	A	F	A	F	A	F	A	F	A	F
4					E	F	A	F	A	F	A	F	A	F
5							E	F	A	F	A	F	A	F
6									E	F	A	F	A	F
7									E		E	F	B	F
8													E	F
9													E	

\* Pos. 1 is next to the motor.

## CM 1, 3, 5, stainless steel

Pos.	9		10		11		12		13		14	
	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller
1*	C	F	C	F	C	F	C	F	C	F	C	F
2	A	F	A	F	A	F	A	F	A	F	A	F
3	A	F	A	F	A	F	A	F	A	F	A	F
4	A	F	A	F	A	F	A	F	A	F	A	F
5	A	F	A	F	A	F	A	F	A	F	A	F
6	A	F	A	F	A	F	A	F	A	F	A	F
7	A	F	A	F	A	F	A	F	A	F	A	F
8	B	F	A	F	A	F	A	F	A	F	A	F
9	E	F	B	F	A	F	A	F	A	F	A	F
10			E	F	B	F	A	F	A	F	A	F
11			E		E	F	B	F	B	F	B	F
12							E	F	A	F	A	F
13							E		E	F	A	F
14							E		E		E	F

\* Pos. 1 is next to the motor.

## 8.4 Key for CM 10, 15, 25

## Bearings

Chamber cpl.	A
Chamber with bearing cpl.	B
Chamber with holes	C
Impeller located in cast iron component	D
Chamber without sand lift	E
Chamber plate, SS pumps	F
Chamber without guide vanes	G
Chamber without guide vanes and sand lift	H
Impeller	I

## 8.5 CM 10, 15, 25, cast iron

## CM 10, 15, 25, cast iron

Pos.	1		2		3		4		5	
	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller
1*	D	I	D	I	D	I	D	I	D	I
2	H		E	I	E	I	E	I	E	I
3					A	I	A	I	A	I
4							A	I	A	I
5									A	I

\* Pos. 1 is next to the motor.

8.6 CM 10, 15, 25, stainless steel

CM 10, 15, 25, stainless steel										
Pos.	1		2		3		4		5	
	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller
1*	C	I	C	I	C	I	C	I	C	I
2	G		A	I	A	I	A	I	A	I
3	G		G		A	I	A	I	A	I
4	F		F		F		A	I	A	I
5							F		A	I
6									G	
7									F	

\* Pos. 1 is next to the motor.

CM 10, 15, 25, stainless steel										
Pos.	6		7		8					
	Chamber	Impeller	Chamber	Impeller	Chamber	Impeller				
1*	C	I	C	I	C	I				
2	A	I	A	I	A	I				
3	A	I	A	I	A	I				
4	A	I	A	I	A	I				
5	A	I	A	I	A	I				
6	B	I	A	I	A	I				
7	F		B	I	A	I				
8			G		B	I				
9			F		F					

\* Pos 1 is next to the motor.









**Argentina**

Bombas GRUNDFOS de Argentina S.A.  
Ruta Panamericana km. 37.500 Centro  
Industrial Garin  
1619 Garin Pcia. de B.A.  
Phone: +54-3327 414 444  
Telefax: +54-3327 45 3190

**Australia**

GRUNDFOS Pumps Pty. Ltd.  
P.O. Box 2040  
Regency Park  
South Australia 5942  
Phone: +61-8-8461-4611  
Telefax: +61-8-8340 0155

**Austria**

GRUNDFOS Pumpen Vertrieb Ges.m.b.H.  
Grundfosstraße 2  
A-5082 Grödig/Salzburg  
Tel.: +43-6246-883-0  
Telefax: +43-6246-883-30

**Belgium**

N.V. GRUNDFOS Bellux S.A.  
Boomssesteenweg 81-83  
B-2630 Aartselaar  
Tél.: +32-3-870 7300  
Télécopie: +32-3-870 7301

**Belarus**

Представительство ГРУНДФОС в  
Минске  
220125, Минск  
ул. Шафарьянская, 11, оф. 56, БЦ  
«Порт»  
Тел.: +7 (375 17) 286 39 72/73  
Факс: +7 (375 17) 286 39 71  
E-mail: minsk@grundfos.com

**Bosnia and Herzegovina**

GRUNDFOS Sarajevo  
Zmaja od Bosne 7-7A,  
BH-71000 Sarajevo  
Phone: +387 33 592 480  
Telefax: +387 33 590 465  
www.ba.grundfos.com  
e-mail: grundfos@bih.net.ba

**Brazil**

BOMBAS GRUNDFOS DO BRASIL  
Av. Humberto de Alencar Castelo Branco,  
630  
CEP 09850 - 300  
São Bernardo do Campo - SP  
Phone: +55-11 4393 5533  
Telefax: +55-11 4343 5015

**Bulgaria**

Grundfos Bulgaria EOOD  
Slatina District  
Iztochna Tangenta street no. 100  
BG - 1592 Sofia  
Tel. +359 2 49 22 200  
Fax. +359 2 49 22 201  
email: bulgaria@grundfos.bg

**Canada**

GRUNDFOS Canada Inc.  
2941 Brighton Road  
Oakville, Ontario  
L6H 6C9  
Phone: +1-905 829 9533  
Telefax: +1-905 829 9512

**China**

GRUNDFOS Pumps (Shanghai) Co. Ltd.  
10F The Hub, No. 33 Suhong Road  
Minhang District  
Shanghai 201106  
PRC  
Phone: +86 21 612 252 22  
Telefax: +86 21 612 253 33

**COLOMBIA**

GRUNDFOS Colombia S.A.S.  
Km 1.5 vía Siberia-Cota Conj. Potrero  
Chico,  
Parque Empresarial Arcos de Cota Bod.  
1A.  
Cota, Cundinamarca  
Phone: +57(1)-2913444  
Telefax: +57(1)-8764586

**Croatia**

GRUNDFOS CROATIA d.o.o.  
Buzinski prilaz 38, Buzin  
HR-10010 Zagreb  
Phone: +385 1 6595 400  
Telefax: +385 1 6595 499  
www.hr.grundfos.com

**GRUNDFOS Sales Czechia and Slovakia s.r.o.**

Čajkovského 21  
779 00 Olomouc  
Phone: +420-585-716 111

**Denmark**

GRUNDFOS DK A/S  
Martin Bachs Vej 3  
DK-8850 Bjerringbro  
Tlf.: +45-87 50 50 50  
Telefax: +45-87 50 51 51  
E-mail: info\_GDK@grundfos.com  
www.grundfos.com/DK

**Estonia**

GRUNDFOS Pumps Eesti OÜ  
Peterburi tee 92G  
11415 Tallinn  
Tel: + 372 606 1690  
Fax: + 372 606 1691

**Finland**

OY GRUNDFOS Pumput AB  
Trukkikuja 1  
FI-01360 Vantaa  
Phone: +358-(0) 207 889 500

**France**

Pompes GRUNDFOS Distribution S.A.  
Parc d'Activités de Chesnes  
57, rue de Malacombe  
F-38290 St. Quentin Fallavier (Lyon)  
Tél.: +33-4 74 82 15 15  
Télécopie: +33-4 74 94 10 51

**Germany**

GRUNDFOS GMBH  
Schlüterstr. 33  
40699 Erkrath  
Tel.: +49-(0) 211 929 69-0  
Telefax: +49-(0) 211 929 69-3799  
e-mail: infoservice@grundfos.de  
Service in Deutschland:  
e-mail: kundendienst@grundfos.de

**Greece**

GRUNDFOS Hellas A.E.B.E.  
20th km. Athinon-Markopoulou Av.  
P.O. Box 71  
GR-19002 Peania  
Phone: +0030-210-66 83 400  
Telefax: +0030-210-66 46 273

**Hong Kong**

GRUNDFOS Pumps (Hong Kong) Ltd.  
Unit 1, Ground floor  
Siu Wai Industrial Centre  
29-33 Wing Hong Street &  
68 King Lam Street, Cheung Sha Wan  
Kowloon  
Phone: +852-27861706 / 27861741  
Telefax: +852-27858664

**Hungary**

GRUNDFOS Hungária Kft.  
Tópark u. 8  
H-2045 Törökbálint,  
Phone: +36-23 511 110  
Telefax: +36-23 511 111

**India**

GRUNDFOS Pumps India Private Limited  
118 Old Mahabalipuram Road  
Thoraiakkam  
Chennai 600 096  
Phone: +91-44 2496 6800

**Indonesia**

PT. GRUNDFOS POMPA  
Graha Intirub Lt. 2 & 3  
Jln. Cililitan Besar No.454. Makasar,  
Jakarta Timur  
ID-Jakarta 13650  
Phone: +62 21-469-51900  
Telefax: +62 21-460 6910 / 460 6901

**Ireland**

GRUNDFOS (Ireland) Ltd.  
Unit A, Merrywell Business Park  
Ballymount Road Lower  
Dublin 12  
Phone: +353-1-4089 800  
Telefax: +353-1-4089 830

**Italy**

GRUNDFOS Pompe Italia S.r.l.  
Via Gran Sasso 4  
I-20060 Truccazzano (Milano)  
Tel.: +39-02-95838112  
Telefax: +39-02-95309290 / 95838461

**Japan**

GRUNDFOS Pumps K.K.  
1-2-3, Shin-Miyakoda, Kita-ku,  
Hamamatsu  
431-2103 Japan  
Phone: +81 53 428 4760  
Telefax: +81 53 428 5005

**Korea**

GRUNDFOS Pumps Korea Ltd.  
6th Floor, Aju Building 679-5  
Yeoksam-dong, Kangnam-ku, 135-916  
Seoul, Korea  
Phone: +82-2-5317 600  
Telefax: +82-2-5633 725

**Latvia**

SIA GRUNDFOS Pumps Latvia  
Deglava biznesa centrs  
Augusta Deglava ielā 60, LV-1035, Rīga,  
Tālr.: + 371 714 9640, 7 149 641  
Fakss: + 371 914 9646

**Lithuania**

GRUNDFOS Pumps UAB  
Smolensko g. 6  
LT-03201 Vilnius  
Tel: + 370 52 395 430  
Fax: + 370 52 395 431

**Malaysia**

GRUNDFOS Pumps Sdn. Bhd.  
7 Jalan Peguam U1/25  
Glenmarie Industrial Park  
40150 Shah Alam  
Selangor  
Phone: +60-3-5569 2922  
Telefax: +60-3-5569 2866

**Mexico**

Bombas GRUNDFOS de México S.A. de  
C.V.  
Boulevard TLC No. 15  
Parque Industrial Stiva Aeropuerto  
Apodaca, N.L. 66600  
Phone: +52-81-8144 4000  
Telefax: +52-81-8144 4010

**Netherlands**

GRUNDFOS Netherlands  
Veluwezoom 35  
1326 AE Almere  
Postbus 22015  
1302 CA ALMERE  
Tel.: +31-88-478 6336  
Telefax: +31-88-478 6332  
E-mail: info\_gnl@grundfos.com

**New Zealand**

GRUNDFOS Pumps NZ Ltd.  
17 Beatrice Tinsley Crescent  
North Harbour Industrial Estate  
Albany, Auckland  
Phone: +64-9-415 3240  
Telefax: +64-9-415 3250

**Norway**

GRUNDFOS Pumper A/S  
Strømsveien 344  
Postboks 235, Leirdal  
N-1011 Oslo  
Tlf.: +47-22 90 47 00  
Telefax: +47-22 32 21 50

**Poland**

GRUNDFOS Pompy Sp. z o.o.  
ul. Klonowa 23  
Baranowo k. Poznania  
PL-62-081 Przeźmierowo  
Tel: (+48-61) 650 13 00  
Fax: (+48-61) 650 13 50

**Portugal**

Bombas GRUNDFOS Portugal, S.A.  
Rua Calvet de Magalhães, 241  
Apartado 1079  
P-2770-153 Paço de Arcos  
Tel.: +351-21-440 76 00  
Telefax: +351-21-440 76 90

**Romania**

GRUNDFOS Pompe România SRL  
Bd. Biruintei, nr 103  
Pantelimon county Ilfov  
Phone: +40 21 200 4100  
Telefax: +40 21 200 4101  
E-mail: romania@grundfos.ro

**Russia**

ООО Грундфос Россия  
ул. Школьная, 39-41  
Москва, RU-109544, Russia  
Тел. (+7) 495 564-88-00 (495) 737-30-00  
Факс (+7) 495 564 8811  
E-mail grundfos.moscow@grundfos.com

**Serbia**

Grundfos Srbija d.o.o.  
Omladinskih brigada 90b  
11070 Novi Beograd  
Phone: +381 11 2258 740  
Telefax: +381 11 2281 769  
www.rs.grundfos.com

**Singapore**

GRUNDFOS (Singapore) Pte. Ltd.  
25 Jalan Tukang  
Singapore 619264  
Phone: +65-6681 9688  
Telefax: +65-6681 9689

**Slovakia**

GRUNDFOS s.r.o.  
Prievozská 4D  
821 09 BRATISLAVA  
Phona: +421 2 5020 1426  
sk.grundfos.com

**Slovenia**

GRUNDFOS LJUBLJANA, d.o.o.  
Leskoškova 9e, 1122 Ljubljana  
Phone: +386 (0) 1 568 06 10  
Telefax: +386 (0) 1 568 06 19  
E-mail: tehnika-si@grundfos.com

**South Africa**

Grundfos (PTY) Ltd.  
16 Lascelles Drive, Meadowbrook Estate  
1609 Germiston, Johannesburg  
Tel.: (+27) 10 248 6000  
Fax: (+27) 10 248 6002  
E-mail: lgradidge@grundfos.com

**Spain**

Bombas GRUNDFOS España S.A.  
Camino de la Fuentequilla, s/n  
E-28110 Algiete (Madrid)  
Tel.: +34-91-848 8800  
Telefax: +34-91-628 0465

**Sweden**

GRUNDFOS AB  
Box 333 (Lunnagårdsgatan 6)  
431 24 Mölndal  
Tel.: +46 31 332 23 000  
Telefax: +46 31 331 94 60

**Switzerland**

GRUNDFOS Pumpen AG  
Bruggacherstrasse 10  
CH-8117 Fällanden/ZH  
Tel.: +41-44-806 8111  
Telefax: +41-44-806 8115

**Taiwan**

GRUNDFOS Pumps (Taiwan) Ltd.  
7 Floor, 219 Min-Chuan Road  
Taichung, Taiwan, R.O.C.  
Phone: +886-4-2305 0868  
Telefax: +886-4-2305 0878

**Thailand**

GRUNDFOS (Thailand) Ltd.  
92 Chaloe Phrakiat Rama 9 Road,  
Dokmai, Pravej, Bangkok 10250  
Phone: +66-2-725 8999  
Telefax: +66-2-725 8998

**Turkey**

GRUNDFOS POMPA San. ve Tic. Ltd. Sti.  
Gebze Organize Sanayi Bölgesi  
Ihsan dede Caddesi,  
2. yol 200. Sokak No. 204  
41490 Gebze/ Kocaeli  
Phone: +90 - 262-679 7979  
Telefax: +90 - 262-679 7905  
E-mail: satis@grundfos.com

**Ukraine**

Бізнес Центр Європа  
Столицне шосе, 103  
м. Київ, 03131, Україна  
Телефон: (+38 044) 237 04 00  
Факс.: (+38 044) 237 04 01  
E-mail: ukraine@grundfos.com

**United Arab Emirates**

GRUNDFOS Gulf Distribution  
P.O. Box 16768  
Jebel Ali Free Zone  
Dubai  
Phone: +971 4 8815 166  
Telefax: +971 4 8815 136

**United Kingdom**

GRUNDFOS Pumps Ltd.  
Grovebury Road  
Leighton Buzzard/Beds. LU7 4TL  
Phone: +44-1525-850000  
Telefax: +44-1525-850011

**U.S.A.**

GRUNDFOS Pumps Corporation  
9300 Loiret Blvd.  
Lenexa, Kansas 66219  
Phone: +1-913-227-3400  
Telefax: +1-913-227-3500

**Uzbekistan**

Grundfos Tashkent, Uzbekistan The Repre-  
sentative Office of Grundfos Kazakhstan in  
Uzbekistan  
38a, Oybek street, Tashkent  
Телефон: (+998) 71 150 3290 / 71 150  
3291  
Факс: (+998) 71 150 3292

Addresses Revised 15.01.2019

<b>99698874</b> 0120
----------------------

ECM: 1276534
--------------

Trademarks displayed in this material, including but not limited to Grundfos, the Grundfos logo and "be think innovate" are registered trademarks owned by The Grundfos Group. All rights reserved. © 2020 Grundfos Holding A/S. All rights reserved.