

# CR, CRI, CRN

Installation and operating instructions



be  
think  
innovate

GRUNDFOS X

# English (GB) Installation and operating instructions

## Original installation and operating instructions

These installation and operating instructions describe Grundfos CR, CRI and CRN pumps, 0.37 - 75 kW.

Sections 1-4 give the information necessary to be able to unpack, install and start up the product in a safe way.

Sections 5-10 give important information about the product, as well as information on service, fault finding and disposal of the product.

## CONTENTS

	Page
<b>1. General information</b>	<b>2</b>
1.1 Hazard statements	2
1.2 Notes	2
<b>2. Receiving the product</b>	<b>3</b>
2.1 Transporting the product	3
2.2 Unpacking the product	3
2.3 Inspecting the product	3
2.4 Lifting the product	3
<b>3. Installing the product</b>	<b>4</b>
3.1 Mechanical installation	4
3.2 Electrical connection	10
<b>4. Starting up the product</b>	<b>13</b>
4.1 Shaft seal run-in	13
4.2 Frequency of starts and stops	14
4.3 Operating the product	14
<b>5. Product introduction</b>	<b>15</b>
5.1 Identification	15
5.2 Intended use of the product	16
<b>6. Servicing the product</b>	<b>16</b>
6.1 Contaminated products	17
6.2 Service documentation	17
6.3 Maintaining the product	17
<b>7. Taking the product out of operation</b>	<b>19</b>
7.1 Frost protection	19
7.2 Taking the product permanently out of operation	19
<b>8. Fault finding the product</b>	<b>20</b>
<b>9. Technical data</b>	<b>22</b>
9.1 Operating conditions	22
9.2 Electrical data	24
9.3 Dimensions and weights	24
<b>10. Disposing of the product</b>	<b>24</b>



Read this document before installing the product. Installation and operation must comply with local regulations and accepted codes of good practice.

## 1. General information

### 1.1 Hazard statements

The symbols and hazard statements below may appear in Grundfos installation and operating instructions, safety instructions and service instructions.

#### DANGER



Indicates a hazardous situation which, if not avoided, will result in death or serious personal injury.

#### WARNING



Indicates a hazardous situation which, if not avoided, could result in death or serious personal injury.

#### CAUTION



Indicates a hazardous situation which, if not avoided, could result in minor or moderate personal injury.

The hazard statements are structured in the following way:

#### SIGNAL WORD



##### Description of hazard

Consequence of ignoring the warning.  
- Action to avoid the hazard.

### 1.2 Notes

The symbols and notes below may appear in Grundfos installation and operating instructions, safety instructions and service instructions.



Observe these instructions for explosion-proof products.



A blue or grey circle with a white graphical symbol indicates that an action must be taken.



A red or grey circle with a diagonal bar, possibly with a black graphical symbol, indicates that an action must not be taken or must be stopped.



If these instructions are not observed, it may result in malfunction or damage to the equipment.



Tips and advice that make the work easier.

## 2. Receiving the product

### 2.1 Transporting the product

#### WARNING

##### Falling objects



Death or serious personal injury

- Keep the product in a stable and fixed position during transportation.
- Wear personal protective equipment.

### 2.2 Unpacking the product

#### WARNING

##### Falling objects



Death or serious personal injury

- Keep the product in a stable position during unpacking.
- Wear personal protective equipment.

### 2.3 Inspecting the product

Before you install the product, do the following:

1. Check that the product is as ordered.
2. Check that no visible parts have been damaged.

If parts are damaged or missing, contact your local Grundfos sales company.

### 2.4 Lifting the product

#### WARNING

##### Falling objects



Death or serious personal injury

- Follow the lifting instructions.
- Use lifting equipment which is approved for the weight of the product.
- Persons must keep a safe distance to the product during lifting operations.
- Wear personal protective equipment.




Note that typically the centre of gravity of the pump is close to the motor.


When lifting the entire product with motor, follow these instructions:

- Pumps with 0.37 - 5.5 kW motors, all types:  
Lift the pump by straps or similar lifting equipment in the motor flange.
- Pumps with 7.5 - 22 kW motors, Grundfos MG and MGE:  
Lift the pump by the motor eyebolts.
- Pumps with 7.5 - 45 kW motors, other types than Grundfos MG and MGE:  
Lift the pump by the lifting brackets on the motor flange.

0.37 - 5.5 kW




7.5 - 22 kW



TM04 0339 0608

7.5 - 45 kW\*



TM05 9564 4113

**Fig. 1** Lifting points

- \* In case of pumps with other motors than Grundfos MG and MGE.

### 3. Installing the product

#### 3.1 Mechanical installation

##### **WARNING**

###### **Contamination when pumping drinking water**

Death or serious personal injury

- Before the pump is used for supplying drinking water, flush the pump thoroughly with clean water.
- Do not use the pump for drinking water if the internal parts have been in contact with particles or substances not suitable for water intended for human consumption.



The pump must be installed according to national water regulations and standards.



##### 3.1.1 Lifting the product

##### **WARNING**

###### **Falling objects**

Death or serious personal injury

- Follow the lifting instructions.
- Use lifting equipment which is approved for the weight of the product.
- Persons must keep a safe distance to the product during lifting operations.
- Wear personal protective equipment.

For lifting instructions, see section [2.4 Lifting the product](#).

#### 3.1.2 Drive-end motor bearing

Make sure to use the correct type of drive-end (DE) motor bearing for the bare-shaft pump. Please check the specific pump range and pump version stated on the nameplate and select the corresponding DE bearing.








Pump version <sup>1)</sup>	DE bearing CR 1-64 pump range		DE bearing CR 95-255 pump range	
	Deep-groove ball bearing (62/63xx)	Angular contact bearing (73xx)	Deep-groove ball bearing (62/63xx)	Angular contact bearing (73xx)
A Standard pump	0.37 - 3 kW	4-45 kW	75-200 kW	5.5 - 55 kW
T Pump with thrust handling device (THD) <sup>2)</sup>	-	-	5.5 - 55 kW	Not allowed
Z Pump with bearing flange <sup>2)</sup>	0.37 - 45 kW	Not allowed	5.5 - 200 kW	Not allowed

1) Refer to the codes for pump version in section [5.1.2 Type key for CR, CRN 32, 45 and 64](#).

2) Factory product variants (FPV).

### 3.1.3 Installation guidelines

The pump must be secured to a horizontal, plane and solid foundation with bolts through the holes in the base plate. When installing the pump, be aware of the information below in order to avoid damaging the pump.

Illustration	Information
1	 <p>TM02 0013 3800</p> <p>Arrows on the pump base show the direction of flow of liquid through the pump.</p>
2	 <p>TM00 2256 3393</p> <p>This information is stated in fig. 3 in the appendix:</p> <ul style="list-style-type: none"> <li>port-to-port lengths</li> <li>dimensions of the base plate</li> <li>pipe connections</li> <li>diameter and position of anchor bolts.</li> </ul>
3	 <p>TM01 1241 4097</p> <p>You can install the pump vertically or horizontally. However, the motor must neither fall below the horizontal plane nor be installed upside down.</p> <p>Make sure that an adequate supply of cool air reaches the motor cooling fan.</p> <p>Motors above 4 kW must be supported.</p>
3a	 <p>TM05 7705 1013</p> <p>Additional support. As the centre of gravity of the pump is relatively high, we recommend that pumps installed on ships, in areas with risk of earth quake or in systems which can be moved, are equipped with an additional support bracket. You can fit the bracket from the motor stool to the bulkhead of the ship, a rigid wall in a building or to a rigid part.</p>
4	 <p>TM02 0116 3800</p> <p>To minimise possible noise from the pump, we recommend that you fit expansion joints on either side of the pump.</p> <p>Build a foundation and carry out mechanical installation as described in section <b>3.1.4 Foundation</b>. Fit the isolating valves on either side of the pump to avoid draining the system if the pump needs to be removed for cleaning, repair or replacement.</p> <p>Always protect the pump against backflow by means of a non-return valve.</p>
5	 <p>TM02 0114 3800</p> <p>Install the pipes so that air pockets do not occur, especially on the inlet side of the pump.</p>
6	 <p>TM02 0115 3800</p> <p>Fit a vacuum valve close to the pump if the installation has one of these characteristics:</p> <ul style="list-style-type: none"> <li>The outlet pipe slopes downwards away from the pump.</li> <li>There is a risk of siphon effect.</li> <li>Protection against backflow of unclean liquids is needed.</li> </ul>

### 3.1.4 Foundation

#### WARNING

##### Falling objects


Death or serious personal injury

- Keep the product in a stable and fixed position before installing it.
- Make sure that the foundation is suitable for the weight of the product.

We recommend that you install the pump on a concrete foundation which is heavy enough to provide permanent and rigid support for the entire pump. The foundation must be capable of absorbing any vibration, normal strain or shock. The concrete foundation must have an absolutely level and even surface.

Place the pump on the foundation, and fasten it. The base plate must be supported on the whole area.

The following instruction applies when mounting the pump in both vertical and horizontal position. Place the pump on the foundation, and fasten it. See fig. 2.




**Fig. 2** Correct installation

TM04 0342 0608


The recommended length and width of the foundation are shown in fig. 3. Note that for pumps with motor size below or equal to 30 kW, the length and width of the foundation must be 200 mm larger than the base plate.

For pumps with motor size equal to 37 kW or above, the length and width must always be 1.5 x 1.5 (Lf x Bf) m.




**Fig. 3** Foundation, vertical mounting

TM04 0343 0608



The foundation length and width must always be 200 mm larger than the length and width of the pump. See fig. 4.



**Fig. 4** Foundation, horizontal mounting


The mass of the foundation must be at least 1.5 times the total mass of the pump. The minimum height of the foundation ( $h_f$ ) can then be calculated:

$$h_f = \frac{M_{\text{pump}} \times 1.5}{L_f \times B_f \times \delta_{\text{concrete}}}$$

The density ( $\delta$ ) of concrete is usually taken as 2200 kg/m<sup>3</sup>.


In installations where noise-less operation is particularly important, we recommend that you use a foundation with a mass up to 5 times that of the pump.

The foundation must be provided with anchor bolts for fixing the base plate. See fig. 5.



**Fig. 5** Bolt in foundation

When the anchor bolts are in position, place the pump on the foundation. Then align the base plate using shims, if necessary, so that it is completely horizontal. See fig. 6.




**Fig. 6** Alignment with shims

### 3.1.5 Vibration dampening


Elimination of noise and vibrations is best achieved by means of a concrete foundation, vibration dampers and expansion joints.

If you use vibration dampers, install them under the foundation. For pumps with motor size below or equal to 30 kW, you can use vibration dampers as shown in fig. 7.

For pumps with motor sizes equal to 37 kW or above, use a Sylomer® plate as shown in fig. 8.



**Fig. 7** Pump on vibration dampers



**Fig. 8** Pump on Sylomer® plate

### 3.1.6 Outdoor installation

When the pump is installed outdoors, we recommend that you provide the motor with a rain cover. We also recommend that you open one of the drain holes in the motor flange.

### 3.1.7 Tightening torques

#### WARNING

##### Flange gasket blowout



Death or serious personal injury

- Tighten flange bolts according to the torque values stated in the installation and operating instructions.


The table shows the recommended torques for base plate anchor bolts and flange bolts.

The bolt quality must be minimum class 8.8.

CR, CRI, CRN	Base [Nm]	Flange bolts [Nm]		
		Bolt size	DIN, JIS, ANSI	Oval
1s-5	40	M10	-	50-60
		M12	60	-
10-20	50	M12	60	60-70
		M16	100	70-80
32-64	70	M20	150	-
		M24	200	-

### 3.1.8 Flange forces and torques

If not all loads reach the maximum permissible value stated in the tables below, one of these values may exceed the normal limit. Contact Grundfos for further information.



TM04 0346 2013

**Fig. 9** Flange forces and torques

Y-direction: Inlet or outlet

Z-direction: Direction of chamber stack

X-direction: 90 ° from inlet or outlet

The following tables represent the values that apply according to the material quality.

**Force limits**

Flange, DN [mm]	Type	CR - Cast iron pump housing			CRI, CRN - Stainless steel pump housing		
		Force, Y- direction [N]	Force, Z- direction [N]	Force, X- direction [N]	Force, Y- direction [N]	Force, Z- direction [N]	Force, X- direction [N]
25/32	1s-5	338	394	319	675	788	638
40	10	413	469	375	825	938	750
50	15 and 20	563	581	506	1125	1163	1013
65	32	694	788	638	1388	1575	1275
80	45	938	769	844	1875	1538	1688
100	64	1256	1013	1125	2513	2025	2250

**Torque limits**

Flange, DN [mm]	Type	CR - Cast iron pump housing			CRI, CRN - Stainless steel pump housing		
		Torque, Y- direction [Nm]	Torque, Z- direction [Nm]	Torque, X- direction [Nm]	Torque, Y- direction [Nm]	Torque, Z- direction [Nm]	Torque, X- direction [Nm]
25/32	1s-5	300	175	125	600	350	250
40	10	400	275	200	800	550	400
50	15 and 20	450	325	250	900	650	500
65	32	500	350	300	1000	700	600
80	45	325	400	550	650	800	1100
100	64	375	475	625	750	950	1250

**3.1.9 Positioning the terminal box**

You can turn the terminal box to four positions, in 90 ° steps. Follow this procedure:

1. If necessary, remove the coupling guards. Do not remove the coupling.
2. Remove the bolts securing the motor to the pump.
3. Turn the motor to the required position.
4. Replace and tighten the bolts.
5. Replace the coupling guards.

Carry out the electrical connection as shown in the diagram inside the terminal box cover.

## 3.2 Electrical connection



Follow the instructions for the motor when carrying out the electrical connections.

The electrical connection must be carried out by an authorised electrician in accordance with local regulations.

### WARNING

#### Electric shock

Death or serious personal injury

- Before starting any work on the product, make sure that the power supply has been switched off and that it cannot be accidentally switched on.
- Connect the pump to an external main switch close to the pump and to a motor-protective circuit breaker or a CUE frequency converter. Make sure you can lock the main switch in OFF position (isolated). Type and requirements as specified in EN 60204-1, 5.3.2.



### WARNING

#### Electric shock

Death or serious personal injury

- The motor must be protected against overload by means of an external motor-protective circuit breaker with IEC trip class 10 or 20.
- Grundfos recommends trip class 20.
- The current setting of the motor-protective circuit breaker must be adjusted to the nominal current stated on the motor nameplate.



### WARNING

#### Electric shock

Death or serious personal injury

- Connect the pump to the same protective-earth (PE) potential as the motor if both motor bearings are of the insulated type, such as ceramic bearings.



Consider whether it is necessary to install an emergency stop switch.

The operating voltage and frequency are marked on the motor nameplate. Make sure that the motor is suitable for the power supply on which it is used and that the motor terminal connection is correct. You will find a wiring diagram in the terminal box.

### 3.2.1 Maximum absorbed current



Some motors can absorb a maximum current which is larger than the full load current  $I_{1/1}$  stated on the nameplate. See the table below.

Motor type according to the nameplate	Upper limit for absorbed current
• Motors marked with both of the below: – full load current $I_{1/1}$ – maximum current $I_{max}$	$I_{max}$
• Grundfos MMG-G motors • Grundfos MMG-E motors	$1.05 \times I_{1/1}$
• Motors marked only with the below: – full load current $I_{1/1}$	$I_{1/1}$

### 3.2.2 Cable entry/screwed connection

All motors are supplied without screwed cable entries. The table below shows the numbers and sizes of cable entry holes of the terminal box according to the standard EN 50262.

Motor [kW]	Number and size of cable entries	Description
0.25 - 0.55	2 x M20 x 1.5	The holes have precast threads and are closed with knock-out cable entries.
0.75 - 3.0	2 x M20	The holes are closed with knock-out cable entries.
4.0 - 7.5	4 x M25	The holes are closed with knock-out cable entries.
11-22	2 x M20 4 x M40	The holes are closed with knock-out cable entries.
30-45	2 x M50 x 1.5	Blanking plug.
55-75	2 x M63 x 1.5	Blanking plug.

### 3.2.3 Three-phase connection

Mains supply [V]		
	Delta connection	Star connection
<b>50 Hz</b>	220-240	/ 380-415
	380-415	/ 660-690
<b>60 Hz</b>	220-277	/ 380-480 <sup>1)</sup>
	380-480	/ 660-690

<sup>1)</sup> 60 Hz motors, 0.37 - 1.1 kW: 220-277/380-440 V.




Fig. 10 Delta connection




Fig. 11 Star connection

If the motor is provided with PTC sensors or PTO contacts, the connection must be in accordance with the wiring diagram in the terminal box.

Connect three-phase motors to a motor-protective circuit breaker.

### 3.2.4 Single-phase connection




Fig. 12 Connection, 220-230 V, 0.37 - 0.75 kW




Fig. 13 Connection, 240 V, 0.37 - 0.75 kW




Fig. 14 Connection, 220-230 V, 1.1 - 2.2 kW




Fig. 15 Connection, 240 V, 1.1 - 2.2 kW

Single-phase Grundfos motors incorporate a thermal switch and require no additional motor protection.

### 3.2.5 Frequency converter operation

You can use three-phase motors for frequency converter operation following the conditions below. This section applies to motors defined in IEC 60034.

### 3.2.6 General conditions

Protect all motors used with frequency converters against voltage peaks and dU/dt according to IEC 60034-17. Grundfos recommends that you use insulated bearings for motors from frame size 225 (45 kW/2-pole, 30 kW/4-pole and 22 kW/6-pole).

### 3.2.7 Mains voltage dependent conditions

#### 200-240 V

No output filters are required for frequency converter operated motors with mains voltages up to 240 V.

#### 380-500 V

For frequency converter operated motors with power cable length less than 25 m and mains supply up to 460 V, no additional motor protection against voltage peaks is required. For frequency converter operated motors with power cable length of more than 25 m or mains supply higher than 460 V, sine-wave filters are required.

#### 500 V and higher

Always use sine-wave filters for motors marked with 500 V or higher voltages.



Motors with reinforced insulation can be supplied as an option. These motors are according to IEC 60034-25 and therefore there is no need for sine-wave filters. This do not eliminate the requirement for insulated bearings from frame size 225.

#### Exception

- Protect Grundfos motors types MG 71 and MG 80 (up to 1.1 kW/2-pole and up to 0.75 kW/4-pole) for supply voltages up to and including 440 V without phase insulation against voltage peaks above 650 V between the supply terminals.
- If you use MG 71 and MG 80 without phase insulation for input voltages above 240 V, it requires that you use sine-wave filters at the output of the frequency converter.

MG 71 and MG 80 with phase insulation for use with variable frequency drives are available as standard products.

#### Motors supplied by Grundfos

You can connect all three-phase MG motors with phase insulation to a frequency converter.

#### Other motor makes than those supplied by Grundfos

Contact Grundfos or the motor manufacturer.

### 3.2.8 Phase insulation, MG 71 and 80

MG motors, frame sizes 71 and 80, do not have phase insulation as standard. The motors are not suitable for frequency converter operation as they are not protected against the voltage peaks caused by the frequency converter operation. Only motors with a rated voltage equal to 460 V or above have phase insulation.



Frequency converter operation of MG motors without phase insulation will cause damage to the motor.

We recommend that you protect all other motors against voltage peaks higher than 1200 V by 2000 V/ $\mu$ sec.

You can eliminate the above disturbances, that is both increased acoustic noise and detrimental voltage peaks, by fitting an LC filter between the frequency converter and the motor.

For further information, contact the frequency converter or motor supplier.

## 4. Starting up the product

### **WARNING**

#### **Corrosive liquids**

Death or serious personal injury

- Wear personal protective equipment.



### **WARNING**

#### **Toxic liquids**

Death or serious personal injury

- Wear personal protective equipment.



### **CAUTION**

#### **Hot or cold liquid**

Minor or moderate personal injury

- Wear personal protective equipment.
- Pay attention to the direction of the vent hole when you fill the pump with liquid and vent it.
- Make sure that no persons are hurt by the escaping liquid.




Fill the pump with liquid and vent it before you start the pump.



Pay attention to the direction of the vent hole during liquid filling and venting. Make sure that the escaping liquid does not cause damage to the motor or other components.



If the pump runs dry, the pump bearings and the shaft seal may be damaged.



TM05 1160 0611 - TM05 8098 1913

**Fig. 16** Vent valve, standard and an optional solution with hose connection

Follow the startup instructions in the appendix.

### **CR, CRI, CRN 1s to 5**

For these pumps, we recommend that you open the bypass valve during startup. See fig. 18 for bypass valve location. The bypass valve connects the inlet and outlet sides of the pump, thus making the filling procedure easier. Close the bypass valve again when the operation is stable.

When pumping liquids containing air, we recommend that you leave the bypass valve open if the operating pressure is lower than 6 bar.

Close the bypass valve if the operating pressure constantly exceeds 6 bar. Otherwise, the material at the opening will be worn because of the high liquid velocity.

## 4.1 Shaft seal run-in

### **WARNING**

#### **Corrosive liquids**

Death or serious personal injury

- Wear personal protective equipment.



### **WARNING**

#### **Toxic liquids**

Death or serious personal injury

- Wear personal protective equipment.



### **CAUTION**

#### **Hot or cold liquid**

Minor or moderate personal injury

- Wear personal protective equipment.



### **!**

Make sure that a leakage does not cause damage to the equipment.

The seal faces are lubricated by the pumped liquid, meaning that there may be a certain amount of leakage from the shaft seal.

When you start the pump for the first time, or when you install a new shaft seal, a certain run-in period is required before the leakage is reduced to an acceptable level. The time required for this depends on the operating conditions, that is every time the operating conditions change, a new run-in period will be started.

Under normal conditions, the leaking liquid will evaporate. As a result, no leakage will be detected.

## 4.2 Frequency of starts and stops

Motor size [kW]	Maximum number of starts per hour
0.37 - 2.2	250
3-4	100
5.5 - 11	50
18.5 - 22	40
30	90
37	50
45	80
55	50
75	50

## 4.3 Operating the product

For operating the product safely, observe the following hazard statements:

### WARNING

#### Contamination when pumping drinking water

Death or serious personal injury

- Do not use the pump for drinking water if the internal parts have been in contact with particles or substances not suitable for water intended for human consumption.



### WARNING

#### Airborne noise

Death or serious personal injury

- Wear personal protective equipment.



See fig. 4 in the appendix.

### WARNING

#### Too high pressure and leakage

Death or serious personal injury

- Do not run the pump against a closed outlet valve.



### CAUTION

#### Hot or cold surface

Minor or moderate personal injury

- Make sure that no one can accidentally come into contact with hot or cold surfaces.

#### Hot or cold surfaces



### CAUTION


#### Hot or cold liquid

Minor or moderate personal injury

- Wear personal protective equipment.



Figure 17 shows which pump parts get as hot or cold as the pumped liquid.



**Fig. 17** Hot or cold surfaces on a CR, CRI and CRN pump

For motor bearing maintenance at ambient temperatures above 40 °C, see section 10. *Disposing of the product*.

## 5. Product introduction

### 5.1 Identification

#### 5.1.1 Type key for CR, CRI, CRN 1s, 1, 3, 5, 10, 15 and 20

Example	CR	3-	10	X-	X-	X-	X-	XXXX
Type range: CR, CRI, CRN								
Rated flow rate in m <sup>3</sup> /h								
Number of impellers								
Code for pump version								
Code for pipe connection								
Code for materials								
Code for rubber pump parts								
Code for shaft seal								

#### 5.1.2 Type key for CR, CRN 32, 45 and 64

Example	CR	32-	2	1-	X-	X-	X-	XXXX
Type range: CR, CRN								
Rated flow rate in m <sup>3</sup> /h								
Number of stages								
Number of impellers with reduced diameter								
Code for pump version								
Code for pipe connection								
Code for materials								
Code for rubber pump parts								
Code for shaft seal								

## 5.2 Intended use of the product

Only use the CR, CRI and CRN pumps according to the specification stated in these installation and operating instructions.

### 5.2.1 Applications

Grundfos multistage in-line centrifugal pumps, types CR, CRI and CRN, are designed for a wide range of applications.

#### CR, CRI, CRN

CR, CRI and CRN pumps are suitable for liquid transfer, circulation and pressure boosting of cold or hot clean liquids.

#### CRN

Use CRN pumps in systems where all parts in contact with the liquid are made of high-grade stainless steel.

### 5.2.2 Pumped liquids

#### DANGER

##### Fire and explosion

Death or serious personal injury

- Do not use the pump for flammable, combustible or explosive liquids.

#### WARNING

##### Chemical attack and leakage

Death or serious personal injury

- Do not use the pump for liquids which can attack the pump materials chemically.
- Contact Grundfos if in doubt.

#### WARNING

##### Corrosive liquids

Death or serious personal injury

- Wear personal protective equipment.

#### WARNING

##### Toxic liquids

Death or serious personal injury

- Wear personal protective equipment.

#### CAUTION

##### Hot or cold liquid

Minor or moderate personal injury

- Wear personal protective equipment.

CR, CRI and CRN pump are suitable for pumping thin, clean, non-flammable, non-combustible or non-explosive liquids, not containing solid particles or fibres.

When pumping liquids with a density and/or viscosity higher than that of water, use motors with correspondingly higher outputs, if required.

## 6. Servicing the product

#### DANGER

##### Electric shock

Death or serious personal injury

- Before starting any work on the product, make sure that the power supply has been switched off and that it cannot be accidentally switched on.

#### WARNING

##### Electric shock

Death or serious personal injury

- Connect the pump to the same protective-earth (PE) potential as the motor if both motor bearings are of the insulated type, such as ceramic bearings.

#### WARNING

##### Falling objects

Death or serious personal injury

- Follow the lifting instructions.
- Use lifting equipment which is approved for the weight of the product.
- Persons must keep a safe distance to the product during lifting operations.
- Wear personal protective equipment.

For lifting instructions, see section [2.4 Lifting the product](#).

#### WARNING

##### Falling objects

Death or serious personal injury

- Keep the product in a stable and fixed position when working on it.

#### WARNING

##### Corrosive liquids

Death or serious personal injury

- Wear personal protective equipment.

#### WARNING

##### Toxic liquids

Death or serious personal injury

- Wear personal protective equipment.

## WARNING

### Contamination when pumping drinking water

Death or serious personal injury

- Before the pump is used for supplying drinking water, flush the pump thoroughly with clean water.
- Do not use the pump for drinking water if the internal parts have been in contact with particles or substances not suitable for water intended for human consumption.
- Always use original spare parts suitable for drinking water.



## CAUTION

### Hot or cold liquid

Minor or moderate personal injury

- Wear personal protective equipment.



## CAUTION

### Hot or cold surface

Minor or moderate personal injury

- Make sure that no one can accidentally come into contact with hot or cold surfaces.



We recommend that you repair pumps with motors of 7.5 kW and above at the installation site. Necessary lifting equipment must be available.

## 6.1 Contaminated products

## CAUTION

### Biological hazard

Minor or moderate personal injury



- Flush the product thoroughly with water and rinse the product parts in water after dismantling.

The product will be classified as contaminated if it has been used for a liquid which is injurious to health or toxic.

If you request Grundfos to service the product, contact Grundfos with details about the liquid before returning the product for service. Otherwise, Grundfos can refuse to accept the product for service.

Any application for service must include details about the liquid.

Clean the product in the best possible way before you return it.

Costs of returning the product are to be paid by the customer.

## 6.2 Service documentation

### 6.2.1 Pump

Service documents and service kits are available in Grundfos Product Center (<http://product-selection.grundfos.com/>).

### 6.2.2 Motor

#### Grundfos motors

Service documentation is available in Grundfos Product Center (<http://product-selection.grundfos.com/>).

If you have any questions, please contact the nearest Grundfos company or service workshop.

#### Other motors makes than MG

Contact the motor manufacturer.

## 6.3 Maintaining the product

## DANGER

### Electric shock

Death or serious personal injury

- Before starting any work on the product, make sure that the power supply has been switched off and that it cannot be accidentally switched on.

## WARNING

### Falling objects

Death or serious personal injury

- Follow the lifting instructions.
- Use lifting equipment which is approved for the weight of the product.
- Persons must keep a safe distance to the product during lifting operations.
- Wear personal protective equipment.



For lifting instructions, see section [2.4 Lifting the product](#).

## **WARNING**



### **Falling objects**

Death or serious personal injury  
- Keep the product in a stable and fixed position when working on it.

## **WARNING**



### **Corrosive liquids**

Death or serious personal injury  
- Wear personal protective equipment.

## **WARNING**



### **Toxic liquids**

Death or serious personal injury  
- Wear personal protective equipment.



## **CAUTION**

### **Hot or cold liquid**

Minor or moderate personal injury  
- Wear personal protective equipment.



## **CAUTION**



### **Hot or cold surface**

Minor or moderate personal injury  
- Make sure that no one can accidentally come into contact with hot or cold surfaces.

## **6.3.1 Pump**

The pump bearings and the shaft seal are maintenance-free.

## **6.3.2 Motor**

Carry out maintenance as described in the instructions for the motor which are supplied with the pump.

### **Motor bearings**

Motors not fitted with grease nipples are maintenance-free.

Motors fitted with grease nipples must be lubricated with a high-temperature, lithium-based grease. See the instructions on the fan cover.

In the case of seasonal operation where the motor is idle for more than 6 months of the year, we recommend that you grease the motor when you take the pump out of operation.

Depending on the ambient temperature, replace or lubricate the motor bearings according to the table below. The table applies to 2-pole motors. The number of operating hours stated for bearing replacement are guidelines only.

Motor size [kW]	Bearing replacement interval [operating hours]				
	40 °C	45 °C	50 °C	55 °C	60 °C
0.37 - 0.75	18000	-	-	-	-
1.1 - 7.5	20000	15500	12500	10000	7500
Motor size [kW]	Lubrication interval [operating hours]				
	40 °C	45 °C	50 °C	55 °C	60 °C
11 - 18.5	4500	3400	2500	1700	1100
22	4000	3100	2300	1500	1000
30-55	4000	3000	2000	1500	-
75	2000	1500	1000	500	-

Intervals for 4-pole motors are twice as long as those for 2-pole motors.

If the ambient temperature is lower than 40 °C, then replace or lubricate the bearings at the intervals mentioned under 40 °C.

## 7. Taking the product out of operation

### 7.1 Frost protection

#### CAUTION



##### Hot or cold liquid

- Minor or moderate personal injury
- Pay attention to the direction of the vent hole and drain plug when draining the pump. Make sure that the escaping liquid does not cause injury to persons.
  - Wear personal protective equipment.



**!** Pay attention to the direction of the vent hole and drain plug when draining the pump. Make sure that the escaping liquid does not cause damage to the motor or other components.


Drain pumps which are not being used during periods of frost to avoid damage.

To drain the pump loosen the vent screw in the pump head and remove all drain plugs from one side of the pump base.

Do not tighten the vent screw and replace the drain plug until the pump is to be used again.

#### CR, CRI, CRN 1s to 5

Before replacing the drain plug in the base, screw the bypass valve out against the stop. See fig. 18.



TM0112434097

**Fig. 18** Location of drain plug and bypass valve

Fit the drain plug by tightening the large union nut followed by the bypass valve.

### 7.2 Taking the product permanently out of operation

Observe the following if the pump is to be permanently taken out of operation and removed from the pipe system.

#### DANGER

##### Electric shock



Death or serious personal injury

- Before starting any work on the product, make sure that the power supply has been switched off and that it cannot be accidentally switched on.

#### WARNING

##### Falling objects



Death or serious personal injury

- Follow the lifting instructions.
- Use lifting equipment which is approved for the weight of the product.
- Persons must keep a safe distance to the product during lifting operations.
- Wear personal protective equipment.

For lifting instructions, see section [2.4 Lifting the product](#).

#### WARNING

##### Falling objects



Death or serious personal injury

- Keep the product in a stable and fixed position when working on it.

#### WARNING

##### Corrosive liquids



Death or serious personal injury

- Wear personal protective equipment.

#### WARNING

##### Toxic liquids



Death or serious personal injury

- Wear personal protective equipment.



#### CAUTION

##### Hot or cold liquid

Minor or moderate personal injury



- Wear personal protective equipment.



#### CAUTION

##### Hot or cold surface

Minor or moderate personal injury



- Make sure that no one can accidentally come into contact with hot or cold surfaces.

## 8. Fault finding the product

### DANGER

#### Electric shock



Death or serious personal injury

- Before starting any work on the product, make sure that the power supply has been switched off and that it cannot be accidentally switched on.

### WARNING



#### Corrosive liquids

Death or serious personal injury

- Wear personal protective equipment.

### WARNING



#### Toxic liquids

Death or serious personal injury

- Wear personal protective equipment.

### WARNING



#### Falling objects

Death or serious personal injury

- Keep the product in a stable and fixed position when working on it.



### CAUTION



#### Hot or cold liquid

Minor or moderate personal injury

- Wear personal protective equipment.



### CAUTION

#### Hot or cold surface

Minor or moderate personal injury

- Make sure that no one can accidentally come into contact with hot or cold surfaces.

Fault	Cause	Remedy
1. The motor does not run when started.	a) Supply failure. b) The fuses are blown. c) The motor-protective circuit breaker has tripped. d) The thermal protection has tripped. e) The main contacts in the motor-protective circuit breaker are not making contact or the coil is faulty. f) The control circuit is defective. g) The motor is defective.	Connect the power supply. Replace fuses. Reactivate the motor-protective circuit breaker. Reactivate the thermal protection. Replace the contacts or the magnetic coil. Repair the control circuit. Replace the motor.
2. The motor-protective circuit breaker trips immediately when the power supply is switched on.	a) One fuse is blown or the automatic circuit breaker has tripped. b) The contacts in the motor-protective circuit breaker are faulty. c) The cable connection is loose or faulty. d) The motor winding is defective. e) The pump is mechanically blocked. f) The motor-protective circuit breaker setting is too low.	Replace the fuse or cut in the circuit breaker. Replace the motor-protective circuit breaker contacts. Fasten or replace the cable connection. Replace the motor. Remove the mechanical blocking of the pump. Set the motor-protective circuit breaker correctly.
3. The motor-protective circuit breaker trips occasionally.	a) The motor-protective circuit breaker setting is too low. b) Low voltage at peak times.	Set the motor-protective circuit breaker correctly. Ensure a stable power supply.
4. The motor-protective circuit breaker has not tripped, but the pump does not run.	a) See 1 a), b), d), e) and f).	

Fault	Cause	Remedy
5. The pump performance is not constant.	a) The pump inlet pressure is too low (cavitation). b) The inlet pipe or pump is partly blocked by impurities. c) The pump draws in air.	Check the inlet conditions. Clean the inlet pipe or pump. Check the inlet conditions.
6. The pump runs, but gives no water.	a) The inlet pipe or pump is blocked by impurities. b) The foot or non-return valve is blocked in closed position. c) There is a leakage in the inlet pipe. d) There is air in the inlet pipe or pump. e) The motor runs in the wrong direction of rotation.	Clean the inlet pipe or pump. Repair the foot or non-return valve. Repair the inlet pipe. Check the inlet conditions. Change the direction of rotation of the motor.
7. The pump runs backwards when switched off.	a) There is a leakage in the inlet pipe. b) The foot or non-return valve is defective.	Repair the inlet pipe. Repair the foot or non-return valve.
8. Leakage in shaft seal.	a) The shaft seal is defective.	Replace the shaft seal.
9. Noise.	a) Cavitation. b) The pump does not rotate freely due to frictional resistance as a result of incorrect pump shaft position. c) Frequency converter operation.	Check the inlet conditions. Adjust the pump shaft. Follow the procedure in fig. 6, 7, 8 or in the appendix. See section <a href="#">3.2.5 Frequency converter operation</a> .

## 9. Technical data

### 9.1 Operating conditions

#### 9.1.1 Liquid temperature

Figure 1 in the appendix states the relationship between liquid temperature range and maximum permissible operating pressure.



The maximum permissible operating pressure and liquid temperature ranges apply to the pump only.

#### 9.1.2 Ambient temperature and altitude

Motor power [kW]	Motor make	Motor efficiency class	Maximum ambient temperature [°C]	Maximum altitude above sea level [m]
0.37 - 0.55	Grundfos MG	-	+40	1000
0.75 - 22	Grundfos MG	IE3	+60	3500
30.0 - 75.0	Siemens	IE3	+55	2750



The maximum permissible ambient temperature is stated on the motor nameplate, and it must not be exceeded during operation to avoid damaging the motor.

If the maximum permissible ambient temperature is not stated on the motor nameplate, the motor must not be used in an ambient temperature above 40 °C.

If the ambient temperature exceeds the above temperature values or the pump is installed at an altitude exceeding the above altitude values, the motor must not be fully loaded due to the risk of overheating. Overheating may result from excessive ambient temperatures or the low density and consequently low cooling effect of the air.

In such cases, it may be necessary to use a motor with a higher rated output.

Pos.	Motor power [kW]	Motor make
1	0.37 - 0.55	MG
	0.37 - 22	MGE
2	0.75 - 22	MG
3	30.0 - 75.0	Siemens

#### Example

Figure 19 shows that the load of an IE3 motor at an ambient temperature of 70 °C must not exceed 89 % of the rated output.

If the pump is installed 4750 m above sea level, the motor must not be loaded more than 89 % of the rated output.

In cases where both the maximum temperature and the maximum altitude are exceeded, the derating factors must be multiplied ( $0.89 \times 0.89 = 0.79$ ).





Fig. 19 Motor output in relation to temperature and altitude

### 9.1.3 Maximum permissible operating pressure and liquid temperature for the shaft seal



The diagram below applies to clean water and water containing antifreeze liquids.

### CR, CRI, CRN 1s to 20 and CR, CRN 32 to 64



**Fig. 20** Maximum permissible operating pressure and liquid temperature

Standard shaft seal	Motor [kW]	Temperature range [°C]
HQQE	0.37 - 45	-40 to +120
HBQE	55-75	0 to 120
HQQV	0.37 - 45	-20 to +90
HBQV	55-75	0 to 90


You can clean CRI and CRN pumps in place (CIP) with a type H shaft seal with EPDM rubber parts, HxxE and liquids up to 64 °C for maximum 15 minutes.



The pumping of liquids above 120 °C may result in periodical noise and reduced pump life.

CR, CRI, CRN pumps are not suitable for the pumping of liquids above 120 °C for long periods.

### 9.1.4 Minimum inlet pressure



TM02 0118 3800

**Fig. 21** Schematic view of open system with a CR pump

Calculate the maximum suction lift "H" in m head as follows:

$$H = Pb \times 10.2 - NPSH - Hf - Hv - H$$

Pb = Barometric pressure in bar.  
Barometric pressure can be set to 1 bar.  
In closed systems, Pb indicates the system pressure in bar.  
(10 bar = 1 MPa)

NPSH = Net Positive Suction Head in m head, to be read from the NPSH curve in the appendix (at the highest flow the pump will be delivering).

Hf = Friction loss in the inlet pipe in m head at the highest flow the pump will be delivering.

Hv = Vapour pressure for water in m head. See fig. 5 in the appendix.  
If the pumped liquid is not water, then use the vapour pressure for the liquid which is being pumped.

tm = Liquid temperature.

Hs = Safety margin = minimum 0.5 m head.

If the calculated "H" is positive, the pump can operate at a suction lift of maximum "H" m head.

If the calculated "H" is negative, an inlet pressure of minimum "H" m head is required. There must be a pressure equal to the calculated "H" during operation.

**Example**

P<sub>b</sub> = 1 bar.

Pump type: CR 15, 50 Hz.

Flow rate: 15 m<sup>3</sup>/h.

NPSH (see the appendix): 1.1 m head.

H<sub>f</sub> = 3.0 m head.

Liquid temperature: 60 °C.

H<sub>v</sub> (from fig. 5 in the appendix): 2.1 m head.

H = P<sub>b</sub> x 10.2 - NPSH - H<sub>f</sub> - H<sub>v</sub> - H<sub>s</sub> [m head].

H = 1 x 10.2 - 1.1 - 3.0 - 2.1 - 0.5 = 3.5 m head.

This means that the pump can operate at a suction lift of maximum 3.5 m head.

Pressure calculated in bar: 3.5 x 0.0981 = 0.343 bar.

Pressure calculated in kPa: 3.5 x 9.81 = 34.3 kPa.

**9.1.5 Maximum permissible inlet pressure**

The tables in the appendix state the maximum permissible inlet pressure. However, the actual inlet pressure + the maximum pump pressure at no flow must always be lower than the values stated in fig. 1 in the appendix.

The pumps are pressure-tested at a pressure of 1.5 times the values stated in fig. 1 in the appendix.

**9.1.6 Minimum flow rate****WARNING****Too high pressure and leakage**


Death or serious personal injury

- Do not run the pump against a closed outlet valve.

Due to the risk of overheating, do not use the pump at flows below the minimum flow rate.

The curves below show the minimum flow rate as a percentage of the rated flow rate in relation to the liquid temperature.

--- = air-cooled top.



TM01 2816 2302

**Fig. 22** Minimum flow rate

**9.1.7 Maximum flow rate**

The table in the appendix states the maximum flow rate. See fig. 2 in the appendix.

**9.2 Electrical data**

See the motor nameplate.

**9.3 Dimensions and weights**

Dimensions: See fig. 3 in the appendix.

Weights: See label on the packing.

**9.3.1 Sound pressure level**

See fig. 4 in the appendix.

**10. Disposing of the product**

This product or parts of it must be disposed of in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.




The crossed-out wheelie bin symbol on a product means that it must be disposed of separately from household waste. When a product marked with this symbol reaches its end of life, take it to a collection point designated by the local waste disposal authorities. The separate collection and recycling of such products will help protect the environment and human health.


See also end-of-life information at [www.grundfos.com/product-recycling](http://www.grundfos.com/product-recycling).

## Appendix


## NPSH




TM027387 3403




TM027126 2703




TM019882 3801




TM027127 2703




TM019883 3300



TM011934 0899



TM019884 3801



TM011935 0899








Fig. 1 Maximum permissible operating pressure and liquid temperature

50 Hz



	Oval		PJE - CLAMP - CA - UNION DIN - FGJ	
	Operating pressure	Liquid temperature range	Operating pressure	Liquid temperature range
CR, CRI, CRN 1s	16 bar	-20 to +120 °C	25 bar	-20 to +120 °C
CR, CRI, CRN 1	16 bar	-20 to +120 °C	25 bar	-20 to +120 °C
CR, CRI, CRN 3	16 bar	-20 to +120 °C	25 bar	-20 to +120 °C
CR, CRI, CRN 5	16 bar	-20 to +120 °C	25 bar	-20 to +120 °C
CR, CRI 10-1 → 10-16	16 bar	-20 to +120 °C	16 bar	-20 to +120 °C
CR, CRI 10-17 → 10-22	-	-	25 bar	-20 to +120 °C
CRN 10	-	-	25 bar	-20 to +120 °C
CR, CRI 15-1 → 15-7	10 bar	-20 to +120 °C	-	-
CR, CRI 15-1 → 15-10	-	-	16 bar	-20 to +120 °C
CR, CRI 15-12 → 15-17	-	-	25 bar	-20 to +120 °C
CRN 15	-	-	25 bar	-20 to +120 °C
CR, CRI 20-1 → 20-7	10 bar	-20 to +120 °C	-	-
CR, CRI 20-1 → 20-10	-	-	16 bar	-20 to +120 °C
CR, CRI 20-12 → 20-17	-	-	25 bar	-20 to +120 °C
CRN 20	-	-	25 bar	-20 to +120 °C
CR, CRN 32-1-1 → 32-7	-	-	16 bar	-30 to +120 °C
CR, CRN 32-8-2 → 32-14	-	-	30 bar	-30 to +120 °C
CR, CRN 45-1-1 → 45-5	-	-	16 bar	-30 to +120 °C
CR, CRN 45-6-2 → 45-11	-	-	30 bar	-30 to +120 °C
CR, CRN 45-12-2 → 45-13-2	-	-	33 bar	-30 to +120 °C
CR, CRN 64-1-1 → 64-5	-	-	16 bar	-30 to +120 °C
CR, CRN 64-6-2 → 64-8-1	-	-	30 bar	-30 to +120 °C

Oval

PJE - CLAMP - CA - UNION  
DIN - FGJ

	Operating pressure	Liquid temperature range	Operating pressure	Liquid temperature range
CR, CRI, CRN 1s	16 bar	-20 to +120 °C	25 bar	-20 to +120 °C
CR, CRI, CRN 1	16 bar	-20 to +120 °C	25 bar	-20 to +120 °C
CR, CRI, CRN 3	16 bar	-20 to +120 °C	25 bar	-20 to +120 °C
CR, CRI, CRN 5	16 bar	-20 to +120 °C	25 bar	-20 to +120 °C
CR, CRI 10-1 → 10-10	16 bar	-20 to +120 °C	16 bar	-20 to +120 °C
CR, CRI 10-12 → 10-17	-	-	25 bar	-20 to +120 °C
CRN 10	16 bar	-20 to +120 °C	25 bar	-20 to +120 °C
CR, CRI 15-1 → 15-5	10 bar	-20 to +120 °C	-	-
CR, CRI 15-1 → 15-8	-	-	16 bar	-20 to +120 °C
CR, CRI 15-9 → 15-12	-	-	25 bar	-20 to +120 °C
CRN 15	10 bar	-20 to +120 °C	25 bar	-20 to +120 °C
CR, CRI 20-1 → 20-5	10 bar	-20 to +120 °C	-	-
CR, CRI 20-1 → 20-7	-	-	16 bar	-20 to +120 °C
CR, CRI 20-8 → 20-10	-	-	25 bar	-20 to +120 °C
CRN 20	10 bar	-20 to +120 °C	25 bar	-20 to +120 °C
CR, CRN 32-1-1 → 32-5	-	-	16 bar	-30 to +120 °C
CR, CRN 32-6-2 → 32-10-2	-	-	30 bar	-30 to +120 °C
CR, CRN 45-1-1 → 45-4	-	-	16 bar	-30 to +120 °C
CR, CRN 45-5-2 → 45-7	-	-	30 bar	-30 to +120 °C
CR, CRN 64-1-1 → 64-3	-	-	16 bar	-30 to +120 °C
CR, CRN 64-4-2 → 64-5-2	-	-	30 bar	-30 to +120 °C

**Fig. 2 Maximum inlet pressure and flow rate for CR, CRI and CRN**

50 Hz				60 Hz			
Pump type	Maximum inlet pressure [bar]	Maximum flow rate [m³/h]	Pump type	Maximum inlet pressure [bar]	Maximum flow rate [m³/h]		
<b>CR, CRI, CRN 1s</b>				<b>CR, CRI, CRN 1s</b>			
1s-2 → 1s-36	10	1	1s-2 → 1s-27	10	1		1.3
<b>CR, CRI, CRN 1</b>				<b>CR, CRI, CRN 1</b>			
1-2 → 1-36	10	1	1-2 → 1-25	10	1		2.9
<b>CR, CRI, CRN 3</b>				1-27	15	1.5	
3-2 → 3-29	10	1	<b>CR, CRI, CRN 3</b>				5.4
3-31 → 3-36	15	1.5	3-2 → 3-17	10	1		
<b>CR, CRI, CRN 5</b>				3-19 → 3-25	15	1.5	
5-2 → 5-16	10	1	<b>CR, CRI, CRN 5</b>				10.2
5-18 → 5-36	15	1.5	5-2 → 5-9	10	1		
<b>CR, CRI, CRN 10</b>				5-10 → 5-24	15	1.5	
10-1 → 10-6	8	0.8	<b>CR, CRI, CRN 10</b>				16
10-7 → 10-22	10	0.8	10-1 → 10-5	8	0.8		
<b>CR, CRI, CRN 15</b>				10-6 → 10-17	10	1	
15-1 → 15-3	8	0.8	<b>CR, CRI, CRN 15</b>				29
15-4 → 15-17	10	1	15-1 → 15-2	8	0.8		
<b>CR, CRI, CRN 20</b>				15-3 → 15-12	10	1	
20-1 → 20-3	8	0.8	<b>CR, CRI, CRN 20</b>				35
20-4 → 20-17	10	1	20-1	8	0.8		
<b>CR, CRN 32</b>				20-2 → 20-10	10	1	
32-1-1 → 32-4	4	0.4	<b>CR, CRN 32</b>				48
32-5-2 → 32-10	10	1	32-1-1 → 32-2	4	0.4		
32-11-2 → 32-14	15	1.5	32-3-2 → 32-6	10	1		
<b>CR, CRN 45</b>				32-7-2 → 32-10-2	15	1.5	
45-1-1 → 45-2	4	0.4	<b>CR, CRN 45</b>				70
45-3-2 → 45-5	10	1	45-1-1 → 45-1	4	0.4		
45-6-2 → 45-13-2	15	1.5	45-2-2 → 45-3	10	1		
<b>CR, CRN 64</b>				45-4-2 → 45-7	15	1.5	
64-1-1 → 64-2-2	4	0.4	<b>CR, CRN 64</b>				102
64-2-1 → 64-4-2	10	1	64-1-1	4	0.4		
64-4-1 → 64-8-1	15	1.5	64-1 → 64-2-1	10	1		
<b>CR, CRN 95</b>				64-2 → 64-5-2	15	1.5	
95-1- → 95 1-1	4	0.4	<b>CR, CRN 95</b>				64
95-2- → 95-3-2	10	1	95-1- → 95 1-1	10	1		
95-3- → 95-6	15	1.5	95-2- → 95-3-2	15	1.5		
95-7- → 95-8-2	20	2	95-4- → 95-5-3	20	2		
<b>CR, CRN 125</b>				<b>CR, CRN 125</b>			
125-1 → 125-2-2	10	1	125-1 → 125-2-2	10	1		
125-2 → 125-4	15	1.5	125-2 → 125-4	15	1.5		
125-5 → 125-10	20	2	125-5 → 125-6	20	2		
<b>CR, CRN 155</b>				<b>CR, CRN 155</b>			
155-1 → 155-1-1	10	1	155-1 → 155-1-1	10	1		
155-2 → 155-3	15	1.5	155-2 → 155-3-3	15	1.5		
155-4-1 → 155-8-2	20	2					


**Fig. 3 Dimensions**

PJE	Oval Pump Type	CLAMP - FlexiClamp				UNION				DIN - FGJ								
		L [mm]	H [mm]	D [mm]	Rp	L [mm]	H [mm]	D [mm]	G	L [mm]	H [mm]	D [mm]	B <sub>2</sub> [mm]	B <sub>1</sub> [mm]	Ø [mm]			
CR 1s	160	50	1	-	-	-	-	-	-	250	75	25/32	100	145	180	220	13	
CRI, CRN 1s	-	-	-	210	50	30	162	50	2	250	75	25/32	100	64	180	220	13	
CR 1	160	50	1	-	-	-	-	-	-	250	75	25/32	100	145	180	220	13	
CRI, CRN 1	-	-	-	210	50	30	162	50	2	250	75	25/32	100	64	180	220	13	
CR 3	160	50	1	-	-	-	-	-	-	250	75	25/32	100	145	180	220	13	
CRI, CRN 3	-	-	-	210	50	30	162	50	2	250	75	25/32	100	64	180	220	13	
CR 5	160	50	1 1/4	-	-	-	-	-	-	250	75	25/32	100	145	180	220	13	
CRI, CRN 5	-	-	-	210	50	30	162	50	2	250	75	25/32	100	64	180	220	13	
CR 10	200	80	1 1/2	-	-	-	-	-	-	280	80	40	130	178	215	256	13.5	
CRI, CRN 10	-	-	-	261	80	60.1	202	80	50	-	280	80	40	130	200	215	248	13
CR 15	200	90	2	-	-	-	-	-	-	300	90	50	130	176	215	256	13.5	
CRI, CRN 15	-	-	-	261	90	60.1	202	90	50	-	300	90	50	130	200	215	248	13
CR 20	200	90	2	-	-	-	-	-	-	300	90	50	130	176	215	256	13.5	
CRI, CRN 20	-	-	-	261	90	60.1	202	90	50	-	300	90	50	130	200	215	248	13
CR 32	-	-	-	-	-	-	-	-	-	320	105	65	170	223	240	298	14	
CRN 32	-	-	-	326	105	88.9	-	-	-	320	105	65	170	226	240	298	14	
CR 45	-	-	-	-	-	-	-	-	-	365	140	80	190	248	266	331	14	
CRN 45	-	-	-	365	135	114.3	-	-	-	365	140	80	190	251	266	331	14	
CR 64	-	-	-	-	-	-	-	-	-	365	140	100	190	248	266	331	14	
CRN 64	-	-	-	365	135	114.3	-	-	-	365	140	100	190	251	266	331	14	

Fig. 4 Airborne noise emitted by pumps with motors fitted by Grundfos

50 Hz		60 Hz	
Motor [kW]	L <sub>pA</sub> [dB(A)] (ISO3743-2/ ISO1680 50 Hz)	Motor [kW]	L <sub>pA</sub> [dB(A)] (ISO3743-2/ ISO1680 60 Hz)
0.37	50	0.37	55
0.55	50	0.55	53
0.75	50	0.75	54
1.1	52	1.1	57
1.5	54	1.5	59
2.2	54	2.2	59
3.0	55	3.0	60
4.0	62	4.0	66
5.5	60	5.5	65
7.5	60	7.5	65
11	60	11	65
15	60	15	65
18.5	60	18.5	65
22	66	22	70
30	67	33.5	78
37	67	41.5	78
45	67.5	51	72
55	71.5	62	76
75	74	84	78
90	73	101	77.5
110	74	123	78.5
132	73.5	148	78
160	77	180	81.5
200	76.5	224	81.5

Fig. 5



TM0274453503

Fig. 6 CR, CRI, CRN 1s, 1, 3 and 5







Fig. 7 CR, CRI, CRN 10, 15 and 20



---


E

M6 - 13 Nm  
M8 - 27 Nm  
M10 - 62 Nm

TM02 8542 3620


---

---

FTM02 8515 0304

---

Fig. 8 CR, CRN 32, 45, 64



Pos.	Designation				
	GB	BG	CZ	DE	DK
1	Adapter flange	Преходен фланец	Mezípríruba	Zwischenflansch	Mellemlflange
1a	Motor stool	Столче на двигателя	Lucernaty motoru	Laterne	Mellemtykke
2	Pump head	Глава на помпата	Hlava čerpadla	Kopfstück	Topstykke
3	Chamber, top	Горна камера	Horní článek	Oberste Kammer	Kammer, øverste
3a	Chamber without neck ring	Камера без пръстен	Článek bez mezerového kroužku	Kammer ohne Spaltring	Kammer uden tætningsring
4	Chamber complete	Камера - комплект	Kompletní článek	Kammer komplett	Kammer komplet
4a	Chamber with bearing ring	Камера с лагерен пръстен	Článek s kroužkem ložiska	Kammer mit Lagerring	Kammer med lejering
5a	Chamber complete	Камера - комплект	Kompletní článek	Kammer komplett	Kammer komplet
6	Base	Основа	Patka	Fußstück	Fodstykke
6a	Stop pin	Шплент	Zárazkový kolík	Sperrzapfen	Rotationslás
6d	Guide plate for base	Водеща плоча за основата	Vodicí deska patky	Führungsplatte für Fußstück	Styrelade til fodstykke
6g	Bearing ring	Ролков лагер	Kroužek ložiska	Lagerring	Lejering
7	Coupling guard	Предпазен капак на съединителят	Kryt spojky	Schutzschild	Skærm
7a	Screw	Винт	Šroub	Schraube	Skrue
8	Coupling complete	Съединител - комплект	Kompletní spojka	Kupplung komplett	Kobling komplet
9	Screw	Винт	Šroub	Schraube	Skrue
10	Shaft pin	Шплент на вала	Válcový kolík	Zylinderstift	Stift
10a	Coupling half	Половина на съединението	Půlspojka	Kupplungshälfte	Koblingshalvpart
12	Flange (oval)	Фланец (овален)	Příruba (oválná)	Flansch (oval)	Flange (oval)
18	Air vent screw	Винт за обезвъздушаване	Odvzdušňovací šroub	Entlüftungsschraube	Luftskrue
19	Pipe plug	Тапа на тръбата	Zátka	Stopfen	Rørprop
21	Plug	Пробка	Zátka	Stopfen	Prop
23	Plug	Пробка	Zátka	Stopfen	Prop
25	Drain plug	Пробка за дренажиране	Vypouštěcí zátka	Entleerungsstopfen	Tømmerprop
26	Staybolt	Шпилка	Rozpěrný šroub	Stehbolzen	Støttebolt
26a	Strap	Лента	Stahovací pás	Spannband	Spændebånd
26b	Screw	Винт	Šroub	Schraube	Skrue
26c	Washer	Шайба	Podložka	Unterlegscheibe	Spændeskive
28	Screw	Винт	Šroub	Schraube	Skrue
28a	Screw	Винт	Šroub	Schraube	Skrue
31	Screw	Винт	Šroub	Schraube	Skrue
32	Washer	Шайба	Podložka	Unterlegscheibe	Spændeskive
32a	Washer	Шайба	Podložka	Unterlegscheibe	Spændeskive
35	Screw	Винт	Šroub	Schraube	Skrue
36	Nut	Гайка	Matici	Mutter	Møtrik
36a	Nut	Гайка	Matici	Mutter	Møtrik
37	O-ring/gasket	О-пръстен/упътнение	O-kroužek/těsnici kroužek	O-Ring/Dichtung	O-ring/pakning
38	O-ring	О-пръстен	O-kroužek	O-Ring	O-ring
38a	O-ring	О-пръстен	O-kroužek	O-Ring	O-ring
39	Gasket	Уплътнение	Těsnění	Dichtung	Pakning
44	Inlet part complete	Входяща част - комплект	Kompletní vtoková část	Einlaufteil komplett	Indløbsdel komplet
44a	Inlet part upper	Входна част, горна	Vtoková část horní	Oberes Einlaufteil	Øvre indløbsdel
44b	Inlet part lower	Входна част, долнна	Vtoková část spodní	Unteres Einlaufteil	Nedre indløbsdel
45	Neck ring	Пръстен	Mezerový kroužek	Spaltring	Tætningsring
45a	Neck ring complete	Пръстен - комплект	Kompletní mezerový kroužek	Spaltring komplett	Tætningsring komplet

Pos.	Designation				
	GB	BG	CZ	DE	DK
47	Bearing ring	Търкалящ лагер	Kroužek ložiska	Lagerring	Lejering
47a	Bearing with driver	Търкалящ лагер с винт за застопоряване	Ložisko s unašečem	Lager mit Mitnehmer	Leje med medbringer
47b	Bearing ring, rotating	Търкалящ лагер - въртящ	Kroužek ložiska otočný	Lagerring, rotierend	Lejering, roterende
47c	Bush	Лагерна втулка	Pouzdro	Buchse	Bøsnings
47d	Retaining ring	Спирателен пръстен	Přídřžný kroužek	Haltering	Låsering
47e	Retaining ring	Спирателен пръстен	Přídřžný kroužek	Haltering	Låsering
48	Split cone nut	Гайка на разрязания конус	Matice upínacího pouzdra	Mutter für Klemmbuchse	Møtrik for klembøsnings
49	Impeller	Работно колело	Oběžné kolo	Laufrad	Løber
49a	Impeller	Работно колело	Oběžné kolo	Laufrad	Løber
49b	Split cone	Разрязан конус	Upínací pouzdro	Klemmbuchse	Klembøsnings
49c	Wear ring	Износваща се пръстен	Těsnící kruh	Verschleißring	Slidring
50a	Outlet part/top guide vanes	Нагнетателна част/горен направляващ апарат	Výtláčná část/horní vodicí lopatky	Auslass/oberster Leitapparat	Afgangsdel/øvre lededel
51	Pump shaft	Ван на помпата	Hřídel čerpadla	Pumpenwelle	Pumpeaksel
55	Sleeve	Вышна втулка	Vnější plášť	Mantel	Svøb
56	Base plate	Основна плоча	Základová deska	Grundplatte	Fodplade
56a	Base plate	Основна плоча	Základová deska	Grundplatte	Fodplade
56c	Screw	Винт	Šroub	Schraube	Skrue
56d	Washer	Шайба	Podložka	Unterlegscheibe	Spændeskive
57	O-ring	О-пръстен	O-kroužek	O-Ring	O-ring
58	Seal carrier	Носач на уплътнението	Unašeč ucpávky	Halter für Wellenabdichtung	Holder for akseltætning
58a	Screw	Винт	Šroub	Schraube	Skrue
60	Spring	Пружина	Pružina	Feder	Fjeder
61	Seal driver	Водач	Unašeč	Mitnehmer	Medbringer
62	Stop ring	Зегерка	Dorazový kroužek	Stopring	Stopring
64	Spacing pipe	Дистанционна тръба	Distanční pouzdro	Distanzhülse	Afstandsønsning
64a	Spacing pipe	Дистанционна тръба	Distanční pouzdro	Distanzhülse	Afstandsønsning
64b	Spacing pipe	Дистанционна тръба	Distanční pouzdro	Distanzhülse	Afstandsønsning
64c	Clamp, splined	Шлицова клема	Drážková spona	Spannstück, Vielnut	Spændestykke, spline
64d	Spacing pipe	Дистанционна тръба	Distanční pouzdro	Distanzhülse	Afstandsønsning
65	Neck ring retainer	Държач на пръстена	Přídřžka mezerového kroužku	Halter für Spaltring	Holder for tætningsring
66	Washer	Шайба	Podložka	Unterlegscheibe	Spændeskive
66a	Washer	Шайба	Podložka	Unterlegscheibe	Spændeskive
66b	Lock washer	Контра - шайба	Pojistná podložka	Sicherungsblech	Låseskive
67	Nut/screw	Гайка/Винт	Matice/Šroub	Mutter/Schraube	Møtrik/Skrue
69	Spacing pipe	Дистанционна тръба	Distanční pouzdro	Distanzhülse	Afstandsønsning
76	Nameplate set	Табела - комплект	Sada štítků	Schildersatz	Skiltesæt
76a	Rivet	Нит	Nýt	Niete	Nitte
77	Pump head cover	Капак на главата на помпата	Kryt hlavy čerpadla	Mantel für Pumpenkopf	Overdækning til pumpehoved
100	O-ring	О-пръстен	O-kroužek	O-Ring	O-ring
105	Shaft seal	Уплътнение на вал	Hřídelová ucpávka	Wellenabdichtung	Akseltætning
201	Flange	Фланец	Příruba	Flansch	Flange
203	Retaining ring	Спирателен пръстен	Přídřžný kroužek	Haltering	Låsering

Pos.	Designation				
	EE	ES	FI	FR	GR
1	Üleminek äärik	Brida acoplamiento	Válilaiппa	Bride d'adaptation	Φλάντια προσαρμογής
1a	Mootoripukk	Acoplamiento	Mootorin jalusta	Lanterne moteur	Στήριγμα κινητήρα
2	Pumba pea	Cabezal bomba	Pumpupää	Tête de pompe	Κεφαλή αντίλας
3	Ülemine vahepesa	Cámera superior	Pesállyin	Chambre supérieure	Θάλαμος, άνω
3a	Tihendusröngata vahepesa	Cámera sin anillo de junta	Pesá, ilman kaulengasta	Chambre sans bague d'étanchéité	Θάλαμος χωρίς δακτύλιο λαιμού
4	Komplektne vahepesa	Cámera completa	Täydellinen pesä	Chambre complète	Θάλαμος πλήρης
4a	Laagriga vahepesa	Cámera con anillo cojinete	Pesá laakerirenkaalla	Chambre avec bague de palier	Θάλαμος με δακτύλιο εδράνου
5a	Komplektne vahepesa	Cámera completa	Täydellinen pesä	Chambre complète	Θάλαμος πλήρης
6	Alus	Base	Jalkakappale	Pied de pompe	Βάση
6a	Lukustustihvt	Pasador tope	Pidätintappi, lukitustappi	Goupille d'arrêt	Πλίρος συγκράτησης
6d	Aluse juhplaat	Placa guía para base	Ohjauslevy jalustaan	Plaque pour pied de pompe	Πλάκα οδηγός γιά τη βάση
6g	Alumine laager	Anillo cojinete	Laakerirengas	Joint de palier	Δακτύλιος εδράνου
7	Ühendusmuhi kate	Protector acoplamiento	Kytikimen suoja	Protège-accouplement	Προφυλακτήρας συνδέσμου
7a	Kruvi	Tornillo	Ruuvi	Vis	Κοχλίας
8	Komplektne ühendusmuhv	Acoplamiento completo	Täydellinen kytkin	Accouplement complet	Σύνδεσμος πλήρης
9	Kruvi	Tornillo	Ruuvi	Vis	Κοχλίας
10	Völli tihvt	Pasador eje	Akselitappi	Goupille cylindrique	Πλίρος άξονα
10a	Siduri osa	Semicacoplamiento	Kytikimen puolisko	Demi-accouplement	Ημισύνδεσμος
12	Flants (oval)	Brida (ovalada)	Laippa (soikea)	Bride (ovale)	Φλάντια (οβάλ)
18	Öhutusventtiil	Tornillo purga aire	Ilmausuuruvi	Vis de purge	Τάπτο εξαερισμού
19	Aäriku kork	Tapón tubería	Putkitulppa	Bouchon	Τάπτο σωλήνα
21	Kork	Tapón	Tulppa	Bouchon	Τάπτα
23	Kork	Tapón	Tulppa	Bouchon	Τάπτα
25	Tühjendusava kork	Tapón purga	Tyhjennystulppa	Bouchon de vidange	Τάπτο αποστράγγισης
26	Distantspolt	Espárramo sujetación	Pinnapultti	Goujon	Κοχλίες συγκράτησης
26a	Klamber	Tirante	Haka (säppi)	Tirant d'assemblage	Τιράντα
26b	Kruvi	Tornillo	Ruuvi	Vis	Κοχλίας
26c	Seib	Arandela	Aluslevy	Rondelle	Ροδέλα
28	Kruvi	Tornillo	Ruuvi	Vis	Κοχλίας
28a	Kruvi	Tornillo	Ruuvi	Vis	Κοχλίας
31	Kruvi	Tornillo	Ruuvi	Vis	Κοχλίας
32	Seib	Arandela	Aluslevy	Rondelle	Ροδέλα
32a	Seib	Arandela	Aluslevy	Rondelle	Ροδέλα
35	Kruvi	Tornillo	Ruuvi	Vis	Κοχλίας
36	Mutter	Tuerca	Mutteri	Ecrou	Περικόχλιο
36a	Mutter	Tuerca	Mutteri	Ecrou	Περικόχλιο
37	O-ring/tihend	Junta tórica/junta	O-rengas tiiviste	Joint/bague	Δακτύλιος-Ο/ παρέμβασμα
38	O-ring	Junta tórica	O-rengas	Joint	Δακτύλιος-Ο
38a	O-ring	Junta tórica	O-rengas	Joint	Δακτύλιος-Ο
39	Tihend	Junta	Tiiviste	Bague	Τσιμούχα
44	Komplektne imiosa	Parte aspiración completa	Täydellinen sisäosa	Partie aspiration complète	Πλήρες εσωτερικό μέρος
44a	Sisendosa ülemine	Pieza de entrada, superior	Ylempi imuosa	Pièce d'aspiration supérieure	Τμήμα εισόδου, πάνω
44b	Sisendosa alumine	Pieza de entrada, inferior	Alempi imuosa	Pièce d'aspiration inférieure	Τμήμα εισόδου, κάτω
45	Tihendusröngas	Anillo tope	Kaularengas	Bague d'étanchéité	Δακτύλιος λαιμού

Pos.	Designation				
	EE	ES	FI	FR	GR
45a	Tihendusrõngas	Anillo tope completo	Täydellinen kaularengas	Bague d'étanchéité complète	Δακτύλιος λαιμού πλήρης
47	Laager	Anillo cojinete	Laakerirengas	Bague de palier	Δακτύλιος εδράνου
47a	Juhikuga vahelaager	Cojinete con engranaje	Ohjainlaakeri	Bague de palier avec driver	Εδρανό με οδηγό
47b	Laager, pöörlev	Anillo cojinete giratorio	Laakerirengas, pyörivä	Bague de palier tournante	Δακτύλιος εδράνου στρεφόμενος
47c	Puks	Manguito	Holkki	Douille	Φωλιά
47d	Lukustusrõngas	Anillo cierre	Lukitusrengas	Bague de blocage	Δακτύλιος συγκράτησης
47e	Lukustusrõngas	Anillo cierre	Lukitusrengas	Bague de blocage	Δακτύλιος συγκράτησης
48	Löhismutter	Tuerca casquillo cónico	Kartioholki mutteri	Ecrou de cône de serrage	Περικόλιο διαιρούμενου κύνου
49	Tööratas	Impulsor	Juoksupyörä	Roue	Πτερωτή
49a	Tööratas	Impulsor	Juoksupyörä	Roue	Πτερωτή
49b	Survepuks	Casquillo cónico	Kartioholki	Cône de serrage	Διαιρούμενος κύνος
49c	Kulutusrõngas	Anillo desgaste	Kulutusrengas	Bague d'usure	Δακτύλιος φθοράς
50a	Surveosa/ ülemised juhtlabad	Pieza de descarga/ álabes guía superiores	Paineppuoli / ylemmät johdesilvet	Pièce de refoulement/ aubes directrices supérieures	Τμήμα κατάθλιψης/πάνω σδημάτη πτερύγια
51	Pumba völli	Eje bomba	Pumppuaaksi	Arbre de pompe	Αξόνας αντλίας
55	Kattesärk	Camisa exterior	Ulompi vaippa	Chemise	Εξωτερικό χιτώνιο
56	Alusplaat	Placa base	Jalustalevy	Plaque de base	Πλάκα βάσης
56a	Alusplaat	Placa base	Jalustalevy	Plaque de base	Πλάκα βάσης
56c	Kruvi	Tornillo	Ruubi	Vis	Κοχλίας
56d	Seib	Arandela	Aluslevy	Rondelle	Ροδέλα
57	O-ring	Junta tórica	O-rengas	Joint	Δακτύλιος-Ο
58	Tihendi kandur	Soporte cierre	Tiivistekannatin	Toc d'entraînement	Φορέας στυπιοθλίπτη
58a	Kruvi	Tornillo	Ruubi	Vis	Κοχλίας
60	Vedru	Muelle	Jousi	Ressort	Ελαστήριο
61	Vöilitihindi juhik	Guia de cierre	Tiivisteen vetotappi	Toc d'entraînement	Θόηγός στεγνωτοποιητικού
62	Lukustusrõngas	anillo de tope	Pysäytinrengas	Bague d'arrêt	Τερματικός δακτύλιος
64	Distantspuks	Casquillo espaciador	Väliholkki	Douille d'entretoise	Αποστάτης
64a	Distantspuks	Casquillo espaciador	Väliholkki	Douille d'entretoise	Αποστάτης
64b	Distantspuks	Casquillo espaciador	Väliholkki	Douille d'entretoise	Αποστάτης
64c	Soontega puks	Casquillo ranurado	Kiristin, rihlattu	Pièce de serrage	Στεφάνη με εγκοπές
64d	Distantspuks	Casquillo espaciador	Väliholkki	Douille entretoise	Αποστάτης
65	Tihendusrõngal klamber	Retén anillo junta	Kaulusrenkaan pidin	Support pour bague d'étanchéité	Στήριγμα δακτυλίου λαιμού
66	Seib	Arandela	Aluslevy	Rondelle	Ροδέλα
66a	Seib	Arandela	Aluslevy	Rondelle	Ροδέλα
66b	Vedruseib	Arandela cierre	Lukitusaluslevy	Rondelle de blocage	Συγκράτηση ροδέλας
67	Mutter/Kruvi	Tuerca/Tornillo	Mutteri/Ruubi	Ecrou/Vis	Περικόλιο/Κοχλίας
69	Distantspuks	Casquillo espaciador	Väliholkki	Douille entretoise	Αποστάτης
76	Pumba silidik	Juego placa identificación	Arvokilpisarja	Plaque d'identification	Σετ πινακίδας
76a	Neet	Remache	Niitti	Rivet	Πριτσίνι
77	Pumba kaas	Cubierta del cabezal de la bomba	Moottoriosan suoja	Couvercle hydraulique	Καπάκι κεφαλής αντλίας
100	O-ring	Junta tórica	O-rengas	Joint	Δακτύλιος-Ο
105	Vöilitihend	Cierre	Akselitiviste	Garniture mécanique	Στυπιοθλίπτης
201	Äärik	Brida	Laippa	Bride	Φλάντζα
203	Lukustusrõngas	Anillo cierre	Lukitusrengas	Bague de blocage	Δακτύλιος συγκράτησης

Pos.	Designation				
	HR	HU	IT	LT	LV
1	međuprinrubnica	csatlakozó karima	Flangie adattatrici	Tarpinis flanšas	Pārejas savienotājelementa atloks
1a	međukomad	motorartó közdarab	Lanterna del motore	Variklio atrama	Motora paliktnis
2	glava crpke	szivattyúfej	Testa pompa	Siurbilo galvutė	Sūkņa galva
3	gornja komora	felső kamra	Camera superiore	Viršutinė kamera	Kamera, augšējā
3a	komora bez rascjepljenog prstena	közkamra résgyűrű nélkül	Camera senza collarino	Kamera be kaklelio žiedu	Kamera bez gredzena ar frēzējumu
4	kompletna komora	komplett közkamra	Camera completa	Kamera	Nokomplektēta kamera
4a	komora s ležajnim prstenom	csapágvas közkamra	Camera con cuscinetto	Kamera su guolio žiedu	Kamera ar gultņa gredzenu
5a	kompletna komora	komplett közkamra	Camera completa	Kamera	Nokomplektēta kamera
6	nožni dio	talp	Base	Korpusas	Balstplātne
6a	zatik	rögzítő tüske	Molla di arresto	Fiksatorius	Atdures tapa
6d	vodilica za nožni dio	áramlástervező tányér	Guida per basamento	Korpuso centravimo plokštėlė	Balstplātnes vadotne
6g	prsten ležaja	csapagygyűrű	Cuscinetto	Atraminis guolis	Gultņa gredzens
7	zaštitna spojka	tengelykapcsoló burkolat	Giunti di protezione	Movos apsauga	Savienotājuzmanas aizsargs
7a	vijak	csavar	Vite	Varžtas	Skrūve
8	spojka kompletna	komplett tengelykapcsoló	Giunto completo	Visa mova	Nokomplektēta savienotājuzmanava
9	vijak	csavar	Vite	Varžtas	Skrūve
10	zatik vratila	tengelyretesz	Molla albero	Veleno kaištis	Vārsptas tapa
10a	Spojnica	Tengelykapcsolófél	Semigiunto	Movos pusē	Savienotājuzmanas daļa
12	Prirubnica (ovalna)	Karima (ovális)	Flangia (ovale)	Flanšas (ovalinis)	Atloks (ovāls)
18	odzračni vijak	légtelenítő csavar	Vite della ventola	Oro išleidimo angos varžtas	Atgaisošanas skrūve
19	čep	karima zárócsavar	Tappo	Vamzdžio kamštelis	Caurules noslēgs
21	čep	zárócsavar	Tappo	Kamštelis	Noslēgs
23	čep	zárócsavar	Tappo	Kamštelis	Noslēgs
25	čep za pražnenje	ürítőcsavar	Tappo spурго	Skysčio išleidimo kamštelis	Izliešanas noslēgs
26	sprežni vijak	összefogó rúd	Tiranti	Savarža	Enkurskrūve
26a	zatezna traka	összefogó pánt	Tirante	Juostinė apkaba	Siksna
26b	vijak	csavar	Vite	Varžtas	Skrūve
26c	podložna pločica	távtartó	Rondella	Poveržlē	Paplāksne
28	vijak	csavar	Vite	Varžtas	Skrūve
28a	vijak	csavar	Vite	Varžtas	Skrūve
31	vijak	csavar	Vite	Varžtas	Skrūve
32	podložna pločica	távtartó	Rondella	Poveržlē	Paplāksne
32a	podložna pločica	távtartó	Rondella	Poveržlē	Paplāksne
35	vijak	csavar	Vite	Varžtas	Skrūve
36	matica	csavaranya	Dado	Veržlē	Uzgrieznis
36a	matica	csavaranya	Dado	Veržlē	Uzgrieznis
37	O-prsten/brtva	O-gyűrű/tömítés	O ring/guranizione	Žiedas/tarpiklis	Apalā šķērsgriezuma bīlgredzens / starplika
38	O-prsten	O-gyűrű	O ring	Žiedas	Apalā šķērsgriezuma bīlgredzens
38a	O-prsten	O-gyűrű	O ring	Žiedas	Apalā šķērsgriezuma bīlgredzens
39	Brtsva	Tömités	Guarnizione	Tarpiklis	Starplika
44	ulazni dio kompletan	komplett belső rész	Parte interna completa	Visa įsiurbimo dalis	Nokomplektēta ieplūdes daļa
44a	Gornji ulazni dio	Szívó oldal, felső	Parte superiore sezione di aspirazione	Viršutinė įvado dalis	Augšējā ieplūdes daļa

Pos.	Designation				
	HR	HU	IT	LT	LV
44b	Donji ulazni dio	Szívó oldal, alsó	Parte inferiore sezione di aspirazione	Apatinė jvado dalis	Apakšējā ieplūdes daļa
45	rascijepljeni prsten	résgyűrű	Collarino	Kakliuko žiedas	Gredzens ar frēzējumu
45a	rascijepljeni prsten kompletan	komplett résgyűrű	Colalrino completo	Visas kakliuko žiedas	Nokomplektēts gredzens ar frēzējumu
47	prsten ležaja	csapággyűrű	Cuscinetto	Guolis	Gultnā gredzens
47a	prsten ležaja sa zahvatnikom	csapág, megvezetővel	Cuscinetto con guida	Istatoma guolis	Gultnis ar vadotni
47b	prsten ležaja, rotirajući	csapággyűrű, forgórész	Cuscinetto rotante	Besisukantis guolis	Gultnā gredzens, rotējošs
47c	tuljak	persely	Boccolla	Jvorē	Ieliktnis
47d	pridržni prsten	rögzítő gyűrű	Anello di arresto	Laikantysis žiedas	Sprostgredzens
47e	pridržni prsten	rögzítő gyűrű	Anello di arresto	Laikantysis žiedas	Sprostgredzens
48	matica za konusni prsten	szorítókúp anya	Dado bussola conica	Skelta kūginė veržlė	Šķelts konusveida uzgrieznis
49	rotor	járókerék	Girante	Darbaratis	Darbrats
49a	rotor	járókerék	Girante	Darbaratis	Darbrats
49b	konusni prsten	szorítókúp	Bussola conica	Skelta kūginė jvorē	Šķelts konuss
49c	potrošni prsten	kopogýrű	Anello di usura	Dévéjimosi žiedas	Nodiluma kompensators
50a	Ispusni dio/gornja krilca vodilice	Nyomó oldal/felső vezetőlapatok	Parti superiori sezione di manda	Išvado dalis/viršutinės krepiamiosios mentės	Izplūdes daļa / augšējās virzošās lāptīņas
51	vratilo crpke	szivattyú tengely	Albero pompa	Siurblio velenas	Sūkņa vārpsta
55	plāst	köpenycső	Camicia esterna	Išorinis cilindras	Uzmaava
56	osnovna ploča	alaplap	Basamento	Korpuso pagrindas	Balstplātne
56a	osnovna ploča	alaplap	Basamento	Korpuso pagrindas	Balstplātne
56c	vijak	csavar	Vite	Varžtas	Skrūve
56d	podložna pločica	távtartó	Rondella	Poveržlē	Paplāksne
57	O-prsten	O-gyűrű	O ring	Žiedas	Apalā šķērsgriezuma blīvrgredzens
58	držać brtve	tómítés zárfedél	Porta tenuta	Riebokšlio laikiklis	Blīves turētājs
58a	vijak	csavar	Vite	Varžtas	Skrūve
60	opruga	rugó	Molla	Spyruoklē	Atspere
61	zahvatnik	vezető gyűrű	Guida garnizione	Riebokšlio tarpiklis	Blīvējuma vadotne
62	zaustavni prsten	stopgyűrű	Anello di arresto	Fiksavimo žiedas	Aizsarggredzens
64	odstojnik	távtartó gyűrű	Tubo distanziale	Tarpiné jvorē	Atdalīšanas caurule
64a	odstojnik	távtartó gyűrű	Tubo distanziale	Tarpiné jvorē	Atdalīšanas caurule
64b	odstojnik	távtartó gyűrű	Tubo distanziale	Tarpiné jvorē	Atdalīšanas caurule
64c	zatezni komad, višeutorni	hornyos rögzítőgyűrű	Giunto	Apkaba, skelta	Skava, rievota
64d	odstojnik	távtartó gyűrű	Tubo distanziale	Tarpiné jvorē	Atdalīšanas caurule
65	držać za rascijepljeni prsten	résgyűrű rögzítő	Fermo per collarino	Kakliuko žiedo laikiklis	Gredzens ar frēzējumu vadplāksne
66	podložna pločica	távtartó	Rondella	Poveržlē	Paplāksne
66a	podložna pločica	távtartó	Rondella	Poveržlē	Paplāksne
66b	sigurnosna pločica	rögzítő alátét	Blocco per rondella	Fiksuojamoji poveržlē	Sprostplāksne
67	matica/vijak	csavaranya/csavar	Dado/Vite	Fiksuojamoji veržlē/Varžtas	Uzgrieznis/skrūve
69	odstojnik	távtartó gyűrű	Tubo distanziale	Tarpiné jvorē	Atdalīšanas caurule
76	natpisne pločice	adattábla készlet	Targhetta	Vardiné plokštelē	Datu plāksnišu komplekts
76a	Zakovica	Szegecs	Rivetto	Kniedē	Kniede
77	Poklopac glave crpke	Szivattyú fej fedél	Copertura testa pompa	Siurblio galvutēs gaubtas	Sūkņa galvas pārsegs
100	O-prsten	O-gyűrű	O ring	Žiedas	Apalā šķērsgriezuma blīvrgredzens
105	brtva vratila	tengelytómítés	Tenuta meccanica	Riebokšlis	Vārpstas blīve
201	prirubnica	karima	Flangia	Flanšas	Atloks
203	pridržni prsten	rögzítő gyűrű	Blocca flangia	Laikantysis žiedas	Sprostgredzens

Pos.	Designation				
	NL	PL	PT	RO	RS
1	Adapterflens	Kolnierz przejściowy	Flange do adaptador	Flanșa de adaptare	Prirbunica podešavanja
1a	Lantaarnstuk	Podstawa silnika	Adaptador do motor	Scaunul motorului	Oslonac motora
2	Pompkop	Główica pompy	Cabeça da bomba	Capul pompei	Glava pumpe
3	Bovenste kamer	Komora górska	Câmara superior	Camera superioară	Gornje kućište
3a	Kamer zonder spaltring	Komora bez pierścienia bieżnego	Câmara sem aro	Camera fără inel de uzură	Kućište bez oslonog prstena
4	Kamer compleet	Komora, kompletna	Câmara completa	Camera completă	Kompletno kućište
4a	Kamer met lager	Komora z pierścieniem oporowym lożyska	Câmara com casquilho	Camera cu lagăr	Kućište sa ležišnim prstenom
5a	Kamer compleet	Komora, kompletna	Câmara completa	Camera completă	Kompletno kućište
6	Voetstuk	Podstawa	Base	Baza pompei	Element oslonca
6a	Anti rotatie stift	Kołek ustalający	Pino	Știft de blocare	Zauastvni štift
6d	Geleideplaat voor voetstuk	Dolna płytka kierująca	Prato-guia da base	Placa de ghidaj pentru baza pompei	Vodeća ploča osnove
6g	Lager	Pierścień oporowy lożyska	Casquillo	Lagăr	Prsten kugličnog ležaja
7	Koppeling beschermmer	Osłona sprzągła	Protecção do acoplamento	Apărătoare de protecție	Zaštita spojnice
7a	Schroef	Šruba	Parafuso	Şurub	Zavrtanj
8	Koppeling compleet	Sprząglo, komplet	Acoplamento completo	Cuplaj complet	Komplet spojnice
9	Schroef	Šruba	Parafuso	Şurub	Zavrtanj
10	Stift	Klin mocujący walu	Pino do veio	Știftul axului	Cilindrični štift
10a	Koppelingshelft	Polówka sprzągła	Semi-acoplamento	Semicuplă	Polutkučna spojnice
12	Flens (oval)	Kolnierz (ovalny)	Flange (oval)	Flanșă (ovală)	Prirbunica (ovalna)
18	Ontluchtings-schroef	Šruba odpowietrzająca	Parafuso de purga	Şurub de aerisire	Zavrtanj za odzraćivanje
19	Plug	Korek	Bujão da tubagem	Dop filetat pentru țeavă	Žep cevi
21	Plug	Korek	Bujão da tubagem	Dop	Čep
23	Plug	Korek	Bujão da tubagem	Dop	Čep
25	Aftapplug	Korek spustowy	Bujão de drenagem	Dop (bușon) de golire	Drenažni čep
26	Trekstag	Šruba ściągająca	Perno	Prezoane	Osnovni zavrtanj
26a	Spanband	Ściąg	Tirante	Clemă	Osigurač
26b	Schroef	Šruba	Parafuso	Şurub	Zavrtanj
26c	Sluitring	Podkładka	Anilha	Šaibă	Podloška
28	Schroef	Šruba	Parafuso	Şurub	Zavrtanj
28a	Schroef	Šruba	Parafuso	Şurub	Zavrtanj
31	Schroef	Šruba	Parafuso	Şurub	Zavrtanj
32	Sluitring	Podkładka	Anilha	Šaibă	Podloška
32a	Sluitring	Podkładka	Anilha	Šaibă	Podloška
35	Schroef	Šruba	Parafuso	Şurub	Zavrtanj
36	Moer	Nakrętka	Fêmea	Piuliță	Matica
36a	Moer	Nakrętka	Fêmea	Piuliță	Matica
37	O-ring pakking	Pierścien O-ring/uszczelka	O-ring/junta	O-ring/garnitură	O-zaptivni prsten
38	O-ring	Pierścien O-ring	O-ring	O-ring	O-prsten
38a	O-ring	Pierścien O-ring	O-ring	O-ring	O-prsten
39	Pakking	Uszczelka	Junta	Garnitură	Zaptivač
44	Inlaatdeel compleet	Komora wlotowa	Aspiração completa	Parte de intrare completă	Komplet ulazni deo
44a	Bovenste inlaatgedeelte	Część wlotowa (górska)	Peça de entrada, superior	Parte aspirație superioară	Gornji deo ulaza
44b	Onderste inlaatgedeelte	Część wlotowa (dolna)	Peça de entrada, inferior	Parte aspirație inferioară	Donjni deo ulaza
45	Spaltring	Pierścien bieżny	Aro	Inel de etanșare	Osloni prsten
45a	Spaltring compleet	Pierścien bieżny, obrotowy	Aro completo	Inel de etanșare complet	Komplet oslonog prstena
47	Lager	Pierścien oporowy lożyska	Casquillo	Lagăr	Prsten kugličnog ležaja

Pos.	Designation				
	NL	PL	PT	RO	RS
47a	Lager met meenemer	Łožysko z zabierakiem	Casquillo com guia	Lagăr cu cuzinet	Kuglični ležaj sa prstenom
47b	Lager roterend	Pierścień lożyskowy	Casquillo rotativo	Lagăr rotativ	Kuglični ležaj rotirajući
47c	Bus	Tulejka	Manga	Bucșă	Čaura
47d	Borgring	Pierścień mocujący	Retentor	Inel de blocare	Noseći prsten
47e	Borgring	Pierścień mocujący	Retentor	Inel de blocare	Noseći prsten
48	Klembusmoer	Nakrętka tulei stożkowej	Fêmea cónica	Piuličă cu strângere pe con	Matica konusne čaure
49	Waaier	Wirnik	Impulsor	Rotor	Obrtno kolo pumpe
49a	Waaier	Wirnik	Impulsor	Rotor	Obrtno kolo pumpe
49b	Klembus	Tuleja stożkowa	Casquillo cónico	Con de strângere	Konusna čaura
49c	Sluitring	Pierścień bieżny	Aro de desgaste	Inel de uzură	Habajući prsten
50a	Uitlaatgedeelte/ bovenste geleideschoep	Część wylotowa/górne krawędzie w korpusie	Peça de descarga/pás guia da parte superior	Parte refulare	Potisni deo/Gornje usmerno kolo
51	Pompas	Wal pompy	Veio	Axul pompei	Osvina pumpe
55	Mantel	Plaszcz	Camisa exterior	Manta exteroară	Spoljna zaštita
56	Voetplaat	Podstawa	Base	Placa de bază	Osnovna ploča
56a	Voetplaat	Podstawa	Base	Placa de bază	Osnovna ploča
56c	Schroef	Šruba	Parafuso	Şurub	Zavrtanj
56d	Sluitring	Podkładka	Anilha	Šaibă	Podloška
57	O-ring	Pierścień O-ring	O-ring	O-ring	O-prsten
58	Houder voor asafdichting	Mocowanie uszczelnienia	Suporte do empanque	Suport pentru etanșare	Kućište zaptivanja osovine
58a	Schroef	Šruba	Parafuso	Şurub	Zavrtanj
60	Veer	Sprzęzyna	Mola	Arc	Opruga
61	Meenemer	Zabierak	Batente do espaçador	Distanțier pentru etanșarea mecanică	Pogonaš zaptivaca
62	Stopring	Pierścień stopowy	Mola de encosto	Semering	Zauštnvi prsten
64	Afstandsbus	Tulejka dystansowa	Espaçador	Tub distanțier	Odstojna čaura
64a	Afstandsbus	Tulejka dystansowa	Espaçador	Tub distanțier	Odstojna čaura
64b	Afstandsbus	Tulejka dystansowa	Espaçador	Tub distanțier	Odstojna čaura
64c	Spanstuk, splined	Tulejka wielowypustowa	Casquillo escatelado	Suport canelat	Osigurač saumetkom
64d	Afstandsbus	Tulejka dystansowa	Espaçador	Tub distanțier	Odstojna čaura
65	Houder voor spaltring	Tulejka dystansowa	Retentor do aro	Suport pentru inelul de etanșare	Držać oslonog prstena
66	Sluitring	Podkładka	Anilha	Šaibă	Podloška
66a	Sluitring	Podkładka	Anilha	Šaibă	Podloška
66b	Borgring	Podkładka zabezpieczająca	Anilha retentora	Šaibă de blocare	Osiguravajuća podloška
67	Moer/Schroef	Nakrętka/Šruba	Fêmea/Parafuso	Piuličă/Şurub	Matica/Zavrtanj
69	Afstandsbus	Tulejka dystansowa	Espaçador	Tub distanțier	Odstojna čaura
76	Typeplaat set	Tabliczka znamionowa	Chapa de identificação	Eticheta	Pločica označavanja
76a	Klinknagel	Nit	Rebite	Nit	Zakivak
77	Deksel pompkop	Pokrywa głowicy pompy	Cobertura da cabeça da bomba	Acoperire capul pompei	Poklopac glave pumpe
100	O-ring	Pierścień O-ring	O-ring	O-ring	O-prsten
105	Asafdichting	Uszczelnienie walu	Empanque mecânico	Etanșare mechanică	Zaptivac osovine
201	Flens	Kolnierz	Flange	Flanșa	Prirbunica
203	Borgring	Pierścień mocujący	Anel retentor	Inel de blocare	Osloni prsten

Pos.	Designation			
	RU	SE	SI	SK
1	Промежуточный фланец	Mellanfläns	Vmesna priobnica	Medzipríruba
1a	Фонарь	Mellanstycke	Konzola motorja	Lucerna
2	Головная часть насоса	Toppstycke	Glava črpalke	Horné teleso čerpadla
3	Верхняя камера	Kammare, övre	Najvišja stopnja	Horná komora
3a	Камера без щелевого уплотнения	Mallankammare utan tätningsring	Stopnja brez režnega obroča	Komora bez rozverného krúžka
4	Камера в сборе	Kammare komplett	Stopnja komplet	Kompletná komora
4a	Камера с подшипниковым кольцом	Mellankammare med lager	Stopnja z ležajnim obročem	Komora s ložiskovým krúžkom
5a	Камера в сборе	Kammare komplett	Stopnja komplet	Kompletná komora
6	Основание	Fotstycke	Podnožje črpalke	Spodné teleso čerpadla
6a	Стопорный штифт	Stoppsprint	Zaporni zatič	Uzáverný kolík
6d	Направляющая плита для опоры/лапы	Styrplatta till fotstycke	Vodilna plošča za podnožje črpalke	Vodiaca platňa pre spodné teleso
6g	Подшипниковое кольцо	Bottenlager	Ležajni obroč	Ložiskový krúžok
7	Защитный кожух	Kopplingsskärm	Zaščitni pokrov	Ochranný kryt spojky
7a	Винт	Skruv	Vijak	Skrutka
8	Муфта в сборе	Koppling komplett	Sklopka komplet	Kompletná spojka
9	Винт	Skruv	Vijak	Skrutka
10	Цилиндрический штифт	Cylinderstift	Cilindrični zatič	Zylindricky kolík
10a	Полумуфта	Kopplingshalva	Polovica sklopke	Polspojska
12	Овальный фланец	Fläns (oval)	Priobnica (ovalna)	Príruba (oválna)
18	Винт вентиляционного отверстия	Airventilskruv	Odzračevalni vijak	Odvzdušňovacia skrutka
19	Заглушка	Rörprop	Čep	Zátka
21	Заглушка	Prop	Čep	Zátka
23	Заглушка	Prop	Čep	Zátka
25	Заглушка сливного отверстия	Tömnningsprop	Izpraznjevalni čep	Vypúšťacia skrutka
26	Стяжной болт	Stödbult	pritrievalni vijak	Stahovacie skrutky
26a	Стяжная лента	Spännsband	Zatezni pas	Stahovacie spony
26b	Винт	Skruv	Vijak	Skrutka
26c	Шайба	Bricka	Podložka	Podložka
28	Винт	Skruv	Vijak	Skrutka
28a	Винт	Skruv	Vijak	Skrutka
31	Шайба	Skruv	Vijak	Skrutka
32	Шайба	Bricka	Podložka	Podložka
32a	Шайба	Bricka	Podložka	Podložka
35	Винт	Skruv	Vijak	Skrutka
36	Гайка	Mutter	Matica	Matica
36a	Гайка	Mutter	Matica	Matica
37	Уплотнительное кольцо круглого сечения/прокладка	O-ring/packning	O-tesnilo/ tesnilo	O-krúžok/tesnenie
38	Уплотнительное кольцо круглого сечения	O-ring	O-tesnilo	O-krúžok
38a	Уплотнительное кольцо круглого сечения	O-ring	O-tesnilo	O-krúžok
39	Прокладка	Packning	Tesnilo	Tesnenie
44	Деталь всасывающей полости в сборе	Inloppsdel komplett	Vstopni del komplet	Vtoková časť komplet
44a	Впускная часть, верхняя	Övre inloppsdel	Zgornji dovodni del	Horný prívod čerpadla
44b	Впускная часть, нижняя	Undre inloppsdel	Spodnji dovodni del	Dolný prívod čerpadla
45	Щелевое уплотнение	Tätningsring	Režni obroč	Tesniaci krúžok
45a	Щелевое уплотнение в сборе	Tätningsring, komplett	Režni obroč komplet	Tesniaci krúžok komplet
47	Кольцо подшипника	Lager	Ležajni obroč	Ložiskový krúžok
47a	Подшипник с "поводком"	Lager med medbringare	Ležaj z nosilcem	Ložisko s unášacom

Pos.	Designation			
	RU	SE	SI	SK
47b	Вращающееся кольцо подшипника	Lagerring, roterande	Ležajni obroč, rotirajoč	Ložiskový krúžok, rotujúci
47c	Втулка	Bussning	Puša	Medzikrúžok/vložka
47d	Стопорное кольцо	Låsbricka	Držalni obroč	Držný kružok
47e	Стопорное кольцо	Låsbricka	Držalni obroč	Držný kružok
48	Гайка для зажимной втулки	Mutter för klämbussning	Matica za pritrdilno pušo	Matica so stahovacou vložkou
49	Рабочее колесо	Pumphjul	Rotor črpalke	Obežné koleso
49a	Рабочее колесо	Pumphjul	Rotor črpalke	Obežné koleso
49b	Разжимная втулка	Klämbussning	Pritrdilna puša	Stahovacia vložka
49c	Антифрикционное кольцо	Slitring	Obrabni obroč	Uzatvárací kružok
50a	Выпускающая часть/верхние направляющие лопатки	Utllopsdel/övre ledskenor	Tlačni del/zgornjega voda	Výpust/vrchné vodiace lopatky
51	Вал насоса	Pumpaxel	Os črpalke	Hriadeľ
55	Кожух	Mantel	Plašč	Plášt
56	Плита-основание	Fotstycke	Osnovna plošča	Základová platňa
56a	Плита-основание	Fotstycke	Osnovna plošča	Základová platňa
56c	Šruba	Skruv	Vijak	Skrutka
56d	Шайба	Bricka	Podložka	Podložka
57	Уплотнительное кольцо круглого сечения	O-ring	O-tesnilo	O-kružok
58	Базовая деталь уплотнения вала	Hållare för axeltätning	Držalo drsnega tesnila	Držiak upchávky hriadeľa
58a	Винт	Skruv	Vijak	Skrutka
60	Пружина	Fjäder	Vzmet	Spružina
61	Пружина торцовного уплотнения	Medbringare	Gonilo tesnila	Unášač
62	Стопорное кольцо	Stoppring	Stop prstan	Dorazový kružok
64	Промежуточная втулка	Avståndsbussning	Distančník	Dištančné puzdro
64a	Промежуточная втулка	Avståndsbussning	Distančník	Dištančná puzdro
64b	Промежуточная втулка	Avståndsbussning	Distančník	Dištančná puzdro
64c	Шлицевая зажимная гильза	Avståndsbussning (spline)	Natezní kos, utorni	Španovaci kus, drážkovaný
64d	Промежуточная втулка	Avståndsbussning	Distančník	Dištančné puzdro
65	Базовая деталь щелевого уплотнения	Hållare för tätningsring	Držalo režnega obroča	Držiak pre tesniaci kružok
66	Шайба	Bricka	Podložka	Podložka
66a	Шайба	Bricka	Podložka	Podložka
66b	Стопорная шайба	Låsbricka	Varnostna podložka	Zaistovací plech
67	Гайка/Šruba	Mutter/Skruv	Matica/Vijak	Matica/Skrutka
69	Промежуточная втулка	Avståndsbussning	Distančník	Dištančné puzdro
76	Фирменная табличка с техническими параметрами в сборе	Typskylt	Tipska ploščica	Štítek čerpadla
76a	Заклепка	Nit	Zakovica	Nit
77	Крышка головной части насоса	Kåpa, pumphuvud	Pokrov glave črpalke	Kryt čerpadla
100	Уплотнительное кольцо круглого сечения	O-ring	O-tesnilo	O-kružok
105	Уплотнение вала	Axeltätning	Drsno tesnilo	Upchávka hriadeľa
201	Фланец	Fläns	Prirobica	Príruba
203	Стопорное кольцо	Låsbricka	Držalni obroč	Tesniaci kružok/tesnenie

Pos.	Designation			
	TR	UA	KZ	CN
1	Küçültme flanşı	Перехідник	Аралық фланец	接头法兰
1a	Motor oturağı	Опора електродвигуна	Шам	电机座
2	Pompa başı	Головна частина насоса	Сорғының жоғарғы белігі	泵头
3	Bölmе, üst	Камера, верх	Жоғарғы камера	腔体。顶部
3a	Boyun halkasız bölme	Камера без ущельновального кольца	Саңылаусыз тығыздай камерасы	颈环
4	Komple bölümе	Набір камер	Жинақталған камера	完整腔体
4a	Yatak halkası bölme	Камера з кільцем підшипника	Подшипник сақинасы бар камера	带轴承环的腔体
5a	Komple bölümе	Набір камер	Жинақталған камера	完整腔体
6	Taban	Основа	Табаны	底座
6a	Stop pimi	Штифт зупинки	Ұстагыш штифт	止动销
6d	Taban için kılavuz plakası	Направляющая плита для основы	Треулердердің/аяқтардың бағыттағыш плитасы	基架导板
6g	Yatak halkası	Кільце опори	Подшипник сақина	轴承环
7	Kaplin koruması	Захисний кожух	Қорғыш қаптама	联轴器护罩
7a	Vida	Гвинт	Винт	螺丝
8	Komple kaplin	Муфта в сбори	Жинақталған муфта	联轴器套件
9	Vida	Гвинт	Винт	螺丝
10	Şaft pimi	Штифт валу	Цилиндрил штифт	轴销
10a	Kaplin yarısı	Напівмуфта	Жартылай муфта	联轴器
12	Flanş (oval)	Фланец (овальный)	Фланец (сопак)	法兰（椭圆）
18	Hava tahlilevidası	Гвинт вентиляционного клапана	Желдету саңылауының винті	排气螺丝
19	Boru tapası	Трубна заглушка	Тығын	管塞
21	Tara	Кабельний ввід	Тығын	插头
23	Tara	Кабельний ввід	Тығын	插头
25	Tahliye tapası	Пробка дренажного отверстия	Ағызу саңылауының тығыны	排水螺栓
26	Germe civatasi, saplama	Шпилька	Тарту бұрандасты	拉杆螺栓
26a	Şerit	Стрічка	Тартқыш бау	拉紧板条
26b	Vida	Гвинт	Винт	螺丝
26c	Pul	Шайба	Шайба	垫圈
28	Vida	Гвинт	Винт	螺丝
28a	Vida	Гвинт	Винт	螺丝
31	Vida	Гвинт	Винт	螺丝
32	Pul	Шайба	Шайба	垫圈
32a	Pul	Шайба	Шайба	垫圈
35	Vida	Гвинт	Винт	螺丝
36	Somun	Гайка	Гайка	螺母
36a	Somun	Гайка	Гайка	螺母
37	O-ring/conta	Ущельновальное кольце/прокладка	Денгелек кималы тығыздарғыш сақина/аралық қабат	O型圈/垫圈
38	O-ring	Ущельновальное кольце	Денгелек кималы тығыздарғыш сақина	O型圈
38a	O-ring	Ущельновальное кольце	Денгелек кималы тығыздарғыш сақина	O型圈
39	Conta	Прокладка	Аралық қабат	垫圈
44	Komple emme kismi	Всмоктуюча частина повна	Жинақталған сорғыш құстагы бөлшек	进口部分
44a	Giriş kismi üst	Верхняча частина впуску	Жоғарғы кіріс бөлік	上进口部件
44b	Giriş kismi alt	Нижняча частина впуску	Төмөнгі кіріс бөлік	下进口部件
45	Boyun halkası	Ущельновальное кольце	Саңылау тығыздарғыш	颈环
45a	Komple boyun halkası	Ущельновальное кольце повне	Жинақталған саңылау тығыздарғыш	颈环成品
47	Yatak halkası	Кільце опори	Подшипник сақинасы	轴承环
47a	Sürücülü yatak halkası	Опора з двигуном	"Жібі бар" подшипник	带驱动器的轴承
47b	Yatak halkası, döner	Кільце опори, що обертається	Подшипниктің айналғыш сақинасы	轴承动环
47c	Burç	Втулка	Втулка	衬套


Pos.	Designation			
	TR	UA	KZ	CN
47d	Tespit halkası	Стопорне кільце	Ұстагыш сақина	固定环
47e	Tespit halkası	Стопорне кільце	Ұстагыш сақина	固定环
48	Yarık koni somunu	Гайка для розтискної втулки	Қысқыш втулка гайкасы	花键圆锥螺母
49	Kanat	Робоче колесо	Жұмыс дәңгелегі	叶轮
49a	Kanat	Робоче колесо	Жұмыс дәңгелегі	叶轮
49b	Kapalı somun	Розтискна втулка	Босату втулкасы	花键圆锥
49c	Aşınma halkası	Кільце щільнінного ущільнення	Антіфрикционлық сақина	耐磨环
50a	Basma kismi/üst kilavuz kanatlar	Випуск/верхній блок направляющих лопаток	Шығару бөлігі/жогарғы бағыттағыш қалақтар	出口部件/顶部导流叶片
51	Mil	Вал насоса	Сорғы білірі	泵轴
55	Dış ceket	Зовнішня втулка	Қантама	套筒
56	Şase	Плита-основа	Астыңы плита	底板
56a	Şase	Плита-основа	Астыңы плита	底板
56c	Vida	Гвинт	Винт	螺丝
56d	Pul	Шайба	Шайба	垫圈
57	O-ring	Ущільнювальне кільце	Денгелек құмалы тығыздадыш сақина	O型圈
58	Salmasta taşıyıcı	Тримач ущільнення	Білік тығыздагышының негізгі бешшегі	机封压盖
58a	Vida	Гвинт	Винт	螺丝
60	Yay	Пружина	Серіппе	弹簧
61	Salmasta yuvası	Оправлення ущільнення	Бүйірлік тығызыда серіплесі	密封驱动
62	Kitleme somunu	Стопорне кільце	Ұстасыш сақина	止动环
64	Ayar ara parçası	Втулка	Арапық втулка	隔管
64a	Ayar ara parçası	Втулка	Арапық втулка	隔管
64b	Ayar ara parçası	Втулка	Арапық втулка	隔管
64c	Kelepçe boru	Шлицевий хомут	Тісті қысқыш гильза	花键夹
64d	Ayar ara parçası	Втулка	Арапық втулка	隔管
65	Boğaz aşınma halkası	Фіксатор ущільнювального кільца	Санылау тығыздагышының негізгі бешшегі	颈环挡圈
66	Pul	Шайба	Шайба	垫圈
66a	Pul	Шайба	Шайба	垫圈
66b	Kitleme pulu	Стопорна шайба	Ұстасыш шайба	锁紧垫圈
67	Somun/Vida	Гайка/гвинт	Гайка/ винт	螺母/螺丝
76a	Percin	Заклепка	Тойтarma шеге	隔管
77	Pompa kafası kapağı	Кришка головної частини насоса	Сорғы басының қақлағы	铭牌套件
69	Ayar ara parçası	Втулка	Арапық втулка	铆钉
76	Etiket	Шилдик насоса	Жинақталған техникалық параметрлері бар фирмалық тақташа	泵顶盖
100	O-ring	Ущільнювальне кільце	Денгелек құмалы тығыздадыш сақина	O型圈
105	Mekanik salmastra	Торцеве ущільнення валу	Білік тығыздагышы	轴封
201	Flans	Фланець	Фланец	法兰
203	Tutucu halka	Стопорне кільце	Ұстасыш сақина	固定环

Pos.	Designation				
	ID	MK	NO	IS	AR
1	Flensa adaptor	Адаптерска прирабница	Adapterflens	Millistykkisflans	الثافة المهيأة
1a	Wadah motor	Подлога за моторот	Motorbukk	Mótorstallur	كرسي المحرك
2	Head pompa	Глава на пумпата	Pumpehode	Dæluhaus	رأس مضخة
3	Chamber, atas	Комора, горна	Kammer, topp	Hólf, efsti hluti	الحجزة العلوية
3a	Chamber tanpa ring leher	Комора без вратен прстен	Kammer uten kragering	Hólf án hálshring	الحجزة دون وجود حلقة الخفيفة
4	Chamber lengkap	Целосна комора	Kammer, komplett	Allt hólfð	الحجزة بالكامل
4a	Chamber dengan ring bantalan motor	Комора со прстен на лежиштето	Kammer med lagerring	Hólf með leguvörn	الحجزة مع وجود حلقة كرسي التحمس
5a	Chamber lengkap	Целосна комора	Kammer, komplett	Allt hólfð	الحجزة بالكامل
6	Alas	Поднојје	Fotstykke	Botn	القاعدية
6a	Pin penghenti	Игличка за запирање	Stoppstift	Festipinni	مسار الإيقاف
6d	Pelat pemandu untuk alas	Основа-водилка за поднојјето	Føringsplate for fotstykke	Stýriplata fyrir botn	اللوح التوجيهي الخاص بالقاعدية
6g	Ring bantalan poros	Прстен на лежиштето	Lagerring	Leguvörn	حاجة كرسي التحمس
7	Pemandu sambungan	Заштитник на спојницата	Koblingsvern	Tengjáhlíf	واقي الفازنة
7a	Sekrup	Завртка	Skrue	Skrúfa	مسار
8	Sambungan selesai	Целосна спојка	Kobling, komplett	Tengingu lokið	الفازنة بالكامل
9	Sekrup	Завртка	Skrue	Skrúfa	مسار
10	Pin poros	Игличка на основата	Akselstift	Skaftipinni	مسار المعود
10a	Sambungan setengah	Полуспојка	Koblingshalvdel	Skrútfungi	نصف الفازنة
12	Flensa (oval)	Прирабница (овална)	Flens (oval)	Flans (sporóskjulaga)	الثافة (البيج - لوارية)
18	Sekrup lubang udara	Завртка за обезвоздушување	Lufteskru	Loftunarskrá	براغي تنفس الهواء
19	Sumbat pipa	Цевен чеп	Rørplugg	Rörtappi	طرف الأنابيب
21	Sumbat	Приклучок	Plugg	Tappi	السدادة
23	Sumbat	Приклучок	Plugg	Tappi	السدادة
25	Sumbat pengurasan	Чеп за празнење	Tappeplugg	Botntappi	سدادة التفريغ
26	But penguat	Спојка	Ankerbolt	Stagbolti	مسار التثبيت
26a	Pengikat	Ремен	Stropp	Ól	الحزام
26b	Sekrup	Завртка	Skrue	Skrúfa	مسار
26c	Cincin	Подлошка	Skive	Skinna	حاجة إحكام الربط
28	Sekrup	Завртка	Skrue	Skrúfa	مسار
28a	Sekrup	Завртка	Skrue	Skrúfa	مسار
31	Sekrup	Завртка	Skrue	Skrúfa	مسار
32	Cincin	Подлошка	Skive	Skinna	حاجة إحكام الربط
32a	Cincin	Подлошка	Skive	Skinna	حاجة إحكام الربط
35	Sekrup	Завртка	Skrue	Skrúfa	مسار
36	Mur	Навртка	Mutter	Ró	صملولة
36a	Mur	Навртка	Mutter	Ró	صملولة
37	O-ring/gasket	О-прстен/дихтуңг	O-ring/pakning	O-hringur/pakkning	حاجة دائريّة/احتياطيّة
38	O-ring	О-прстен	O-ring	O-hringur	حاجة دائريّة


Pos.	Designation				
	ID	MK	NO	IS	AR
38a	O-ring	О-прстен	O-ring	O-hringur	حاجة دائريّة
39	Gasket	Дихтунг	Pakning	Pakkning	حاجة
44	Komponen saluran hisap selesai	Целосен доводен дел	Innløpsdel, komplett	Allur inntakshluti	جزء المدخل بالكامل
44a	Komponen saluran hisap bagian atas	Горен доводен дел	Innløpsdel, øvre	Efri hluti inntakshluta	جزء المدخل العلوي
44b	Komponen saluran hisap bagian bawah	Долен доводен дел	Innløpsdel, nedre	Neðri hluti inntakshluta	جزء المدخل السفلي
45	Ring leher	Вратен прстен	Kragering	Hálsringur	الحلقة العنقية
45a	Ring leher selesai	Целосен вратен прстен	Kragering, komplett	Allur hálsringurinn	الحلقة العنقية بالكاملا
47	Ring bantalan poros	Прстен на лежиштето	Lagerring	Leguvörn	حاجة كرسي التحمل
47a	Bantalan poros dengan pengendali	Лежиште со управувач	Lager med drev	Lega með drifi	كرسي تحمل مزودة بناقل حركة
47b	Ring bantalan poros, berputar	Прстен на лежиштето, ротирачки	Lagerring, roterende	Leguvörn, snúanleg	حاجة كرسي التحمل، مواردة
47c	Selongsong	Славина	Hylse	Hólkur	جلبة
47d	Ring penahan	Потпорен прстен	Sikringsring	Festihringur	حاجة ثبات
47e	Ring penahan	Потпорен прстен	Sikringsring	Festihringur	حاجة ثبات
48	Mur split cone	Навртка на конус-разделник	Konisk mutter	Rofin keiluró	صوامة المخروط ذو التقنية
49	Impeller	Ротор	Pumpehjul	Dæluhjól	المروحة
49a	Impeller	Ротор	Pumpehjul	Dæluhjól	المروحة
49b	Split cone	Конус-разделник	Del konus	Rofin keila	المخروط ذو التقنية
49c	Wear ring	Прстенеста заптивка	Slitering	Slithringur	حاجة التكال
50a	Bagian pelepasan/bilah pemandu atas	Оводен дел/горни лопатки-водилки	Utløpsdel / øvre lameller	Úttakshluti /stýriblöð	جزء المخرج/الأذرع الطبوية الذريعة
51	Poros pompa	Основна на пумпата	Pumpeaksel	Dæluskaft	عمود إدارة المضخة
55	Lengan	Ракав	Hylse	Slif	الجلبة
56	Alas/penampang pompa	Подножная плоча	Fotplate	Undirstöðuplata	لوحة القاعدة
56a	Alas/penampang pompa	Подножная плоча	Fotplate	Undirstöðuplata	لوحة القاعدة
56c	Sekrup	Завртка	Skrue	Skrúfa	مسمار
56d	Cincin	Подлошка	Skive	Skinna	حاجة احكام الربط
57	O-ring	О-прстен	O-ring	O-hringur	حاجة دائريّة
58	Seal carrier	Носач на спојот	Tetringsbærer	Umgjörð um öxulpétti	خليل ساق التسرب
58a	Sekrup	Завртка	Skrue	Skrúfa	مسمار
60	Pegas	Пружина	Fjær	Gormur	زنبرك
61	Pengendali siil	Управувач на спојот	Tetringsbærer	Flansi	نقل الحركة الخاص بساق التسرب
62	Ring penghenti	Прстен за запирање	Stoppring	Stöðvunarhringur	حاجة الإقفال
64	Pipa pengatur jarak	Цевка за растојание	Avstandsrør	Stöðuhólkur	أربووب المياعضة
64a	Pipa pengatur jarak	Цевка за растојание	Avstandsrør	Stöðuhólkur	أربووب المياعضة
64b	Pipa pengatur jarak	Цевка за растојание	Avstandsrør	Stöðuhólkur	أربووب المياعضة
64c	Klem, terbentang	Клема, со жлебно вратило	Klemme, riflet	Klemma, klofin	مشبك، محدد
64d	Pipa pengatur jarak	Цевка за растојание	Avstandsrør	Stöðuhólkur	أربووب المياعضة
65	Penahan ring leher	Потпора на вратен прстен	Krageringsikring	Festing fyrir hálsring	مثبت الحلقة العنقية

Pos.	Designation				
	ID	MK	NO	IS	AR
66	Cincin	Подлошка	Skive	Skinna	حاجة احكام الربط
66a	Cincin	Подлошка	Skive	Skinna	حاجة احكام الربط
66b	Cincin pengunci	Подлошка за блокирање	Låseskive	Lásskinna	حلقة احكام الربط الخاصة بالغلق
67	Mur/sekrup	Навртка/завртка	Mutter/skrue	Ró/skrúfa	الصوولة/المسمار
76a	Pipa pengatur jarak	Цевка за растојањие	Avstandsrør	Stöðuhólkur	أنبوب المساعدة
77	Set pelat label	Прибор со натписни плоочки	Typeskiiltsett	Merkiplötusett	مجموعة لوحة البيانات
69	Rivet	Клин	Nagle	Hnoðnagli	مسمار برشام
76	Penutup head pompa	Капак за главата на гумпата	Pumpehodedeksel	Hlíf á dæluhaus	غطاء رأس المضخة
100	O-ring	О-прстен	O-ring	O-hringur	حلقة دائريّة
105	Flensa adaptor	Запливка за вратило	Akseltetning	Óxulþetti	مائع تسرب عمود الإدارة
201	Wadah motor	Прирабница	Flens	Festibúnaður	الدّفع
203	Head pompa	Потпорен прстен	Sikringsring	Festihringur	حاجة ثبور


## CR, CRI, CRN 1s, 1, 3 and 5



TN02 0453403




TM02 7383 3403



TM01 9996 3600

## Startup

1



TM01 1403 4497

2




TM01 1404 4497

3




TM01 1405 4497

4




TM01 1406 4497

5




TM01 1407 4497

6





TM01 1408 4497

7



TM01 1409 4497



TM01 9988 3600

## GB Startup

<b>1</b>	Close the isolating valve on the outlet side of the pump and open the isolating valve on the inlet side.	<b>2</b>	Remove the priming plug from the pump head and slowly fill the pump with liquid. Replace the priming plug and tighten securely.
<b>3</b>	See the correct direction of rotation of the pump on the motor fan cover.	<b>4</b>	Start the pump and check the direction of rotation.
<b>5</b>	Vent the pump by means of the vent valve in the pump head. At the same time, open the outlet isolating valve a little.	<b>6</b>	Continue to vent the pump. At the same time, open the outlet isolating valve a little more.
<b>7</b>	Close the vent valve when a steady stream of liquid runs out of it. Completely open the outlet isolating valve.	<b>8</b>	For further information, see section <a href="#">4. Starting up the product</a> .

## BG Пускане в действие

<b>1</b>	Затваря се спирателния кран на напорната страна, а този на смукателната се отваря.	<b>2</b>	Демонтира се пробката за пълнене и помпата бавно се пълни.
<b>3</b>	Вижте правилната посока на въртене на капака на мотора.	<b>4</b>	Включете помпата и проверете правилността на посоката на въртене.
<b>5</b>	Обезвъздушете през обезвъздушителния вентил като същевременно малко отворете крана на напорната страна.	<b>6</b>	Продължете да обезвъздушавате като отваряте крана на напорната страна повече.
<b>7</b>	Затворете обезвъздушителния вентил, когато от него протече флуид. Отворете изцяло крана на напорната страна.	<b>8</b>	За повече информация вж. раздел <a href="#">4. Стартиране на продукта</a> .

## CZ Uvedení do provozu

<b>1</b>	Uzavírejte uzavírací armaturu na výtláčné straně čerpadla a otevřete uzavírací armaturu na sací straně čerpadla.	<b>2</b>	Z hlavy čerpadla vyšroubujte plnící zátku a do čerpadla pomalu nalévejte kapalinu. Plnící zátku vrátte na své místo a pevně utáhněte.
<b>3</b>	Podle šipky na krytu ventilátoru motoru čerpadla zjistěte směr otáčení hřidele čerpadla.	<b>4</b>	Zapněte čerpadlo a zkонтrolujte, zda směr otáčení odpovídá směru uvedenému na krytu ventilátoru motoru.
<b>5</b>	Čerpadlo odvzdušňujte pomocí odvzdušňovacího ventilu umístěného ve hlavě čerpadla. Současně mírně pootevřete uzavírací armaturu na výtláčné straně čerpadla.	<b>6</b>	Pokračujte v odvzdušňování čerpadla. Současně otevřete poněkud více uzavírací armaturu na výtláčné straně čerpadla.
<b>7</b>	Odvzdušnovací ventil uzavřete, jakmile jím začne vytékat kapalina bez vzduchu. Otevřete naplněno uzavírací armaturu na výtláčné straně čerpadla tak, abyste dosáhli pracovního bodu čerpadla.	<b>8</b>	Další informace jsou uvedeny v kapitole <a href="#">4. Spouštění výrobku</a> .

## DE Inbetriebnahme

<b>1</b>	Das druckseitige Absperrventil schließen und das saugseitige Absperrventil öffnen.	<b>2</b>	Einfüllstopfen demontieren und Pumpe langsam auffüllen. Einfüllstopfen wieder einschrauben und fest anziehen.
<b>3</b>	Siehe richtige Drehrichtung auf der Lüfterhaube des Motors.	<b>4</b>	Pumpe einschalten und Drehrichtung der Pumpe prüfen.
<b>5</b>	Pumpe über Entlüftungsventil im Kopfstück der Pumpe entlüften. Gleichzeitig das druckseitige Absperrventil ein wenig öffnen.	<b>6</b>	Die Entlüftungsvorgehensweise fortsetzen. Gleichzeitig das druckseitige Absperrventil ein bisschen mehr öffnen.
<b>7</b>	Entlüftungsventil schließen, wenn das Medium aus dem Ventil herausläuft. Das druckseitige Absperrventil ganz öffnen.	<b>8</b>	Weitere Informationen hierzu finden Sie in Abschnitt <a href="#">4. Inbetriebnahme des Produkts</a> .

## DK Idriftsætning

<b>1</b>	Luk afspæringsventilen på pumpens afgangsside og åbn afspæringsventilen på pumpens tilgangsside.	<b>2</b>	Afmontér spædepropren i topstykket og spæd pumpen langsomt. Montér derefter spædepropren igen.
<b>3</b>	Se pumpens korrekte omdrejningsretning på motorens ventilatorskærm.	<b>4</b>	Start pumpen og kontrollér pumpens omdrejningsretning.
<b>5</b>	Udluft pumpen på udluftningsventilen, som er placeret i topstykket. Åbn samtidig afspæringsventilen på pumpens afgangsside lidt.	<b>6</b>	Fortsæt med at udlufte pumpen. Åbn samtidig afspæringsventilen på pumpens afgangsside lidt mere.
<b>7</b>	Luk udluftningsventilen, når der løber en jævn væskestrøm ud af den. Åbn afspæringsventilen på pumpens afgangsside helt.	<b>8</b>	For yderligere information, se afsnit <a href="#">4. Idriftsætning af produktet</a> .

## EE Käivitamine

<b>1</b>	Sulgege ventiil pumba survepoolel ja avage ventiili pumba imipoolel.	<b>2</b>	Eemaldage pumbalt täiteava kork ja täitke pump aegamööda vedelikuga. Pange kork tagasi oma kohale ja kinnitage hoolikalt.
<b>3</b>	Pöörlemisjuund on tähistatud nooltega ventilaatori kattel.	<b>4</b>	Käivitage pump ja kontrollige selle pöörlemisjuunda.
<b>5</b>	Ventileerige pumpa selle peas paikneva õhutusventiili abil. Samal ajal avage veidi survepoolle ventiili.	<b>6</b>	Jätkake pumba ventileerimist. Samal ajal avage veelgi rohkem survepoolle ventiili.
<b>7</b>	Sulgege õhutusventiili niipea, kui vedelik hakkab ühtlaselt välja voolama. Avage survepoolle ventiil täielikult.	<b>8</b>	Lisainfot vt jaotisest <a href="#">4. Pumba käivitamine</a> .

## ES Puesta en marcha

<b>1</b>	Cerrar la válvula de corte en el lado de descarga de la bomba y abrir la válvula de corte en el lado de aspiración.	<b>2</b>	Quitar el tapón de cebado del cabezal de la bomba y llenar la bomba despacio de agua. Volver a poner el tapón de cebado y apretarlo bien.
<b>3</b>	Comprobar el sentido de giro correcto de la bomba en la tapa del ventilador del motor.	<b>4</b>	Poner la bomba en marcha y comprobar el sentido de giro.
<b>5</b>	Purgar la bomba mediante la válvula de purga en el cabezal de la bomba. Al mismo tiempo, abrir un poco la válvula de corte de la descarga.	<b>6</b>	Seguir purgando la bomba. Al mismo tiempo abrir un poco más la válvula de corte de la descarga.
<b>7</b>	Cerrar la válvula de purga cuando salga por la misma un flujo constante de líquido. Abrir la válvula de corte de la descarga completamente.	<b>8</b>	Para obtener más información, consulte la sección <a href="#">4. Puesta en marcha del producto</a> .

## FI Käyttöönotto

<b>1</b>	Sulje pumpun painepuolen sulkiventtiili ja avaa tulopuolen sulkiventtiili.	<b>2</b>	Iroita pumpun yläkappaleen täytötulppa ja täytä pumppu hitaasti. Asenna täytötulppa tämän jälkeen.
<b>3</b>	Tarkista tuuletinkannesta pumpun oikea pyörimissuunta.	<b>4</b>	Käynnistä pumppu ja varmista oikea pyörimissuunta.
<b>5</b>	Ilmaa pumppu yläkappaleessa sijaitsevan ilmausruuvin kautta. Aukaise samalla hiukan pumpun painepuolen sulkiventtiiliä.	<b>6</b>	Jatka pumpun ilmaamista ja avaa pumpun painepuolen sulkiventtiiliä hiukan enemmän.
<b>7</b>	Sulje ilmausventtiili kun siitä suihkuaa tasainen vesivirta. Aukaise pumpun painepuolen sulkiventtiili kokonaan.	<b>8</b>	Lisätietoja on kohdassa <a href="#">4. Käyttöönotto</a> .

## FR Mise en route

<b>1</b>	Fermer la vanne d'isolement du côté refoulement et ouvrir la vanne d'isolement du côté aspiration de la pompe.	<b>2</b>	Démonter le bouchon d'amorçage de la tête de pompe et amorcer lentement la pompe. Remettre en place le bouchon d'amorçage.
<b>3</b>	Voir le sens correct de rotation de la pompe sur le capot du ventilateur du moteur.	<b>4</b>	Démarrer la pompe et vérifier son sens de rotation.
<b>5</b>	Purger la pompe par la vis de purge située dans la tête de pompe. Ouvrir simultanément légèrement la vanne d'isolement du côté refoulement.	<b>6</b>	Continuer à purger la pompe. Ouvrir simultanément un peu plus la vanne d'isolement du côté refoulement.
<b>7</b>	Fermer la vis de purge lorsqu'un filet d'eau homogène s'écoule. Ouvrir entièrement la vanne d'isolement du côté refoulement.	<b>8</b>	Pour plus d'informations, voir paragraphe <a href="#">4. Démarrage</a> .

## GR Εκκίνηση

<b>1</b> Κλείστε τη βάνα απομόνωσης στην πλευρά κατάθλιψης της αντλίας και ανοίξτε τη βάνα απομόνωσης στην πλευρά αναρρόφησης.	<b>2</b> Αφαιρέστε την τάπα πλήρωσης από την κεφαλή της αντλίας και γεμίστε σιγάσιγά την αντλία με υγρό. Επανατοποθετήστε την τάπα πλήρωσης και σφίγξτε τη καλά.
<b>3</b> Δείτε τη σωστή φορά περιστροφής της αντλίας στο κάλυμμα ανεμιστήρα του κινητήρα.	<b>4</b> Θέστε την αντλία σε λειτουργία και ελέγχετε τη φορά περιστροφής.
<b>5</b> Εξαερώστε την αντλία με τη βοήθεια της βαλβίδας εξαέρωσης στην κεφαλή της αντλίας. Ταυτόχρονα, ανοίξτε λίγο τη βάνα απομόνωσης κατάθλιψης.	<b>6</b> Συνεχίστε την εξαέρωση της αντλίας. Ταυτόχρονα, ανοίξτε λίγο ακόμη τη βάνα απομόνωσης κατάθλιψης.
<b>7</b> Κλείστε τη βαλβίδα εξαέρωσης όταν πια η ροή του υγρού που εξέρχεται είναι σταθερή. Ανοίξτε τελείως τη βάνα απομόνωσης κατάθλιψης.	<b>8</b> Για περισσότερες πληροφορίες, βλέπε κεφάλαιο <a href="#">4. Εκκίνηση του προϊόντος</a> .

## HR Puštanje u pogon

<b>1</b> Zatvoriti zaporni ventil na tlačnoj strani a otvoriti zaporni ventili na usisnoj strani.	<b>2</b> Skinuti čep za punjenje pa crpku polagano napuniti. Ponovno vratiti čep za punjenje te ga čvrsto pritegnuti.
<b>3</b> Prekontrolirati ispravni smjer vrtnje na poklopcu ventilatora motora.	<b>4</b> Uključiti crpku pa ispitati ispravni smjer vrtnje crpke.
<b>5</b> Odzračiti crpku preko odzračnog ventila u glavi crpke. Istovremeno malo otvoriti zaporni ventil na tlačnoj strani.	<b>6</b> Nastaviti s odzračivanjem. Istovremeno još malo jače otvoriti zaporni ventil na tlačnoj strani.
<b>7</b> Zatvoriti odzračni ventil kad medij počne izlaziti na ventilu. Potpuno otvoriti zaporni ventil na tlačnoj strani.	<b>8</b> Za više informacija, pogledajte poglavlje <a href="#">4. Pokretanje proizvoda</a> .

## HU Üzembelevezés

<b>1</b> A nyomóoldali elzárószelepét zárjuk el, a szívóoldali elzárószelepét nyissuk ki.	<b>2</b> A betöltőcsavart vegyük ki és a szivattyút lassan töltük fel. A betöltőcsavart csavarjuk vissza és szorosan húzzuk meg.
<b>3</b> Nézzük meg a motor ventillátorfedelén a helyes forgásirányt.	<b>4</b> Kapcsoljuk be a szivattyút és ellenőrizzük forgásirányát.
<b>5</b> A szivattyú fejrészén lévő légtelenítőszelepen át légtelenítünk a szivattyút. Egyidejűleg kissé nyissuk meg a nyomóoldali elzárószelepét.	<b>6</b> Folytassuk a légtelenítést, egyidejűleg kissé jobban nyissuk meg a nyomóoldali elzárószelepét.
<b>7</b> Amikor a légtelenítőszelepen már a levegőmentes szállított közeg lép ki, zárjuk el a szelépet. A nyomóoldali elzárószelepét teljesen nyissuk ki.	<b>8</b> További információkat a <a href="#">4. A termék beüzemelése</a> című részben talál.

## IT Avviamento

<b>1</b>	Chiudere la valvola di intercettazione sul lato di mandata della pompa e aprire quella sul lato di aspirazione.	<b>2</b>	Rimuovere il tappo di adescamento dalla testa pompa e versare lentamente il liquido nella pompa. Reinserire il tappo e chiuderlo accuratamente.
<b>3</b>	Osservare il corretto senso di rotazione della pompa sul coperchio della ventola motore.	<b>4</b>	Avviare la pompa e controllare il senso di rotazione.
<b>5</b>	Sfiicare la pompa per mezzo della valvola di sfiato sulla testa pompa. Contemporaneamente, aprire leggermente la valvola di mandata.	<b>6</b>	Continuare a sfiicare la pompa, continuando contemporaneamente ad aprire la valvola di mandata.
<b>7</b>	Chiudere la valvola di sfiato quando fuoriesce un flusso di liquido costante. Aprire completamente la valvola di mandata.	<b>8</b>	Per ulteriori informazioni, vedi sezione <a href="#">4. Avviamento del prodotto</a> .

## LT Paleidimas

<b>1</b>	Uždarykite vožtuvą siurblio išvado pusėje ir atidarykite vožtuvą siurblio įvado pusėje.	<b>2</b>	Siurblio galvutėje atsukite pripildymo kamštelį ir siurblį lėtai pripildykite skryčio. Įstatykite pripildymo kamštelį ir gerai užveržkite.
<b>3</b>	Pažiūrėkite ant variklio ventiliatoriaus gaubto, kokia yra teisinga siurblio sukimosi kryptis.	<b>4</b>	Paleiskite siurblį ir patirkinkite sukimosi kryptį.
<b>5</b>	Per siurblio galvutėje esantį oro išleidimo vožtuvą išleiskite iš siurblio orą. Tuo pačiu metu truputį atidarykite išvado vožtuvą.	<b>6</b>	Teskite oro išleidimą. Tuo pačiu metu truputį daugiau atidarykite išvado vožtuvą.
<b>7</b>	Oro išleidimo vožtuvą uždarykite, kai iš jo pradeda tekėti nusistovėjusi skryčio čiurkšlė. Visiškai atidarykite išvado vožtuvą.	<b>8</b>	Daugiau informacijos pateikta skyriuje <a href="#">4. Produktų paleidimas</a> .

## LV Iedarbināšana

<b>1</b>	Aizveriet sprostvārstu sūkņa izplūdes pusē un atveriet sprostvārstu ieplūdes pusē.	<b>2</b>	Noņemiet iepildīšanas aizgriezni no sūkņa galvas un lēnām piepildiet sūkni ar šķidrumu. Ievietojiet iepildīšanas aizgriezni atpakaļ un cieši aizgrieziet to.
<b>3</b>	Sūkņa pareizo rotācijas virzienu skatiet uz motora ventilatora vāka.	<b>4</b>	Ieslēdziet sūkni un pārbaudiet rotācijas virzenu.
<b>5</b>	Vent the pump by means of the vent valve in the pump head. At the same time, open the outlet isolating valve a little.	<b>6</b>	Turpiniet sūkņa atgaisošanu. Tajā pašā laikā atveriet izplūdes sprostvārstu nedaudz vairāk.
<b>7</b>	Atgaisojet sūkni, izmantojot sūkņa galvā esošo atgaisošanas vārstu. Vienlaikus nedaudz atveriet izplūdes sprostvārstu.	<b>8</b>	Papildinformāciju skatiet sadaļā <a href="#">4. Produkta ieslēgšana</a> .

## NL In bedrijf nemen

<b>1</b>	Sluit de scheidingsafsluiter aan de perszijde van de pomp en open de afsluiter aan de zuigzijde.	<b>2</b>	Verwijder de ontluchtingsschroef van de pompkop en vul de pomp langzaam met vloeistof. Breng de ontluchtingsschroef terug op zijn plaats en zorg dat deze stevig vast zit.
<b>3</b>	Kijk of de draairichting van de pomp klopt (zie beschermkap van de motorventilator).	<b>4</b>	Start de pomp en controleer de draairichting.
<b>5</b>	Ontlucht de pomp met behulp van de ontluchtingsklep in de pompkop. Open tegelijkertijd de persafsluiter een beetje.	<b>6</b>	Ontlucht de pomp verder. Doe tegelijkertijd de persafsluiter iets verder open.
<b>7</b>	Sluit de ontluchtingsklep wanneer het medium gelijkmataig uit de ontluchtingsopening stroomt. Open de persafsluiter volledig.	<b>8</b>	Voor meer informatie, zie paragraaf <a href="#">4. Het product in bedrijf nemen</a> .

## PL Uruchomienie

<b>1</b>	Zamknąć zawór odcinający na tłoczeniu pompy i otworzyć zawór odcinający na ssaniu.	<b>2</b>	Z głowicy pompy zdjąć korek zalewowy i napełnić pompę cieczą. Założyć korek i dokręcić go mocno.
<b>3</b>	Poprzez pokrywę wentylatora silnika sprawdzić, czy kierunek obrotów pompy jest prawidłowy.	<b>4</b>	Uruchomić pompę i jeszcze raz sprawdzić kierunek obrotów.
<b>5</b>	Poprzez otwór odpowietrzający na głowicy pompy odpowietrzyć pompę. Jednocześnie轻轻地 otworzyć zawór odcinający na tłoczeniu.	<b>6</b>	Dalej odpowietrzać pompę. Jednocześnie jeszcze trochę otworzyć zawór odcinający na tłoczeniu.
<b>7</b>	Gdy z otworu odpowietrzającego zacznie wypływać stalsy strumień cieczy, zamknąć go. Całkowicie otworzyć zawór odcinający na tłoczeniu.	<b>8</b>	Dalsze informacje - zob. rozdział <a href="#">4. Uruchamianie produktu</a> .

## PT Arranque inicial

<b>1</b>	Feche a válvula de seccionamento do lado da descarga e abra a válvula de seccionamento do lado da aspiração.	<b>2</b>	Retire o bujão de purga da cabeça da bomba e lentamente encha esta com o líquido. Monte o bujão de purga.
<b>3</b>	Certifique-se de que o sentido de rotação da bomba está correcto, i.e., está de acordo com o que se indica na tampa do ventilador do motor.	<b>4</b>	Efectue o arranque da bomba e verifique o sentido de rotação.
<b>5</b>	Purge a bomba por meio da respectiva válvula, existente na cabeça da bomba. Ao mesmo tempo, abra ligeiramente a válvula de seccionamento do lado da descarga.	<b>6</b>	Continue a purgar a bomba. Ao mesmo tempo, abra um pouco mais a válvula de seccionamento do lado da descarga.
<b>7</b>	Feche a válvula de purga quando um caudal uniforme começar a sair por ela. Abra agora completamente a válvula de seccionamento do lado da descarga.	<b>8</b>	Para mais informações, consulte a secção <a href="#">4. Proceder ao arranque do produto</a> .

## RO Punerea în funcțiune

<b>1</b> Închideți vana de refulare și deschideți vana de aspirație complet.	<b>2</b> Desfaceți ventilul de amorsare din capul pompei și încet umpleți pompa cu lichid. Strângeți bine ventilul după umplere.
<b>3</b> Urmăriți sensul corect de rotație al pompei indicat la partea superioară a motorului la ventilator.	<b>4</b> Porniți pompa și verificați sensul de rotație.
<b>5</b> Aerisiti pompa prin intermediul ventilului de aerisire situat în capul pompei. În același timp deschideți vana de refulare.	<b>6</b> Continuați să aerisiti pompa. În același timp deschideți vana de refulare progresiv.
<b>7</b> Închideți ventilul de aerisire când apa începe să arunce prin orificiu. Se va deschide complet vana de refulare.	<b>8</b> Pentru informații suplimentare, vezi secțiunea <a href="#">4. Pornirea în funcțiune a produsului</a> .

## RS Puštanje u rad

<b>1</b> Zatvoriti zaustavni ventil na potisnoj strani i otvoriti zaustavni ventil na usisnoj strani.	<b>2</b> Demontirati ulivni priključak i polako napuniti pumpu. Novo ušrafiti ulivni priključak i čvrsto ga pritegnuti.
<b>3</b> Uočiti pravilan smer obrtanja na poklopcu ventilatora motora.	<b>4</b> Uključiti pumpu i proveriti smer obrtanja pumpe.
<b>5</b> Odzračiti pumpu preko odzračnog ventila na glavi pumpe. Istovremeno malo otvoriti zaustavni ventil na potisnoj strani.	<b>6</b> Nastaviti sa postupkom odzračivanja. Istovremeno zaustavni ventil na potisnoj strani otvoriti još malo više.
<b>7</b> Kada radni fluid počne da ističe iz ventila zatvoriti odzračni ventil. Zaustavni ventil na potisnoj strani potpuno otvoriti.	<b>8</b> Za više informacija, pogledajte poglavlje <a href="#">4. Puštanje proizvoda u rad</a> .

## SE Igångkörning

<b>1</b> Stäng avstängningsventilen på pumpens trycksida och öppna avstängningsventilen på sugsidan.	<b>2</b> Avlägsna späddproppen i toppstycket och fyll pumpen långsamt. Sätt sedan tillbaka proppen.
<b>3</b> Kontrollera rätt rotationsriktning enligt motorns fläktkåpa.	<b>4</b> Starta pumpen och kontrollera pumpens rotationsriktning.
<b>5</b> Avlufta pumpen med hjälp av ventilen på toppstycket. Öppna samtidigt avstängningsventilen på pumpens trycksida något.	<b>6</b> Fortsätt avlufta pumpen. Öppna samtidigt avstängningsventilen på trycksidan lite till.
<b>7</b> Stäng avluftningsventilen när en jämn vätskeström kommer ut ur den. Öppna avstängningsventilen på trycksidan helt.	<b>8</b> Mer information finns i avsnitt <a href="#">4. Igångkörning av produkten</a> .

## SI Zagon

<b>1</b>	Tlačni zaporni ventil zapreti in odpreti sesalni zaporni ventil.	<b>2</b>	Čep odprtine za nalivanje odpreti in črpalko počasi napolniti. Ponovno priviti čep in močno pritegniti.
<b>3</b>	Kontrolirati je potrebno pravilno smer vrtenja na pokrovu hlajenja motorja.	<b>4</b>	Vklopiti črpalko in preveriti smer vrtenja črpalke.
<b>5</b>	Črpalko odzračiti s pomočjo odzračevalnega ventila na glavi črpalke. Istočasno nekoliko odpreti zaporni ventil na tlačni strani.	<b>6</b>	Odzračevalni postopek nadaljevati. Istočasno na tlačni strani še bolj odpreti zaporni ventil.
<b>7</b>	Odzračevalni ventil zapreti, ko prične iztekatki medij. Zaporni ventil na tlačni strani popolnoma odpreti.	<b>8</b>	Za več informacij glejte poglavje <a href="#">4. Zagon izdelka</a> .

## SK Uvedenie do prevádzky

<b>1</b>	Uzavrite uzatváraciu armatúru na výtláčnej strane čerpadla a otvorte uzatváraciu armatúru na sacej strane čerpadla.	<b>2</b>	Z hlavy čerpadla vyskrutkujte plniacu zátku a do čerpadla pomaly naliievajte kvapalinu. Plniacu zátku naskrutkujte späť a pevne ju dotiahnite.
<b>3</b>	Podľa šípk na kryte ventilátora motora čerpadla zistite smer otáčania sa hriadeľa čerpadla.	<b>4</b>	Zapnite čerpadlo a skontrolujte, či smer otáčania sa hriadeľa zodpovedá smeru uvedenom na kryte ventilátora motora.
<b>5</b>	Čerpadlo odvzdušníte pomocou odvzdušňovacieho ventila umiestneného v hlave čerpadla. Súčasne mierne pootvorte uzatváraciu armatúru na výtláčnej strane čerpadla.	<b>6</b>	Pokračujte v odvzdušňovaní čerpadla. Súčasne trochu pootvorte uzatváraciu armatúru na výtláčnej strane čerpadla.
<b>7</b>	Odvzdušňovaci ventil uzatvorte akonáhle z neho začne vytiekať kvapalina. Naplno otvorte uzatváraciu armatúru na výtláčnej strane čerpadla tak, aby ste dosiahli pracovný bod čerpadla.	<b>8</b>	Ďalšie informácie sú uvedené v časti <a href="#">4. Spustenie čerpadla</a> .

## TR İlk çalışma

<b>1</b>	Pompanın basma tarafındaki izolasyon vanasını kapatın ve emme tarafındaki izolasyon vanasını açın.	<b>2</b>	Doldurma tapasını pompa başından söküp ve pompayı sıvı ile doldurun. Doldurma tapasını tekrar yerine takın ve sağlam bir şekilde sıkın.
<b>3</b>	Motor fan kapağında bulunan doğru pompa dönüş yönüne bakın.	<b>4</b>	Pompayı çalıştırın ve dönüş yönünü kontrol edin.
<b>5</b>	Pompa başında bulunan tahliye valfi yardımıyla pompanın havasını alın. Aynı anda, basma izolasyon valfini biraz açın.	<b>6</b>	Pompanın havasını almaya devam edin. Aynı anda, basma izolasyon valfini biraz daha açın.
<b>7</b>	Düzenli bir sıvı akışı gerçekleştiğinde, tahliye valfini kapatın. Basma izolasyon valfini tamamen açın.	<b>8</b>	Daha fazla bilgi için bkz. bölüm <a href="#">4. Ürünün çalıştırılması</a> .

## UA Запуск

<b>1</b>	Закрити запірний кран на виході насоса та відкрити запірний кран на всмоктувальному трубопроводі.	<b>2</b>	Викрутити заглушку з верхньої частини насоса та повільно заповнити насос рідиною. Викрутити заглушку.
<b>3</b>	Перевірити правильний напрямок обертання насоса, що вказаний на кришці вентилятора.	<b>4</b>	Запустити насос та перевірити напрямок обертання.
<b>5</b>	Видалити повітря з насоса з допомогою повітряного клапана в верхній частині насоса. Одночасно привідкрити вихідний запірний кран.	<b>6</b>	Продовжувати видавляти повітря з насоса. Одночасно відкрити вихідний кран ще трохи більше.
<b>7</b>	Закрити повітряний клапан, коли постійний потік рідини потече з насоса. Повністю відкрити вихідний запірний кран.	<b>8</b>	Додаткову інформацію див. у розділі <a href="#">4. Запуск експлуатації</a> .

## CN 启动

<b>1</b>	关闭水泵出水侧的隔离阀，打开进水侧的隔离阀。	<b>2</b>	从泵头上拆下注水塞并缓慢加注水泵。装好注水塞并确保拧紧。
<b>3</b>	在电机风扇盖上察看水泵正确的转动方向。	<b>4</b>	启动水泵，检查转动方向。
<b>5</b>	通过位于泵头的排气阀对泵排气。与此同时，再略微打开出水侧隔离阀。	<b>6</b>	继续对水泵排气。与此同时，再将出水侧隔离阀打开得更大一点。
<b>7</b>	在看到液体持续平稳地从排气阀流出后关闭此阀。 完全打开出水隔离阀。	<b>8</b>	更多信息请参见章节 <a href="#">4. 启动产品</a> 。

## MK Вклучување

<b>1</b>	Затворете го изолацискиот вентил на одводната страна од пумпата и полека отворете го изолацискиот вентил на креводната страна.	<b>2</b>	Извадете го чепот за вшмукување од главата на пумпата и полека наполнете ја пумпата со течност. Заменете го чепот за вшмукување и цврсто затегнете го.
<b>3</b>	Точниот правец на ротација е прикажан со стрелки на капакот на вентилаторот на моторот.	<b>4</b>	Вклучете ја пумпата и проверете ја насоката на ротирање.
<b>5</b>	Обезвоздушете ја пумпата со помош на вентил за обезвоздушување во главата на пумпата. Истовремено, подврете го одводниот изолациски вентил.	<b>6</b>	Продолжете со обезвоздушување на пумпата. Истовремено, отворете го малку повеќе одводниот изолациски вентил.
<b>7</b>	Затворете го вентилот за обезвоздушување штом од него ќе протече рамномерен млаз течност. Целосно отворете го одводниот изолациски вентил.	<b>8</b>	За дополнителни информации, видете во делот <a href="#">4. Вклучување на производот</a> .

## ID Mulai

<b>1</b>	Tutup katup penutup di bagian pelepasan pompa lalu buka katup penutup di bagian hisap.	<b>2</b>	Lepas sumbat pemancing dari kepala pompa lalu secara perlahan isilah pompa dengan air. Pasang kembali sumbat pemancing dan kencangkan.
<b>3</b>	Lihat arah rotasi pompa yang benar pada penutup kipas motor.	<b>4</b>	Jalankan pompa lalu periksa arah rotasi pompa.
<b>5</b>	Pancing pompa dengan menggunakan sumbat pemancing di head pompa. Pada saat bersamaan, buka sedikit katup pemisah dengan sisi pelepasan.	<b>6</b>	Lanjutkan memancing pompa. Pada saat bersamaan, buka lebih lebar katup pemisah dengan sisi pelepasan.
<b>7</b>	Tutup katup pemancing setelah air keluar deras. Membuka sepenuhnya katup pemisah pelepasan.	<b>8</b>	Untuk informasi lebih lanjut, lihat bagian <a href="#">4. Menghidupkan produk</a> .

## NO Oppstart

<b>1</b>	Steng isoleringsventilen på utløpssiden av pumpen og åpne isoleringsventilen på innløpssiden.	<b>2</b>	Fjern fyllepluggen fra pumpehodet og fyll pumpen langsomt med væske. Sett på plass fyllepluggen og trekk godt til.
<b>3</b>	Se riktig rotasjonsretning for pumpen på motorviftedekselet.	<b>4</b>	Start pumpen og kontroller rotasjonsretningen.
<b>5</b>	Luft ut pumpen ved hjelp av lufteventilen i pumpehodet. Åpne samtidig utløpsventilen litt.	<b>6</b>	Fortsett å lufte pumpen. Åpne samtidig utløpsventilen litt mer.
<b>7</b>	Steng lufteventilen når en jevn strøm av væske kommer ut av den. Åpne utløpsventilen helt.	<b>8</b>	Du finner flere opplysninger i avsnitt <a href="#">4. Oppstart av produktet</a> .

## IS Ræsing

<b>1</b>	Lokið einangrunarloknum á úttakshlið dælunnar og opnið einangrunarlokann á inntakshliðinni.	<b>2</b>	Fjarlægið forgjafartappann úr dæluhausnum og fyllið dæluna hægt með vökv. Setjið forgjafartappann aftur í og herðið tryggilega.
<b>3</b>	Upplýsingar um rétta snúningsstefnu dælunnar eru á viftuhlíf mótorsins.	<b>4</b>	Ræsið dæluna og athugið snúningsstefnuna.
<b>5</b>	Loftið út úr dælunni með því að nota loftlokkann í dæluhausnum. Opnið úttakseinangrunarlokann lítillega um leið.	<b>6</b>	Haldið áfram að lofta út úr dælunni. Opnið um leið aðeins meira fyrir úttakseinangrunarlokann.
<b>7</b>	Lokið loftlokanum þegar stöðugur straumur af vökv rennur út um hann. Opnið úttakseinangrunarlokann alveg.	<b>8</b>	Nánari upplýsingar eru í kafla <a href="#">4. Gangsetning vörunnar</a> .

ـ دعـة التـشـغـيل

## YETKİLİ GRUNDFOS SERVİSLERİ

Firma	Adres	Telefon Cep telefonu Faks	İlgili Kişi Eposta
GRUNDFOS POMPA KOCAELİ	GEBZE ORGANİZE SANAYİ BÖLGESİ. İHSAN DEDE CADDESİ.2.YOL 200.SOKAK.NO:204 GEBZE KOCAELİ	0262 679 79 79 0553 259 51 63 0262 679 79 05	EMRAH ŞİMŞEK esimsek@grundfos.com
SUNPO ELEKTRİK ADANA	YEŞİLOBA MAH. 46003 SOK. ARSLANDAMİ İŞ MERK. C BLOK NO:6/2-1 SEYHAN ADANA	0322 428 50 14 0533 461 71 14 0322 428 48 49	LEVENT BAKIRKOL sunpo-elektrik@hotmail.com
ARDA POMPA ANKARA	26 NOLU İŞ MERKEZİ 1120.SOKAK NO:5/1,5/5 OSTİM/ANKARA	0312 385 98 93 0541 805 89 44 0312 385 8904	METİN ENGİN CANBAZ metincanbaz@ardapompa.com.tr
ÜĞUR SU POMPALARı ANKARA	AHİ EVRAN MAHALLESİ ÇAĞRIŞIM CADDESİ NO:2/15 SİNCAN /ANKARA	0312 394 37 52 0532 505 12 62 0312 394 37 19	ÜĞUR YETİŞ ÖCAL uguryetisocal@gmail.com
GROSER A.Ş. ANTALYA	ŞAFAK MAHALLESİ.5041.SOKAK.SANAYİ 28 C BLOK NO:29 KEPEZ ANTALYA	0242 221 43 43 0532 793 89 74 0242 221 43 42	DOĞAN YÜCEL servis@groseras.com
KOÇYİĞİTLER ELEKTRİK BOBİNAJ ANTALYA	ORTA MAH. SERİK CAD. NO.116 SERİK ANTALYA	0242 722 48 46 0532 523 29 34 0242 722 48 46	BİLAL KOÇYİĞİT kocigitler@kocigitlerbobinaj.com
TEKNİK BOBİNAJ BURSA	ALAADDİN BEY MH.624.SK MESE 5 İŞ MERKEZİ NO:26 D:10 NİLÜFER/BURSA	0224 443 78 83 0507 311 19 08 0224 443 78 95	GÜLDEN MÜÇEOĞLU gulden@bobinaj.com.tr
ASİN TEKNOLOJİ GAZİANTEP	MÜCAHİTLER MAHALLESİ 54 NOLU SOKAK.GÜNEYDOĞU İŞ MERKEZİ NO:10/A ŞEHİTKAMİL	0342 321 69 66 0532 698 69 66 0342 321 69 61	MEHMET DUMAN mduman@asinteknoloji.com.tr
ARI MOTOR İSTANBUL	ORHANLI MESCİT MH.DEMOKRASİ CD.BİRMES SAN.SİT.A-3 BLOK NO:9 TUZLA İSTANBUL	0216 394 21 67 0532 501 47 69 0216 394 23 39	EMİN ARI aycan@arimotor.com.tr
SERİ MEKANİK İSTANBUL	SEYİTNİZAM MAH. DEMİRCİLER SİT. 7.YOL . NO:6 ZEYTİNBURNU İSTANBUL	0212 679 57 23 0532 740 18 02 0212 415 61 98	TAMER ERÜNSAL servis@serimekanik.com
DAMLA POMPA İZMİR	1203/4 SOKAK NO:2/E YENİŞEHİR İZMİR	0232 449 02 48 0532 277 96 44 0232 459 43 05	NEVZAT KIYAK nkiyak@damlapompa.com
ÇAĞRI ELEKTRİK KAYSERİ	ESKİ SANAYİ BÖLGESİ 3.CADDE NO:3-B KOCASINAN-KAYSERİ	0352 320 19 64 0532 326 23 25 0352 330 37 36	ADEM ÇAKICI kayseri.cagrielektrik@gmail.com
MAKSOM OTOMASYON SAMSUN	19 MAYIS MAHALLESİ.642.SOKAK.NO:23 TEKKEKÖY SAMSUN	0362 256 23 56 0532 646 61 42 -	MUSTAFA SARı info@maksom.com
DETAY MÜHENDİSLİK TEKİRDAG	ZAFER MAHALLESİ ŞEHİT YÜZBAŞI YÜCEL KENTER CADDESESİ 06/A BLOK NO:5-6 ÇORLU TEKİRDAG	0282 673 51 33 0549 668 68 68 0282 673 51 35	EROL KARTOĞLU erol@detay-muhendislik.com
ROTATEK ENDÜSTRİYEL TEKİRDAG	ZAFER MH. ŞEHİT YÜZBAŞI YÜCEL KENTER CD. YENİ SANAYİ SİTESİ 08-A BLOK NO:14 ÇORLU / TEKİRDAG	0282 654 51 99 0532 788 11 39 0282 654 51 81	ÖZCAN AKBAŞ ozcan@rotaendustriyel.com
İLDEM TEKNİK İSITMA VAN	ŞEREFIYE MAH ORDU CAD ARAS AP NO 75 İPEKYOLU VAN	0432 216 20 83 0532 237 54 59 0432 216 20 83	BURHAN DEMİREKİ il-dem-teknik@hotmail.com
BARIŞ BOBİNAJ K.K.T.C.	LARNAKA YOLU ÜZERİ.PAPATYA APT.NO:3-4 GAZİMAĞUSA	0542 884 06 62 0542 854 11 35 0533 884 06 62	BARIŞ KIZILKILINÇ barisbobinaj@hotmail.com

## **Argentina**

Bombas GRUNDFOS de Argentina S.A.  
Ruta Panamericana km. 37.500 Centro  
Industrial Garín  
1619 Garín Pcia. de B.A.  
Phone: +54-3327 414 444  
Telefax: +54-3327 45 3190

## **Australia**

GRUNDFOS Pumps Pty. Ltd.  
P.O. Box 2040  
Regency Park  
South Australia 5942  
Phone: +61-8-8461-4611  
Telefax: +61-8-8340 0155

## **Austria**

GRUNDFOS Pumpen Vertrieb  
Ges.m.b.H.  
Grundfosstraße 2  
A-5082 Grödig/Salzburg  
Tel.: +43-6246-883-0  
Telefax: +43-6246-883-30

## **Belgium**

N.V. GRUNDFOS Bellux S.A.  
Boomsesteenweg 81-83  
B-2630 Aartselaar  
Tél.: +32-3-870 7300  
Télécopie: +32-3-870 7301

## **Belarus**

Представительство ГРУНДФОС в  
Минске  
220125, Минск  
ул. Шаффарнянская, 11, оф. 56, БЦ  
«Порт»  
Тел.: +375 17 397 397 3  
+375 17 397 397 4  
Факс: +375 17 397 397 1  
E-mail: minsk@grundfos.com

## **Bosnia and Herzegovina**

GRUNDFOS Sarajevo  
Zmaja od Bosne 7-7A,  
BH-71000 Sarajevo  
Phone: +387 33 592 480  
Telefax: +387 33 590 465  
www.ba.grundfos.com  
e-mail: grundfos@bih.net.ba

## **Brazil**

BOMBAS GRUNDFOS DO BRASIL  
Av. Humberto de Alencar Castelo  
Branco, 630  
CEP 09850 - 300  
São Bernardo do Campo - SP  
Phone: +55-11 4393 5533  
Telefax: +55-11 4343 5015

## **Bulgaria**

Grundfos Bulgaria EOOD  
Slatina District  
Iztochna Tangenta street no. 100  
BG - 1592 Sofia  
Tel. +359 2 49 22 200  
Fax. +359 2 49 22 201  
email: bulgaria@grundfos.bg

## **Canada**

GRUNDFOS Canada Inc.  
2941 Brighton Road  
Oakville, Ontario  
L6H 6C9  
Phone: +1-905 829 9533  
Telefax: +1-905 829 9512

## **China**

GRUNDFOS Pumps (Shanghai) Co. Ltd.  
10F The Hub, No. 33 Suhong Road  
Minhang District  
Shanghai 201106  
PRC  
Phone: +86 21 612 252 22  
Telefax: +86 21 612 253 33

## **COLOMBIA**

GRUNDFOS Colombia S.A.S.  
Km 1.5 vía Siberia-Cota Conj. Potrero  
Chico,  
Parque Empresarial Arcos de Cota Bod.  
1A.  
Cota, Cundinamarca  
Phone: +57(1)-2913444  
Telefax: +57(1)-8764586

## **Croatia**

GRUNDFOS CROATIA d.o.o.  
Buzinski prilaz 38, Buzin  
HR-10010 Zagreb  
Phone: +385 1 6595 400  
Telefax: +385 1 6595 499  
www.hr.grundfos.com

## **GRUNDFOS Sales Czechia and**

### **Slovakia s.r.o.**

Čajkovského 21  
779 00 Olomouc  
Phone: +420-585-716 111

## **Denmark**

GRUNDFOS DK A/S  
Martin Bachs Vej 3  
DK-8850 Bjerringbro  
Tlf.: +45-87 50 50 50  
Telefax: +45-87 50 51 51  
E-mail: info\_GDK@grundfos.com  
www.grundfos.com/DK

## **Estonia**

GRUNDFOS Pumps Eesti OÜ  
Peterburi tee 92G  
11415 Tallinn  
Tel: + 372 606 1690  
Fax: + 372 606 1691

## **Finland**

GRUNDFOS Pumpum AB  
Trukkikuja 1  
FI-01360 Vantaa  
Phone: +358-(0) 207 889 500

## **France**

Pompes GRUNDFOS Distribution S.A.  
Parc d'Activités de Chesnés  
57, rue de Malacobre  
F-38290 St. Quentin Fallavier (Lyon)  
Tél.: +33-4 74 82 15 15  
Télécopie: +33-4 74 94 10 51

## **Germany**

GRUNDFOS GMBH  
Schlütersstr. 33  
40699 Erkrath  
Tel.: +49-(0) 211 929 69-0  
Telefax: +49-(0) 211 929 69-3799  
e-mail: infoservice@grundfos.de  
Service in Deutschland:  
e-mail: kundendienst@grundfos.de

## **Greece**

GRUNDFOS Hellas A.E.B.E.  
20th km. Athinon-Markopoulou Av.  
P.O. Box 71  
GR-19002 Peania  
Phone: +0030-210-66 83 400  
Telefax: +0030-210-66 46 273

## **Hong Kong**

GRUNDFOS Pumps (Hong Kong) Ltd.  
Unit 1, Ground floor  
Siu Wai Industrial Centre  
29-33 Wing Hong Street &  
68 King Lam Street, Cheung Sha Wan  
Kowloon  
Phone: +852-27861706 / 27861741  
Telefax: +852-27858664

## **Hungary**

GRUNDFOS Hungária Kft.  
Tópark u. 8  
H-2045 Törökbalint,  
Phone: +36-23 511 110  
Telefax: +36-23 511 111

## **India**

GRUNDFOS Pumps India Private  
Limited  
118 Old Mahabalipuram Road  
Thoraipakkam  
Chennai 600 096  
Phone: +91-44 2496 6800

## **Indonesia**

PT. GRUNDFOS POMPA  
Graha Intirub Lt. 2 & 3  
Jln. Ciliilitan Besar No.454. Makasar,  
Jakarta Timur  
ID-Jakarta 13650  
Phone: +62 21-469-51900  
Telefax: +62 21-460 6910 / 460 6901

## **Ireland**

GRUNDFOS (Ireland) Ltd.  
Unit A, Merrywell Business Park  
Ballymount Road Lower  
Dublin 12  
Phone: +353-1-4089 800  
Telefax: +353-1-4089 830

## **Italy**

GRUNDFOS Pompe Italia S.r.l.  
Via Gran Sasso 4  
I-20060 Truccazzano (Milano)  
Tel.: +39-02-95838112  
Telefax: +39-02-95309290 / 95838461

## **Japan**

GRUNDFOS Pumps K.K.  
1-2-3, Shin-Miyakoda, Kita-ku,  
Hamamatsu  
431-2103 Japan  
Phone: +81 53 428 4760  
Telefax: +81 53 428 5005

## **Korea**

GRUNDFOS Pumps Korea Ltd.  
6th Floor, Ajou Building 679-5  
Yeoksam-dong, Kangnam-ku, 135-916  
Seoul, Korea  
Phone: +82-2-5317 600  
Telefax: +82-2-5633 725

## **Latvia**

SIA GRUNDFOS Pumps Latvia  
Deglava biznesa centrs  
Augusta Deglava ielā 60, LV-1035, Riga,  
Tāl.: + 371 714 9640, 7 149 641  
Fakss: + 371 914 9646

## **Lithuania**

GRUNDFOS Pumps UAB  
Smolensko g. 6  
LT-03201 Vilnius  
Tel: + 370 52 395 430  
Fax: + 370 52 395 431

**Malaysia**

GRUNDFOS Pumps Sdn. Bhd.  
7 Jalan Peguam U1/25  
Glenmarie Industrial Park  
40150 Shah Alam  
Selangor  
Phone: +60-3-5569 2922  
Telefax: +60-3-5569 2866

**Mexico**

Bombas GRUNDFOS de México S.A. de C.V.  
Boulevard TLC No. 15  
Parque Industrial Stiva Aeropuerto  
Apodaca, N.L. 66600  
Phone: +52-81-8144 4000  
Telefax: +52-81-8144 4010

**Netherlands**

GRUNDFOS Netherlands  
Veluwzezoom 35  
1326 AE Almere  
Postbus 22015  
1302 CA ALMERE  
Tel.: +31-88-478 6336  
Telefax: +31-88-478 6332  
E-mail: info\_gnl@grundfos.com

**New Zealand**

GRUNDFOS Pumps NZ Ltd.  
17 Beatrix Tinsley Crescent  
North Harbour Industrial Estate  
Albany, Auckland  
Phone: +64-9-415 3240  
Telefax: +64-9-415 3250

**Norway**

GRUNDFOS Pumper A/S  
Strømsveien 344  
Postboks 235, Leirdal  
N-1011 Oslo  
Tlf.: +47-22 90 47 00  
Telefax: +47-22 32 21 50

**Poland**

GRUNDFOS Pompy Sp. z o.o.  
ul. Klonowa 23  
Baranowo, k. Poznania  
PL-62-081 Przeźmierowo  
Tel: (+48-61) 650 13 00  
Fax: (+48-61) 650 13 50

**Portugal**

Bombas GRUNDFOS Portugal, S.A.  
Rua Calvet da Magalhães, 241  
Apartado 1079  
P-2770-153 Paço de Arcos  
Tel.: +351-21-440 76 00  
Telefax: +351-21-440 76 90

**Romania**

Grundfos Pompe România SRL  
S-PARK BUSINESS CENTER, Clădirea  
A2, etaj 2, Str. Tipografilor, Nr. 11-15,  
Sector 1, Cod 013714, Bucuresti,  
Romania,  
Tel: 004 021 2004 100  
E-mail: romania@grundfos.ro  
www.grundfos.ro

**Russia**

ООО Грундфос Россия  
ул. Школьная, 39-41  
Москва, RU-109544, Russia  
Тел. (+7) 495 564-88-00 (495) 737-30-00  
Факс (+7) 495 564 8811  
E-mail grundfos.moscow@grundfos.com

**Serbia**

Grundfos Srbija d.o.o.  
Omladinskih brigada 90b  
11070 Novi Beograd  
Phone: +381 11 2258 740  
Telefax: +381 11 2281 769  
www.rs.grundfos.com

**Singapore**

GRUNDFOS (Singapore) Pte. Ltd.  
25 Jalan Tukang  
Singapore 619264  
Phone: +65-6681 9688  
Telefax: +65-6681 9689

**Slovakia**

GRUNDFOS s.r.o.  
Prievozská 4D  
821 09 BRATISLAVA  
Phone: +421 2 5020 1426  
sk.grundfos.com

**Slovenia**

GRUNDFOS LJUBLJANA, d.o.o.  
Leskoškova 9e, 1122 Ljubljana  
Phone: +386 (0) 1 568 06 10  
Telefax: +386 (0) 1 568 06 19  
E-mail: tehnika-si@grundfos.com

**South Africa**

Grundfos (PTY) Ltd.  
16 Lascelles Drive, Meadowbrook Estate  
1609 Germiston, Johannesburg  
Tel.: (+27) 10 248 6000  
Fax: (+27) 10 248 6002  
E-mail: lgradidge@grundfos.com

**Spain**

Bombas GRUNDFOS España S.A.  
Camino de la Fuentecilla, s/n  
E-28110 Algete (Madrid)  
Tel.: +34-91-848 8800  
Telefax: +34-91-628 0465

**Sweden**

GRUNDFOS AB  
Box 333 (Lunnagårdsgatan 6)  
431 24 Mölndal  
Tel.: +46 31 332 23 000  
Telefax: +46 31 331 94 60

**Switzerland**

GRUNDFOS Pumpen AG  
Bruggacherstrasse 10  
CH-8117 Fällanden/ZH  
Tel.: +41-44-806 8111  
Telefax: +41-44-806 8115

**Taiwan**

GRUNDFOS Pumps (Taiwan) Ltd.  
7 Floor, 219 Min-Chuan Road  
Taichung, Taiwan, R.O.C.  
Phone: +886-4-2305 0868  
Telefax: +886-4-2305 0878

**Thailand**

GRUNDFOS (Thailand) Ltd.  
92 Chaloem Phrakiat Rama 9 Road,  
Dokmai, Pravej, Bangkok 10250  
Phone: +66-2-725 8999  
Telefax: +66-2-725 8998

**Turkey**

GRUNDFOS POMPA San. ve Tic. Ltd.  
Sti.  
Gebze Organize Sanayi Bölgesi  
Ihsan dede Caddesi,  
2. yol 200, Sokak No. 204  
41490 Gebze/ Kocaeli  
Phone: +90 - 262-679 7979  
Telefax: +90 - 262-679 7905  
E-mail: satis@grundfos.com

**Ukraine**

Бізнес Центр Європа  
Столичне шосе, 103  
м. Київ, 03131, Україна  
Телефон: (+38 044) 237 04 00  
Факс: (+38 044) 237 04 01  
E-mail: ukraine@grundfos.com

**United Arab Emirates**

GRUNDFOS Gulf Distribution  
P.O. Box 16768  
Jebel Ali Free Zone  
Dubai  
Phone: +971 4 8815 166  
Telefax: +971 4 8815 136

**United Kingdom**

GRUNDFOS Pumps Ltd.  
Grovebury Road  
Leighton Buzzard/Beds. LU7 4TL  
Phone: +44-1525-850000  
Telefax: +44-1525-850011

**U.S.A.**

GRUNDFOS Pumps Corporation  
9300 Loiret Blvd.  
Lenexa, Kansas 66219  
Phone: +1-913-227-3400  
Telefax: +1-913-227-3500

**Uzbekistan**

Grundfos Tashkent, Uzbekistan The  
Representative Office of Grundfos  
Kazakhstan in Uzbekistan  
38a, Oybek street, Tashkent  
Телефон: +(998) 71 150 3290 / 71 150  
3291  
Факс: +(998) 71 150 3292

Addresses Revised 09.09.2020

**96462123** 11.2020

ECM: 1298290

[www.grundfos.com](http://www.grundfos.com)

**GRUNDFOS** X